U.S. Department of Transportation
Federal Aviation Administration

Aviation Environmental Design Tool (AEDT)

Supplemental Manual

AEDT Standard Input File (ASIF)

March 2021

Table of Contents

1 INTRODUCTION 1

1.1 Overview of the ASIF Format 1
1.2 ASIF Schema Documentation 1
1.2.1 ASIF Schema Files 1
1.2.2 AsifMerge.html 1
1.3 Importing External Studies 2

2 ASIF IMPORT TYPES 3

2.1 Full Study Import 3
2.2 Partial ASIF Import 3
2.3 Sample ASIFs 4

3 ASIF EXAMPLES 5

3.1 Create a Simple Study 5
1. Create empty study file 5
2. Populate airport layouts section 6
3. Create receptor set 7
4. Create scenario and case hierarchy 7
5. Populate cases with tracks and air operations 8
6. Create annualization 10
7. Full ASIF 10
3.2 Create an Emissions Dispersion Study 15
1. Create empty study file 16
2. Populate airport layouts section 16
a) Define airport layout 16
b) Define stationary sources 16
c) Define airport gates/terminals 17
d) Define taxiways 18
e) Define runways 19
f) Assemble taxipaths 20
g) Define tracks 21
h) Define airport operating configurations 22
i) Define operational profiles 24
3. Define receptor set 26
4. Define scenario and case hierarchy 26
a) Define scenario properties 26
b) Define the case for non-aircraft operations 27
c) Define the case for aircraft operations 27
5. Full ASIF 30

4 USER-DEFINED ANP AND BADA 4 PROFILES 31

4.1 Overview 31
4.2 User-Defined ANP Profiles 32
4.2.1 Key Requirements for a New ANP Profile 32
4.2.2 ANP Profile – Procedure Steps 32
Sample ASIF for User-Defined ANP Procedural Profile 33
4.2.3 ANP Profile – Fixed-Point 34
Sample ASIF for User-Defined ANP Fixed-Point Profile 34
4.3 User-Defined BADA 4 Profiles (for Existing BADA 4 Aircraft) 35

4.3.1 Key Requirements for a New BADA 4 Profile *35*
Sample ASIF for User-Defined BADA 4 Profile 37
4.4 Create User-Defined ANP and BADA 4 Profiles for New or Existing Aircraft by Using the GUI Export Aircraft Feature 37
4.4.1 Create a New User-Defined Aircraft with Custom Profiles *37*
1. Copy an existing system aircraft to create a new user-defined aircraft *38*
2. Export the new aircraft then delete it *38*
3. Open and edit the exported ASIF *38*
4. Import the ASIF *38*
4.4.2 Add Custom Profiles to Existing Aircraft *38*
1. Export an existing aircraft and its profiles *38*
2. Open and edit the exported ASIF *38*
3. Import the ASIF *39*

5 ASIF DESIGN CONSIDERATION 40

5.1 Airport Layout and Runways 40
5.2 Event Consolidation 41
5.3 Control Codes 41
5.4 Assign Default Ground Suport Equipment (GSE) to Aircraft Operations 43
5.5 Import User-Defined Spectral Class Data 45
Sample ASIF for User-Defined Spectral Class Data 45

6 ASIF SCHEMA DOCUMENTATION 46

1 Introduction

The AEDT Standard Input File (ASIF) provides a standard file format to allow for the import of data into AEDT. The ASIF format allows users to create a new study by importing a complete study including airports, scenarios, cases, operations, tracks, and other study definitions. Users can also use the partial ASIF import to import data into an existing AEDT study.

This Manual provides a description of the ASIF format for the **ASIF schema version 1.2.17**. It also provides an overview of ASIF usage and annotated sample studies. The Manual is intended for analysts and programmers who wish to create ASIF.

It is recommended to use the ASIF schema documentation, **AsifMerge.html**, in conjunction with the Manual. It provides diagrams that illustrate the structure and contents of each XML element as well as rules and properties of each element, see Section 1.2.

1.1 Overview of the ASIF Format

ASIF is based on the XML file format. XML is a text-based file format that is readable by both humans and computers. Data values are tagged with elements and organized in a hierarchical manner such that the elements can contain other elements or data. XML elements can also have attributes which provide metadata that affect how the ASIF importer processes the data in the XML file. This document assumes users have basic familiarity with the XML file format. For additional information about XML, see http://xmlfiles.com/xml/.

An ASIF can be created and edited in a standard XML editor. The *XML Notepad* and *Notepad++* are XML editors that can be downloaded for free online.

1.2 ASIF Schema Documentation

1.2.1 ASIF Schema Files

The ASIF schema (.xsd) files are located under *C:\Program Files\FAA\AEDT3d\Examples* directory.

- ASIF.xsd
- ASIF_Airport.xsd
- ASIF_Common.xsd
- ASIF_Fleet.xsd
- ASIF_Receptors.xsd

1.2.2 AsifMerge.html

The ASIF schema documentation, **AsifMerge.html**, is located under the *C:\Program Files\FAA\AEDT3d\Examples\ASIF Schema Reference* directory. This is a HTML file which contains schema diagrams that illustrate the structure and contents of each XML element. The links in the HTML file facilitates understanding the schema hierarchy and the rules and properties of each element.

The following table describes the notations used in the ASIF schema diagram.

Notation for Schema Diagram

Notation	Icon	Description
Choice indicator		Only one of the elements contained in the selected group can be present
Sequence indicator		Child elements must appear in the specified sequence
Element		Represented by a rectangle with solid or dotted border Solid rectangle – required element Dotted rectangle – optional element
Element with (+) sign		Indicates that the element has child element(s) and/or attribute(s)
Element with min and max bound		Specifies the min/max number of times an element can occur in the parent element

1.3 Importing External Studies

AEDT also supports import of INM and EDMS studies by converting these legacy tools into ASIF format and importing into AEDT. See the AEDT User Manual and the AEDT Supplemental Manual: Quick Start Tutorial for more information on importing legacy studies.

2 ASIF Import Types

There are two types of ASIF import files: a full-study import and a partial-study import. The following sections describe each type of import file.

2.1 Full Study Import

AEDT supports the creation of new studies via ASIF. For a full-study import, the ***content*** attribute of the ***AsifXML*** element must be set to "study".

Please see Section 3 for two sample studies.

2.2 Partial ASIF Import

Partial ASIF is used to import specific pieces of data into an existing AEDT study. A partial ASIF is organized similarly to a full ASIF, except that it contains a single type of data – the ***content*** attribute of the ***AsifXML*** element must specify the data type. The data types that can be imported via partial ASIF are listed below:

- airportLayoutSet
- annualization
- case
- fleet
- receptorSets
- scenario
- boundary
- trackOpSet
- runup
- userGroundSupportEquipmentSet
- stationarySourceSet
- operationalProfileSet

The format for a partial ASIF is outlined below. The header is the same as a full ASIF, except that the ***content*** attribute is not "study". Instead, the ***content*** attribute should specify the data element that appears in the file.

```
<AsifXml xmlns:AsifXml="http://www.faa.gov/ASIF"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" version="1.2.17"
content="ENTER_CONTENT_TYPE_HERE">

<!-- The content block follows here: -->

      <*content type here*>

        ...

      </*end content type*>

</AsifXml>
```

Note that some of these elements rely on information provided in other data blocks. If this information is not provided by the base study when loading the partial ASIF, an error will be generated. For example, attempting to load a partial ASIF containing scenario data that references an airport that does not exist in the base study will cause an error.

2.3 Sample ASIFs

Sample ASIFs, including full study files and partial ASIFs, are located in *C:\Program Files\FAA\AEDT3d\Examples* directory.

Full study ASIF

- asif_emissions_study.xml
- asif_sensor_path_study.xml
- asif_small.xml

Partial ASIF

- PartialASIF_airportLayoutSet.xml
- PartialASIF_annualization.xml
- PartialASIF_boundary.xml
- PartialASIF_operationalProfileSet.xml
- PartialASIF_receptorSets.xml
- PartialASIF_runup.xml
- PartialASIF_scenario.xml
- PartialASIF_stationarySourceSet.xml
- PartialASIF_userGroundSupportEquipmentSet.xml
- UserDefinedANPProfiles-ProcedureSteps.xml
- UserDefinedANPProfiles-ProfilePoints.xml
- UserDefinedBADA4Profiles.xml
- UserDefinedSpectralClass.xml

3 ASIF Examples

This section provides simple steps to assist in the creation of ASIFs for possible studies. See Section 3.1 on developing an ASIF for a simple study and Section 3.2 for an emissions dispersion study.

3.1 Create a Simple Study

Follow the steps below to create an ASIF for a simple study:

1. Create an empty study file.
2. Populate the airport layout section.
3. Define receptor set.
4. Define scenario and case hierarchy.
5. Populate the case with tracks and air operations.
6. Create annualization.

The following sections provide examples of each of the above steps. This example should be used as an aid for understanding the ASIF format, and not as a data reference.

1. Create empty study file

At a minimum, an ASIF consists of the standard XML declaration, a study section, and study metadata.

Study name must be at least five characters long and must not contain periods (.) or spaces.

```
<AsifXml version="1.2.17" content="study"
xmlns:AsifXml="http://www.faa.gov/ASIF"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">

 <study xmlns:asif="http://www.faa.gov/ASIF">
  <!-- User-defined study name -->
  <name>ASIF_example</name>

  <!-- Study type - Emissions, Dispersion, Noise and Emissions, or Noise and
Dispersion -->
  <studyType>Noise and Emissions</studyType>

  <!-- Indicate the units used in the study -->
  <emissionsUnits>Kilograms</emissionsUnits>

  <!-- User-defined study description -->
  <description>A sample study</description>

  <!-- Add airport layouts here -->

  <!-- Add receptors here -->

  <!-- Add scenarios here -->

 </study>
</AsifXml>
```

2. Populate airport layouts section

AEDT requires all airports in the study area to be declared. The airport runway definitions are specified using the ***runwaySet*** element. If runways are not specified in ASIF, then the runway data from the Airport database will be used during the ASIF import.

In the example below, KMDW airport is defined using user-specified runways.

```
<airportLayoutSet>
 <airportLayout>
  <!-- User can specify an airport with user-defined runway -->
  <airportCode type="ICAO">KMDW</airportCode>

  <!-- Airports can have one or more runways defined -->
  <runwaySet>
   <runway>
    <!-- Runway length (in feet) -->
    <length>5932</length>

    <!-- Runway width (in feet) -->
    <width>150</width>

    <!-- One or more runway ends -->
    <runwayEnd>
     <!-- user-defined name for runway end -->
     <name>04R</name>

     <!-- latitude and longitude of runway end -->
     <latitude>41.779496</latitude>
     <longitude>-87.75876</longitude>

     <!-- elevation in feet -->
     <elevation>0.0</elevation>

     <!-- threshold crossing height (in feet) -->
     <threshCrossHeight>50.0</threshCrossHeight>

     <!-- glide slope for an approach to this runway end -->
     <glideSlope>3.0</glideSlope>

     <!-- displaced threshold for departure-->
     <depDispThresh>0.0</depDispThresh>

     <!-- displaced threshold for approach -->
     <appDispThresh>0.0</appDispThresh>

     <!-- Percent change in airport average headwind -->
     <percentWind>0.0</percentWind>
    </runwayEnd>
    <runwayEnd>
     <name>22L</name>
     <latitude>41.791167</latitude>
     <longitude>-87.743554</longitude>
     <elevation>0.0</elevation>
     <threshCrossHeight>50.0</threshCrossHeight>
     <glideSlope>3.0</glideSlope>
```

```
      <depDispThresh>0.0</depDispThresh>
      <appDispThresh>0.0</appDispThresh>
      <percentWind>0.0</percentWind>
     </runwayEnd>
    </runway>
   </runwaySet>
  </airportLayout>
 </airportLayoutSet>
```

3. Create receptor set

If the study includes noise or dispersion analysis, then one or more receptor sets are required. Receptor sets define locations (grid or point) where noise/dispersion measurements are taken. The example below defines a grid type receptor set.

```
<receptorSet>
 <!-- user-defined name -->
 <name>gridfile_100x100</name>
 <grid>
  <!-- Latitude and longitude of southwest corner of grid -->
  <latitude>41.97872</latitude>
  <longitude>-87.90439</longitude>

  <!-- Width and height of grid (in nautical miles) -->
  <width>100.0</width>
  <height>100.0</height>

  <!-- Number of points across height and width of grid -->
  <numWidth>100</numWidth>
  <numHeight>100</numHeight>
 </grid>
</receptorSet>
```

4. Create scenario and case hierarchy

Scenarios contain a set of cases (i.e. operation group) that are used to group aircraft tracks and operations.

The following example demonstrates a simple scenario and case structure. A case can contain one or more child cases.

```
<scenario>
 <!-- user-defined scenario name and description -->
 <name>Baseline_Scenario</name>

 <!-- user-defined start time for scenario -->
 <startTime>2009-11-10T15:02:00</startTime>

 <!-- Duration of scenario (in hours) -->
 <duration>24</duration>

 <!-- Taxi model for scenario -->
 <taxiModel>UserSpecified</taxiModel>

 <!-- Aircraft performance model -->
 <acftPerfModel>SAE1845</acftPerfModel>
```

```
   <!-- Enable/disable bank angle calculations for aircraft performance
modeling -->
   <bankAngle>true</bankAngle>

   <!-- Sulfur related settings -->
   <sulfurConversionRate>0.05</sulfurConversionRate>
   <fuelSulfurContent>6.8E-4</fuelSulfurContent>

   <!-- A description of the scenario -->
   <description>Simple scenario</description>

   <!-- List of airports to use for the scenario -->
   <scenarioAirportLayoutSet>
    <scenarioAirportLayout>
     <airportLayoutName>KMDW</airportLayoutName>
    </scenarioAirportLayout>
   </scenarioAirportLayoutSet>

   <caseSet>
    <!-- One or more case elements -->
    <case>
     <!-- sequential case number unique in this scenario -->
     <caseId>0</caseId>

     <!-- user-defined case name -->
     <name>CaseA</name>

     <!-- Noise emissions source -->
     <source>Aircraft</source>

     <!-- Case start time and duration -->
     <startTime>2009-11-10T15:02:00</startTime>
     <duration>24</duration>

     <!-- Add trackOpSet elements here -->

    </case>
   </caseSet>
  </scenario>
```

5. Populate cases with tracks and air operations

The ***trackOpSet*** element defines a single track and any number of aircraft operations to be flown on that track. A track can be composed of one or more subtracks with dispersion values. An un-dispersed track has one subtrack with dispersion weight of 1. A dispersed track consists of multiple subtracks. The sum of the dispersion weights for all subtracks within a given track must equal 1. Operations defined for the track will be dispersed based on the dispersion weight amongst any subtracks that make up the track.

```
     <trackOpSet>
      <!-- Single track element -->
      <track>
       <!-- user-defined track name -->
       <name>04R_Dep</name>
```

```
        <!-- Track operation type: A = Arrival, D = Departure, O = Overflight
-->
        <optype>D</optype>

        <!-- Airport and runway for this track -->
        <airport type="ICAO">KMDW</airport>
        <runway>04R</runway>

        <!-- tracks can be composed of multiple dispersed subtracks -->
        <subtrack>

         <!-- the user-defined ID for the subtrack -->
         <id>0</id>

         <!-- The sum of the dispersionWeights for all subtracks within a
given track must equal 1 -->
         <dispersionWeight>1.0</dispersionWeight>

         <!-- Set of trackNode or trackVector elements, all must be the same
for each subtrack -->
         <trackNodes>
          <trackNode>
           <latitude>40.65640</latitude>
           <longitude>-73.71322</longitude>
          </trackNode>
          <trackNode>
           <latitude>40.65640</latitude>
           <longitude>-53.71322</longitude>
          </trackNode>
         </trackNodes>

        </subtrack>
       </track>

       <operations>
        <!--operation element represents one or more flights on a track-->
        <operation>
         <!-- user-defined operation id -->
         <id>T9.1</id>

         <!-- AEDT aircraftType for this operation -->
         <aircraftType>
          <airframeModel>Raytheon Beech 1900-C</airframeModel>
          <engineCode>PT67B</engineCode>
          <engineModCode>NONE </engineModCode>
         </aircraftType>

         <!-- number of times to fly this operation -->
         <numOperations>1.0</numOperations>

         <!-- user-defined flight number, optional -->
         <flightNumber>CKE545</flightNumber>

         <!-- user-defined operation type, optional  -->
         <userType>MU3001</userType>
```

```
      <!-- user-defined parameter data, optional -->
      <userParam>J</userParam>

      <!-- arrival or departure airport and runway -->
      <departureAirport type="ICAO">KMDW</departureAirport>
      <departureRunway>04R</departureRunway>
      <arrivalAirport type="FAA">LIT</arrivalAirport>

      <!-- offTime for departures or onTime for arrivals -->
      <offTime>2009-11-10T15:02:00</offTime>

      <!-- aircraft profile  for this operation -->
      <saeProfile>STANDARD</saeProfile>
     </operation>
    </operations>
   </trackOpSet>
```

6. Create annualization

Annualization is the process of performing a weighted summation[1] over the noise and emission results from some or all of the cases within a scenario in order to create results that represent noise and emissions exposures over a time period of interest. Each scenario element may contain an annualization element describing the weighted annualization tree.

```
<annualization>
 <!-- user-defined annulalization name -->
 <name>Baseline_Annualization</name>

 <!-- Define one or more groups of cases and groups -->
 <annualizationGroup>

   <!-- Define rolloup weight for this group -->
   <weight>1.0</weight>
   <!-- Associate scenario case with this annualization group -->
   <annualizationCase>
      <!-- Specify case name -->
      <name>CaseA</name>
      <!-- Define rollup weight for this case -->
      <weight>1.0</weight>
   </annualizationCase>

 </annualizationGroup>
</annualization>
```

7. Full ASIF

The full study ASIF is as follows:

[1] The word 'summation' is used figuratively and the actual process of correctly summing or adding together noise or emissions results depends upon the metric being used. For example: energy metric results would not be directly added together for a result since they are logarithmic values, but would rather be log-added.

```
<AsifXml version="1.2.17" content="study"
xmlns:AsifXml="http://www.faa.gov/ASIF"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">

 <study xmlns:asif="http://www.faa.gov/ASIF">

  <!-- User-defined study name -->
  <name>ASIF_example</name>

  <!-- Study type - Emissions, Dispersion, Noise and Emissions, or Noise and
Dispersion -->
  <studyType>Noise and Emissions</studyType>

  <!-- Indicate the units used in the study -->
  <emissionsUnits>Kilograms</emissionsUnits>

  <!-- User-defined study description -->
  <description>A sample study</description>

  <airportLayoutSet>
   <airportLayout>
    <!-- User can specify an airport with user-defined runway -->
    <airportCode type="ICAO">KMDW</airportCode>

    <!-- Airports can have one or more runways defined -->
    <runwaySet>
     <runway>
      <!-- Runway length (in feet) -->
      <length>5932</length>

      <!-- Runway width (in feet) -->
      <width>150</width>

      <!-- One or more runway ends -->
      <runwayEnd>
       <!-- user-defined name for runway end -->
       <name>04R</name>

       <!-- latitude and longitude of runway end -->
       <latitude>41.779496</latitude>
       <longitude>-87.75876</longitude>

       <!-- elevation in feet -->
       <elevation>0.0</elevation>

       <!-- threshold crossing height (in feet) -->
       <threshCrossHeight>50.0</threshCrossHeight>

       <!-- glide slope for an approach to this runway end -->
       <glideSlope>3.0</glideSlope>

       <!-- displaced threshold for departure-->
       <depDispThresh>0.0</depDispThresh>

       <!-- displaced threshold for approach -->
       <appDispThresh>0.0</appDispThresh>
```

```
      <!-- Percent change in airport average headwind -->
      <percentWind>0.0</percentWind>
     </runwayEnd>
     <runwayEnd>
      <name>22L</name>
      <latitude>41.791167</latitude>
      <longitude>-87.743554</longitude>
      <elevation>0.0</elevation>
      <threshCrossHeight>50.0</threshCrossHeight>
      <glideSlope>3.0</glideSlope>
      <depDispThresh>0.0</depDispThresh>
      <appDispThresh>0.0</appDispThresh>
      <percentWind>0.0</percentWind>
     </runwayEnd>
    </runway>
   </runwaySet>
  </airportLayout>
 </airportLayoutSet>

 <receptorSet>
  <!-- user-defined name -->
  <name>gridfile_100x100</name>
  <grid>
   <!-- Latitude and longitude of southwest corner of grid -->
   <latitude>41.97872</latitude>
   <longitude>-87.90439</longitude>

   <!-- Width and height of grid (in nautical miles) -->
   <width>100.0</width>
   <height>100.0</height>

   <!-- Number of points across height and width of grid -->
   <numWidth>100</numWidth>
   <numHeight>100</numHeight>
  </grid>
 </receptorSet>

 <scenario>
  <!-- user-defined scenario name and description -->
  <name>Baseline_Scenario</name>

  <!-- user-defined start time for scenario -->
  <startTime>2009-11-10T15:02:00</startTime>

  <!-- Duration of scenario (in hours) -->
  <duration>24</duration>

  <!-- Taxi model for scenario -->
  <taxiModel>UserSpecified</taxiModel>

  <!-- Aircraft performance model -->
  <acftPerfModel>SAE1845</acftPerfModel>

  <!-- Enable/disable bank angle calculations for aircraft performance
modeling -->
```

```
   <bankAngle>true</bankAngle>

   <!-- Sulfur related settings -->
   <sulfurConversionRate>0.05</sulfurConversionRate>
   <fuelSulfurContent>6.8E-4</fuelSulfurContent>

   <!-- A description of the scenario -->
   <description>A sample scenario</description>

   <!-- List of airports to use for the scenario -->
   <scenarioAirportLayoutSet>
    <scenarioAirportLayout>
     <airportLayoutName>KMDW</airportLayoutName>
    </scenarioAirportLayout>
   </scenarioAirportLayoutSet>

   <caseSet>
    <!-- One or more case elements -->
    <case>
     <!-- sequential case number unique in this scenario -->
     <caseId>0</caseId>

     <!-- user-defined case name -->
     <name>CaseA</name>

     <!-- Noise emissions source -->
     <source>Aircraft</source>

     <!-- Case start time and duration -->
     <startTime>2009-11-10T15:02:00</startTime>
     <duration>24</duration>

     <trackOpSet>
      <!-- Single track element -->
      <track>
       <!-- user-defined track name -->
       <name>04R_Dep</name>
       <!-- Track operation type: A = Arrival, D = Departure, O = Overflight
-->
       <optype>D</optype>

       <!-- Airport and runway for this track -->
       <airport type="ICAO">KMDW</airport>
       <runway>04R</runway>

       <!-- tracks can be composed of multiple dispersed subtracks -->
       <subtrack>

        <!-- the user-defined ID for the subtrack -->
        <id>0</id>

        <!-- The sum of the dispersionWeights for all subtracks within a
given track must equal 1 -->
        <dispersionWeight>1.0</dispersionWeight>
```

```
        <!-- Set of trackNode or trackVector elements, all must be the same
for each subtrack -->
        <trackNodes>
         <trackNode>
          <latitude>40.65640</latitude>
          <longitude>-73.71322</longitude>
         </trackNode>
         <trackNode>
          <latitude>40.65640</latitude>
          <longitude>-53.71322</longitude>
         </trackNode>
        </trackNodes>

       </subtrack>
      </track>

      <operations>
       <!--operation element represents one or more flights on a track-->
       <operation>
        <!-- user-defined operation id -->
        <id>T9.1</id>

        <!-- AEDT aircraftType for this operation -->
        <aircraftType>
         <airframeModel>Raytheon Beech 1900-C</airframeModel>
         <engineCode>PT67B</engineCode>
         <engineModCode>NONE </engineModCode>
        </aircraftType>

        <!-- number of times to fly this operation -->
        <numOperations>1.0</numOperations>

        <!-- user-defined flight number, optional -->
        <flightNumber>CKE545</flightNumber>

        <!-- user-defined operation type, optional -->
        <userType>MU3001</userType>

        <!-- user-defined parameter data, optional -->
        <userParam>J</userParam>

        <!-- arrival or departure airport and runway -->
        <departureAirport type="ICAO">KMDW</departureAirport>
        <departureRunway>04R</departureRunway>
        <arrivalAirport type="FAA">LIT</arrivalAirport>

        <!-- offTime for departures or onTime for arrivals -->
        <offTime>2009-11-10T15:02:00</offTime>

        <!-- aircraft profile  for this operation -->
        <saeProfile>STANDARD</saeProfile>
       </operation>
      </operations>
     </trackOpSet>

    </case>
```

```
   </caseSet>

   <annualization>
    <!-- user-defined annulalization name -->
    <name>Baseline_Annualization</name>

    <!-- Define one or more groups of cases and groups -->
    <annualizationGroup>

      <!-- Define rolloup weight for this group -->
      <weight>1.0</weight>
      <!-- Associate scenario case with this annualization group -->
      <annualizationCase>
         <!-- Specify case name -->
         <name>CaseA</name>
         <!-- Define rollup weight for this case -->
         <weight>1.0</weight>
      </annualizationCase>

    </annualizationGroup>
   </annualization>

  </scenario>
 </study>
</AsifXml>
```

3.2 Create an Emissions Dispersion Study

An emissions dispersion study contains the same core elements as a simple study (Section 3.1). In addition, a typical dispersion study includes additional airport features (gates, taxiways, taxipaths), operational profiles, airport configuration, and stationary sources.

1. Create an empty study file.
2. Populate the airport layout section.
    a. Basic airport information (airport code and location)
    b. Stationary sources
    c. Airport gates/terminals
    d. Taxiways
    e. Runways
    f. Taxipaths
    g. Tracks
    h. Airport configurations
3. Create receptor set.
4. Create scenario and case hierarchy.
    a. Airport scenario properties
    b. Non-aircraft operations case
    c. Aircraft operations case

The following sections provide examples of the steps. This ASIF example should be used as an aid for understanding the ASIF format, and not as a data reference. This example is based on the STUDY_PVD study included with AEDT installation; but it has been much simplified for illustrative purposes. Please

note that both the aircraft operations and the non-aircraft operations in this study are defined using operational profiles. When running profile-based aircraft operations, the "Apply Delay & Sequencing Model on Taxi" modeling option must be selected, and operating configuration and taxi network must exist in the airport layout.

1. Create empty study file

At a minimum, an ASIF consists of the standard XML declaration, a study section, and study metadata.

Study name must be at least five characters long and must not contain periods (.) or spaces.

```
<?xml version="1.0" encoding="utf-8"?>
<AsifXml xmlns:xsd="http://www.w3.org/2001/XMLSchema"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" version="1.2.17" content="study">
  <study>
    <name>PVD2004_small</name>
    <studyType>Dispersion</studyType>
    <emissionsUnits>Kilograms</emissionsUnits>
    <description>A sample emissions study</description>

  <!-- Add airport layouts here -->
  <!-- Add receptors here -->
  <!-- Add scenarios here -->

  </study>
</AsifXml>
```

2. Populate airport layouts section

AEDT requires all airports in the study area to be declared. In addition to runways and tracks, the airport layout section can contain buildings, stationary sources of emissions (such as generators, training fires, or boilers), gates, terminals, taxiways, taxipaths, airport configurations, and operational profiles.

a) Define airport layout

Define the basic airport layout properties including layout name, airport code, and location.

```
    <airportLayoutSet>
      <airportLayout>
        <name>Baseline_PVD2004_layout</name>
        <airportCode type="ICAO">KPVD</airportCode>
        <startDate>2004-01-01</startDate>
        <elevation>55</elevation>     <!-- in feet -->
        <taxiInTime>7</taxiInTime>    <!-- in minutes -->
        <taxiOutTime>19</taxiOutTime> <!-- in minutes -->
        <latitude>41.723999</latitude>
        <longitude>-71.428221</longitude>
```

b) Define stationary sources

Define each stationary source with an individual location definition, as well as other properties that describe the nature or amount of emissions. Each stationary source may have different elements associated with it. The example below defines an emergency generator.

```
        <stationarySourceSet>
          <stationarySource>
```

```
      <name>600kw Emergency Gen-Baseline-KPVD-2004</name>
      <pointStationarySource>
        <pointCoord>
          <latitude>41.743248909695488</latitude>
          <longitude>-71.412168090784959</longitude>
        </pointCoord>
        <baseElevation>16.764</baseElevation>   <!-- in meters -->
        <releaseHeight>12.192</releaseHeight>   <!-- in meters -->
        <gasVelocity>15</gasVelocity>           <!-- in meters/sec -->
        <stackDiameter>0.100584</stackDiameter> <!-- in meters -->
        <temperature>400</temperature>          <!-- in Fahrenheit -->
      </pointStationarySource>
      <categoryGenerator>
        <typeCode>2</typeCode>
        <powerRatingHorsepower>1340</powerRatingHorsepower>
        <CO_EF>3.03</CO_EF>
        <TOC_EF>1.14</TOC_EF>
        <NOx_EF>14</NOx_EF>
        <SOx_EF>0.93</SOx_EF>
        <PM10_EF>0.998</PM10_EF>
        <pollutionControlFactorTOC>0</pollutionControlFactorTOC>
        <pollutionControlFactorCO>0</pollutionControlFactorCO>
        <pollutionControlFactorNOx>0</pollutionControlFactorNOx>
        <pollutionControlFactorSOx>0</pollutionControlFactorSOx>
        <pollutionControlFactorPM10>0</pollutionControlFactorPM10>
        <pm25ToPm10Ratio>1</pm25ToPm10Ratio>
      </categoryGenerator>
    </stationarySource>
  </stationarySourceSet>
```

c) Define airport gates/terminals

Airport gates can be defined as a point or a polygon. In AEDT, a polygon gate is referred as a terminal. For dispersion modeling, gates are modeled in AERMOD as either volume or area sources. A single-point gate (a pair of X/Y coordinates) is modeled as a volume source; while a polygon gate is modeled as an area source.

This example declares a terminal (polygon with eight points) which is defined by a set of latitude and longitude coordinates.

```
  <gateSet>
    <gate>
      <name>AC</name>
      <elevation>16.76</elevation>            <!-- in meters -->
      <releaseHeight>1.499616</releaseHeight> <!-- in meters -->
      <sigmaY>0.1</sigmaY>
      <sigmaZ>0.1</sigmaZ>
      <polygonCoords>
        <vertex>
          <latitude>41.745139410943032</latitude>
          <longitude>-71.410155909148983</longitude>
        </vertex>
        <vertex>
          <latitude>41.74454094786433</latitude>
          <longitude>-71.4088479272253</longitude>
        </vertex>
```

```
        <vertex>
          <latitude>41.739914698711225</latitude>
          <longitude>-71.412700204036113</longitude>
        </vertex>
        <vertex>
          <latitude>41.740535077085347</latitude>
          <longitude>-71.414048427664284</longitude>
        </vertex>
        <vertex>
          <latitude>41.742143089180551</latitude>
          <longitude>-71.4130440975597</longitude>
        </vertex>
        <vertex>
          <latitude>41.741863092089559</latitude>
          <longitude>-71.412435917483549</longitude>
        </vertex>
        <vertex>
          <latitude>41.743155491944563</latitude>
          <longitude>-71.411380309779929</longitude>
        </vertex>
        <vertex>
          <latitude>41.74350128931475</latitude>
          <longitude>-71.411515795803126</longitude>
        </vertex>
      </polygonCoords>
    </gate>
  </gateSet>
```

d) Define taxiways

Taxiways are line segments that link gates, runways, and other taxiways. They are composed of sequences of latitude and longitude coordinates, and specify the speed of aircraft that use them at each node.

Only the first two taxiways out of 24 are shown here for brevity. The entire taxiways are included in the example file.

```
  <taxiwaySet>
    <taxiway>
      <name>A2 to 3</name>
      <dispersionWidth>22.86</dispersionWidth> <!-- in meters -->
      <taxiNodeSet>
        <taxiNode>
          <latitude>41.747442309926434</latitude>
          <longitude>-71.399033659570691</longitude>
          <elevation>16.76</elevation> <!-- in meters -->
          <speed>17</speed>            <!-- in mph -->
        </taxiNode>
        <taxiNode>
          <latitude>41.746840990624833</latitude>
          <longitude>-71.397780701750833</longitude>
          <elevation>16.76</elevation>
          <speed>17</speed>
        </taxiNode>
      </taxiNodeSet>
    </taxiway>
```

```
    <taxiway>
      <name>AC inout 1 to 2</name>
      <dispersionWidth>22.86</dispersionWidth>
      <taxiNodeSet>
        <taxiNode>
          <latitude>41.742510604805076</latitude>
          <longitude>-71.411486739128023</longitude>
          <elevation>16.76</elevation>
          <speed>17</speed>
        </taxiNode>
        <taxiNode>
          <latitude>41.742008226242724</latitude>
          <longitude>-71.410307016216962</longitude>
          <elevation>16.76</elevation>
          <speed>17</speed>
        </taxiNode>
      </taxiNodeSet>
    </taxiway>

     ............

  </taxiwaySet>
```

e) Define runways

A runway in AEDT is defined by two runway ends. Runways are used by departing and arriving aircraft, and are linked to gates by taxipaths. The example below defines two runways: 05-23 and 16-34.

```
  <runwaySet>
    <runway>
      <length>7069</length> <!-- in feet -->
      <width>150</width>    <!-- in feet -->
      <runwayEnd>
        <name>05</name>
        <latitude>41.73040290796537</latitude>
        <longitude>-71.411541169743472</longitude>
        <elevation>54.986876640419943</elevation> <!-- in feet -->
        <glideSlope>3</glideSlope>
      </runwayEnd>
      <runwayEnd>
        <name>23</name>
        <latitude>41.746840990624833</latitude>
        <longitude>-71.397780701750833</longitude>
        <elevation>54.986876640419943</elevation>
        <glideSlope>3</glideSlope>
      </runwayEnd>
    </runway>

    <runway>
      <length>5961</length>
      <width>150</width>
      <runwayEnd>
        <name>16</name>
        <latitude>41.748017908874452</latitude>
        <longitude>-71.4087003031238</longitude>
```

```
        <elevation>54.986876640419943</elevation>
        <glideSlope>3</glideSlope>
      </runwayEnd>
      <runwayEnd>
        <name>34</name>
        <latitude>41.735182619491127</latitude>
        <longitude>-71.395155630736014</longitude>
        <elevation>54.986876640419943</elevation>
        <glideSlope>3</glideSlope>
      </runwayEnd>
    </runway>
  </runwaySet>
```

f) Assemble taxipaths

Taxipaths are a series of taxiways that aircraft takes from a gate to a runway end (outbound) or from a runway end to a gate (inbound). Taxipaths can be composed of multiple taxiway line segments; and separate taxipaths may share taxiways in common as paths across the airport.

Only the first two taxipaths out of eight are shown here for brevity. The entire taxipaths are included in the example file.

```
  <taxipathSet>
    <taxipath>
      <gateName>AC</gateName>
      <runwayName>05</runwayName>
      <direction>Outbound</direction>
      <taxiwayName>AC inout 1 to 2</taxiwayName>
      <taxiwayName>T3 to 4</taxiwayName>
      <taxiwayName>T4 to 5</taxiwayName>
      <taxiwayName>T5 to 6</taxiwayName>
      <taxiwayName>E1 to 2</taxiwayName>
      <taxiwayName>S2 to 3</taxiwayName>
      <taxiwayName>S3 to 4</taxiwayName>
    </taxipath>

    <taxipath>
      <gateName>AC</gateName>
      <runwayName>05</runwayName>
      <direction>Inbound</direction>
      <taxiwayName>N5 to 6</taxiwayName>
      <taxiwayName>N4 to 5</taxiwayName>
      <taxiwayName>N3 to 4</taxiwayName>
      <taxiwayName>N2 to 3</taxiwayName>
      <taxiwayName>T1 to 2</taxiwayName>
      <taxiwayName>T2 to 3</taxiwayName>
      <taxiwayName>AC inout 1 to 2</taxiwayName>
    </taxipath>

     ............

  </taxipathSet>
```

g) Define tracks

Tracks are paths flown by aircraft, and are defined for an aircraft type (fixed-wing or rotary-wing) and an operation type (arrival, departure, or touch & go). This sample ASIF contains a total of 12 tracks consisting of arrival, departure, and touch & go tracks for each of the four runway ends. Only the first three tracks are shown here for brevity.

```
<trackSet>
  <track>
    <name>05_D_FixedWing</name>
    <optype>D</optype>
    <wingtype>F</wingtype>
    <airport type="ICAO">KPVD</airport>
    <runway>05</runway>
    <subtrack>
      <id>0</id>
      <dispersionWeight>1</dispersionWeight>
      <trackNodes>
        <trackNode>
          <latitude>41.73040290796537</latitude>
          <longitude>-71.411541169743472</longitude>
        </trackNode>
        <trackNode>
          <latitude>41.746840990624833</latitude>
          <longitude>-71.397780701750833</longitude>
        </trackNode>
        <trackNode>
          <latitude>43.137117876102565</latitude>
          <longitude>-70.202867639935235</longitude>
        </trackNode>
      </trackNodes>
    </subtrack>
  </track>

  <track>
    <name>23_D_FixedWing</name>
    <optype>D</optype>
    <wingtype>F</wingtype>
    <airport type="ICAO">KPVD</airport>
    <runway>23</runway>
    <subtrack>
      <id>0</id>
      <dispersionWeight>1</dispersionWeight>
      <trackNodes>
        <trackNode>
          <latitude>41.746840990624833</latitude>
          <longitude>-71.397780701750833</longitude>
        </trackNode>
        <trackNode>
          <latitude>41.73040290796537</latitude>
          <longitude>-71.411541169743472</longitude>
        </trackNode>
        <trackNode>
          <latitude>40.32809642691705</latitude>
          <longitude>-72.555207007763542</longitude>
        </trackNode>
      </trackNodes>
```

```
      </subtrack>
    </track>

    <track>
      <name>05_A_FixedWing</name>
      <optype>A</optype>
      <wingtype>F</wingtype>
      <airport type="ICAO">KPVD</airport>
      <runway>05</runway>
      <subtrack>
        <id>0</id>
        <dispersionWeight>1</dispersionWeight>
        <trackNodes>
          <trackNode>
            <latitude>40.32809642691705</latitude>
            <longitude>-72.555207007763542</longitude>
          </trackNode>
          <trackNode>
            <latitude>41.73040290796537</latitude>
            <longitude>-71.411541169743472</longitude>
          </trackNode>
        </trackNodes>
      </subtrack>
    </track>
```

h) Define airport operating configurations

Airport operating configurations specify the weather conditions and times under which particular runway assignments are made for aircraft based on the aircraft weight category (Small, Large, or Heavy). Operating configurations are only used if the Delay and Sequencing Modeling is selected.

A single configuration is defined in this example, but multiple configurations could be defined in an airport layout. Please note that the following <airportConfig> section does not contain any activation parameters (such as wind direction, wind speed, hour of day, ceiling, visibility, and temperature). This means that all the activation parameters are set to no bound.

```
  <airportConfigSet>
    <airportConfig>
      <configurationName>Configuration</configurationName>
      <useDistribution>false</useDistribution>
      <airportCapacity>
        <capacityPoint>
          <arrivalsPerHour>27</arrivalsPerHour>
          <departuresPerHour>52</departuresPerHour>
        </capacityPoint>
        <capacityPoint>
          <arrivalsPerHour>52</arrivalsPerHour>
          <departuresPerHour>27</departuresPerHour>
        </capacityPoint>
      </airportCapacity>

      <runwayAssignmentSet>
        <runwayAssignment>
          <aircraftSize>S</aircraftSize>
          <runway>16</runway>
          <arrivalPercentage>0.8</arrivalPercentage>
```

```
    <departurePercentage>1.32</departurePercentage>
    <tgoPercentage>0</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>S</aircraftSize>
    <runway>23</runway>
    <arrivalPercentage>50.74</arrivalPercentage>
    <departurePercentage>52.33</departurePercentage>
    <tgoPercentage>50</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>S</aircraftSize>
    <runway>34</runway>
    <arrivalPercentage>13.04</arrivalPercentage>
    <departurePercentage>8.06</departurePercentage>
    <tgoPercentage>15</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>S</aircraftSize>
    <runway>05</runway>
    <arrivalPercentage>35.42</arrivalPercentage>
    <departurePercentage>38.29</departurePercentage>
    <tgoPercentage>35</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>L</aircraftSize>
    <runway>16</runway>
    <arrivalPercentage>0.8</arrivalPercentage>
    <departurePercentage>1.32</departurePercentage>
    <tgoPercentage>0</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>L</aircraftSize>
    <runway>23</runway>
    <arrivalPercentage>50.74</arrivalPercentage>
    <departurePercentage>52.33</departurePercentage>
    <tgoPercentage>50</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>L</aircraftSize>
    <runway>34</runway>
    <arrivalPercentage>13.04</arrivalPercentage>
    <departurePercentage>8.06</departurePercentage>
    <tgoPercentage>15</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>L</aircraftSize>
    <runway>05</runway>
    <arrivalPercentage>35.42</arrivalPercentage>
    <departurePercentage>38.29</departurePercentage>
    <tgoPercentage>35</tgoPercentage>
  </runwayAssignment>
  <runwayAssignment>
    <aircraftSize>H</aircraftSize>
    <runway>16</runway>
    <arrivalPercentage>0.8</arrivalPercentage>
    <departurePercentage>1.32</departurePercentage>
```

```
            <tgoPercentage>0</tgoPercentage>
          </runwayAssignment>
          <runwayAssignment>
            <aircraftSize>H</aircraftSize>
            <runway>23</runway>
            <arrivalPercentage>50.74</arrivalPercentage>
            <departurePercentage>52.33</departurePercentage>
            <tgoPercentage>50</tgoPercentage>
          </runwayAssignment>
          <runwayAssignment>
            <aircraftSize>H</aircraftSize>
            <runway>34</runway>
            <arrivalPercentage>13.04</arrivalPercentage>
            <departurePercentage>8.06</departurePercentage>
            <tgoPercentage>15</tgoPercentage>
          </runwayAssignment>
          <runwayAssignment>
            <aircraftSize>H</aircraftSize>
            <runway>05</runway>
            <arrivalPercentage>35.42</arrivalPercentage>
            <departurePercentage>38.29</departurePercentage>
            <tgoPercentage>35</tgoPercentage>
          </runwayAssignment>
        </runwayAssignmentSet>
      </airportConfig>
    </airportConfigSet>
```

i) Define operational profiles

Operational profiles allows the user to define variations in activity throughout a day, week, or year. The three types of operational profiles are Quarter-Hourly, Daily, and Monthly. When using operational profiles in a study, at least one profile for each profile type (Quarter Hourly, Daily, and Monthly) must defined.

These profiles provide a weighting factor that determines how often activity occurs during the time period. Aircraft and non-aircraft sources can all be assigned operational profiles. For this example, the same profiles are used for all both aircraft and non-aircraft sources; but in practice different profiles will be defined for aircraft, GSEs, or stationary sources.

Only the first part of the quarterly-hour profile is shown here for brevity. The entire profile is given in the example file.

```
    <quarterHourlyProfileSet>
      <quarterHourlyProfile>
        <profileName>Aircraft-Baseline-KPVD</profileName>
        <temporalFactor startHour="0" startMinutes="0">0.1092</temporalFactor>
        <temporalFactor startHour="0" startMinutes="15">0.0712</temporalFactor>
        <temporalFactor startHour="0" startMinutes="30">0.0452</temporalFactor>
        <temporalFactor startHour="0" startMinutes="45">0.0274</temporalFactor>
        <temporalFactor startHour="1" startMinutes="0">0.0226</temporalFactor>
        <temporalFactor startHour="1" startMinutes="15">0.0144</temporalFactor>
        <temporalFactor startHour="1" startMinutes="30">0.0135</temporalFactor>
        <temporalFactor startHour="1" startMinutes="45">0.0087</temporalFactor>

         ............
```

```
    </quarterHourlyProfile>
  </quarterHourlyProfileSet>

  <dailyProfileSet>
    <dailyProfile>
      <profileName>Aircraft-Baseline-KPVD</profileName>
      <temporalFactorSunday>0.8889</temporalFactorSunday>
      <temporalFactorMonday>0.9354</temporalFactorMonday>
      <temporalFactorTuesday>0.9565</temporalFactorTuesday>
      <temporalFactorWednesday>0.9494</temporalFactorWednesday>
      <temporalFactorThursday>1</temporalFactorThursday>
      <temporalFactorFriday>0.9494</temporalFactorFriday>
      <temporalFactorSaturday>0.8103</temporalFactorSaturday>
    </dailyProfile>
  </dailyProfileSet>

  <monthlyProfileSet>
    <monthlyProfile>
      <profileName>Aircraft-Baseline-KPVD</profileName>
      <temporalFactorJanuary>0.6097</temporalFactorJanuary>
      <temporalFactorFebruary>0.768</temporalFactorFebruary>
      <temporalFactorMarch>0.7468</temporalFactorMarch>
      <temporalFactorApril>0.6508</temporalFactorApril>
      <temporalFactorMay>0.7803</temporalFactorMay>
      <temporalFactorJune>0.9452</temporalFactorJune>
      <temporalFactorJuly>0.9967</temporalFactorJuly>
      <temporalFactorAugust>1</temporalFactorAugust>
      <temporalFactorSeptember>0.963</temporalFactorSeptember>
      <temporalFactorOctober>0.9657</temporalFactorOctober>
      <temporalFactorNovember>0.8889</temporalFactorNovember>
      <temporalFactorDecember>0.8374</temporalFactorDecember>
    </monthlyProfile>
  </monthlyProfileSet>

  <activityProfileSet>
    <activityProfile name="ActivityProfile-Baseline-KPVD-0-0-0">
      <quarterHourlyProfile>Aircraft-Baseline-KPVD</quarterHourlyProfile>
      <dailyProfile>Aircraft-Baseline-KPVD</dailyProfile>
      <monthlyProfile>Aircraft-Baseline-KPVD</monthlyProfile>
    </activityProfile>
  </activityProfileSet>
```

3. Define receptor set

The receptor set defines a set of points or a grid in which noise or emission concentrations will be modeled. A receptor set is required for dispersion modeling.

```
<receptorSet>
  <name>CartesianReceptors-Baseline-KPVD</name>
  <pointReceptor>
    <name>01</name>
    <latitude>41.755692229957511</latitude>
    <longitude>-71.401734634031868</longitude>
    <elevation>54.986876640419943</elevation>              <!-- in feet -->
    <receptorHeight>5.9099999999999993</receptorHeight>    <!-- in feet -->
  </pointReceptor>

  <pointReceptor>
    <name>05</name>
    <latitude>41.757757081502177</latitude>
    <longitude>-71.387029661597552</longitude>
    <elevation>54.986876640419943</elevation>
    <receptorHeight>5.9099999999999993</receptorHeight>
  </pointReceptor>

  <pointReceptor>
    <name>11</name>
    <latitude>41.729547105591479</latitude>
    <longitude>-71.399671869272</longitude>
    <elevation>54.986876640419943</elevation>
    <receptorHeight>5.9099999999999993</receptorHeight>
  </pointReceptor>

  <pointReceptor>
    <name>17</name>
    <latitude>41.727308139168834</latitude>
    <longitude>-71.418091960358765</longitude>
    <elevation>54.986876640419943</elevation>
    <receptorHeight>5.9099999999999993</receptorHeight>
  </pointReceptor>
</receptorSet>
```

4. Define scenario and case hierarchy

A scenario contains a set of cases, which contain groups of aircraft operations, non-aircraft operations, and runup operations.

a) Define scenario properties

Define the basic scenario properties including airport information, weather data, and study time.

```
<scenario>
  <name>2004-Baseline</name>
  <startTime>2004-01-01T00:00:00</startTime>
  <duration>8784</duration> <!-- in hours -->
  <taxiModel>Sequencing</taxiModel>
  <timeInModeBasis>Performance</timeInModeBasis>
  <acftPerfModel>SAE1845</acftPerfModel>
  <bankAngle>false</bankAngle>
  <sulfurConversionRate>0.005</sulfurConversionRate>
```

```
<description> for year 2004</description>
<scenarioAirportLayoutSet>
  <scenarioAirportLayout>
    <airportLayoutName>Baseline_PVD2004_layout</airportLayoutName>
    <mixingHeight>2226</mixingHeight> <!-- in feet -->
    <useHourlyMetData>true</useHourlyMetData>
    <averageTemperature>50.4</averageTemperature>       <!-- in Fahrenheit -->
    <dailyHighTemperature>69.35</dailyHighTemperature>  <!-- in Fahrenheit -->
    <dailyLowTemperature>48.65</dailyLowTemperature>    <!-- in Fahrenheit -->
    <pressure>29.92</pressure>       <!-- in inches of Hg -->
    <pressureMSL>29.92</pressureMSL> <!-- in inches of Hg -->
    <humidty>60</humidty>            <!-- in percentage -->
    <windSpeed>8</windSpeed>         <!-- in knots -->
    <windDirection>0</windDirection> <!-- in degrees -->
    <ceiling>99999.99</ceiling> <!-- in feet -->
    <visibility>50</visibility> <!-- in miles -->
  </scenarioAirportLayout>
</scenarioAirportLayoutSet>
```

b) Define the case for non-aircraft operations

This study contains two cases. The first case contains non-aircraft operations (i.e., stationary source operations). The second case contains aircraft operations and GSEs assigned to those aircraft.

The example below declares the first case (non-aircraft operations). The second case (aircraft operations) is described in the next Step 4c.

```
<caseSet>
  <case>
    <caseId>-1623425151</caseId>
    <name>2004_Baseline_NonAircraft</name>
    <startTime>2004-01-01T00:00:00</startTime>
    <duration>8784</duration>
    <stationarySourceOperationSet>
      <stationarySourceOperation>
        <refName>600kw Emergency Gen-Baseline-KPVD-2004</refName>
        <emissionsUsage>
          <yearlyValue>500</yearlyValue>
          <activityProfile>ActivityProfile-Baseline-KPVD-0-0-0</activityProfile>
        </emissionsUsage>
      </stationarySourceOperation>
    </stationarySourceOperationSet>
  </case>
```

c) Define the case for aircraft operations

This section defines aircraft operations, as well as GSEs assigned to those aircraft. In this example, a single aircraft type is used with a simplified set of assigned GSEs. In practice, a variety of aircraft types and GSEs would appear in a single study.

```
  <case>
    <caseId>466140608</caseId>
    <name>2004_Baseline_Operations</name>
    <startTime>2004-01-01T00:00:00</startTime>
    <duration>8784</duration>
    <operation>
      <id>D_1</id>
```

```
<aircraftType>
  <airframeModel>Airbus A319-100 Series</airframeModel>
  <engineCode>3CM028</engineCode>
  <apuName>APU GTCP 36-300 (80HP)</apuName>
  <groundSupportEquipmentLTOOperationSet>
    <groundSupportEquipmentLTOOperation>
      <gseID>8</gseID>
      <fuelType>Diesel</fuelType>
      <horsepower>88</horsepower>
      <loadFactor>0.8</loadFactor>
      <departureOpTime>3.9</departureOpTime> <!-- in minutes -->
    </groundSupportEquipmentLTOOperation>
    <groundSupportEquipmentLTOOperation>
      <gseID>13</gseID>
      <fuelType>Gasoline</fuelType>
      <horsepower>107</horsepower>
      <loadFactor>0.55</loadFactor>
      <departureOpTime>8</departureOpTime>
      <arrivalOpTime>8</arrivalOpTime>
    </groundSupportEquipmentLTOOperation>
    <groundSupportEquipmentLTOOperation>
      <gseID>14</gseID>
      <fuelType>Gasoline</fuelType>
      <horsepower>107</horsepower>
      <loadFactor>0.5</loadFactor>
      <departureOpTime>11</departureOpTime>
      <arrivalOpTime>12</arrivalOpTime>
    </groundSupportEquipmentLTOOperation>
    <groundSupportEquipmentLTOOperation>
      <gseID>17</gseID>
      <fuelType>Diesel</fuelType>
      <horsepower>210</horsepower>
      <loadFactor>0.53</loadFactor>
      <departureOpTime>9.7</departureOpTime>
    </groundSupportEquipmentLTOOperation>
    <groundSupportEquipmentLTOOperation>
      <gseID>29</gseID>
      <fuelType>Diesel</fuelType>
      <horsepower>175</horsepower>
      <loadFactor>0.25</loadFactor>
      <departureOpTime>14</departureOpTime>
    </groundSupportEquipmentLTOOperation>
    <groundSupportEquipmentLTOOperation>
      <gseID>36</gseID>
      <fuelType>Diesel</fuelType>
      <horsepower>56</horsepower>
      <loadFactor>0.25</loadFactor>
      <arrivalOpTime>2.1</arrivalOpTime>
    </groundSupportEquipmentLTOOperation>
    <groundSupportEquipmentLTOOperation>
      <gseID>41</gseID>
      <fuelType>Diesel</fuelType>
      <horsepower>235</horsepower>
      <loadFactor>0.2</loadFactor>
      <departureOpTime>8</departureOpTime>
      <arrivalOpTime>7</arrivalOpTime>
    </groundSupportEquipmentLTOOperation>
```

```
      </groundSupportEquipmentLTOOperationSet>
    </aircraftType>
    <numOperations>366</numOperations>
    <opType>D</opType>
    <departureAirport type="ICAO">KPVD</departureAirport>
    <departureGate>AC</departureGate>
    <departureApuTime>3.5</departureApuTime> <!-- in minutes -->
    <taxiOutDuration>10.72</taxiOutDuration> <!-- in minutes -->
    <taxiInDuration>6.24</taxiInDuration>    <!-- in minutes -->
    <activityProfile>ActivityProfile-Baseline-KPVD-0-0-0</activityProfile>
    <actypeWeight>146100</actypeWeight>      <!-- in pounds -->
    <fuelSulfurContent>0.00068</fuelSulfurContent>
  </operation>

  <operation>
    <id>A_1</id>
    <aircraftType>
      <airframeModel>Airbus A319-100 Series</airframeModel>
      <engineCode>3CM028</engineCode>
      <apuName>APU GTCP 36-300 (80HP)</apuName>
      <groundSupportEquipmentLTOOperationSet>
        <groundSupportEquipmentLTOOperation>
          <gseID>8</gseID>
          <fuelType>Diesel</fuelType>
          <horsepower>88</horsepower>
          <loadFactor>0.8</loadFactor>
          <departureOpTime>3.9</departureOpTime>
        </groundSupportEquipmentLTOOperation>
        <groundSupportEquipmentLTOOperation>
          <gseID>13</gseID>
          <fuelType>Gasoline</fuelType>
          <horsepower>107</horsepower>
          <loadFactor>0.55</loadFactor>
          <departureOpTime>8</departureOpTime>
          <arrivalOpTime>8</arrivalOpTime>
        </groundSupportEquipmentLTOOperation>
        <groundSupportEquipmentLTOOperation>
          <gseID>14</gseID>
          <fuelType>Gasoline</fuelType>
          <horsepower>107</horsepower>
          <loadFactor>0.5</loadFactor>
          <departureOpTime>11</departureOpTime>
          <arrivalOpTime>12</arrivalOpTime>
        </groundSupportEquipmentLTOOperation>
        <groundSupportEquipmentLTOOperation>
          <gseID>17</gseID>
          <fuelType>Diesel</fuelType>
          <horsepower>210</horsepower>
          <loadFactor>0.53</loadFactor>
          <departureOpTime>9.7</departureOpTime>
        </groundSupportEquipmentLTOOperation>
        <groundSupportEquipmentLTOOperation>
          <gseID>29</gseID>
          <fuelType>Diesel</fuelType>
          <horsepower>175</horsepower>
          <loadFactor>0.25</loadFactor>
          <departureOpTime>14</departureOpTime>
```

```xml
            </groundSupportEquipmentLTOOperation>
            <groundSupportEquipmentLTOOperation>
              <gseID>36</gseID>
              <fuelType>Diesel</fuelType>
              <horsepower>56</horsepower>
              <loadFactor>0.25</loadFactor>
              <arrivalOpTime>2.1</arrivalOpTime>
            </groundSupportEquipmentLTOOperation>
            <groundSupportEquipmentLTOOperation>
              <gseID>41</gseID>
              <fuelType>Diesel</fuelType>
              <horsepower>235</horsepower>
              <loadFactor>0.2</loadFactor>
              <departureOpTime>8</departureOpTime>
              <arrivalOpTime>7</arrivalOpTime>
            </groundSupportEquipmentLTOOperation>
          </groundSupportEquipmentLTOOperationSet>
        </aircraftType>
        <numOperations>366</numOperations>
        <opType>A</opType>
        <arrivalAirport type="ICAO">KPVD</arrivalAirport>
        <arrivalGate>AC</arrivalGate>
        <arrivalApuTime>3.5</arrivalApuTime>
        <taxiOutDuration>10.72</taxiOutDuration>
        <taxiInDuration>6.24</taxiInDuration>
        <activityProfile>ActivityProfile-Baseline-KPVD-0-0-0</activityProfile>
        <actypeWeight>137800</actypeWeight>
        <fuelSulfurContent>0.00068</fuelSulfurContent>
      </operation>
    </case>
  </caseSet>
```


5. Full ASIF

The full ASIF, *asif_emissions_study.xml*, is located in the directory: C:\Program Files\FAA\AEDT3d\Examples

1. Import the full ASIF in AEDT.
2. Create an annualization.
3. Create a metric result.

Please note that both the aircraft operations and the non-aircraft operations in this study are defined using operational profiles. When running profile-based aircraft operations, the “Apply Delay & Sequencing Model on Taxi” modeling option must be selected, and operating configuration and taxi network must exist in the airport layout.

4 User-Defined ANP and BADA 4 Profiles

4.1 Overview

There are three ways of creating and adding user-defined ANP and BADA 4 profiles in an AEDT study:

- By using the profile editor in the AEDT Graphical User Interface (GUI), Equipment tab (see Section 7.2.1 in AEDT User Manual);
- Creating and importing ASIF partial; and
- Direct database injection.

Of these methods, the first two are preferred because they include application-provided constraint and error checking. The following table provides a feature summary of the the three methods.

This Chapter focuses on the ASIF method and the direct database injection method for adding user-defined profiles

- Section 4.2 and Section 4.3 provide information on creating ASIF files that can be imported using ASIF partial import and provide details that would facilitate direct database injection to create user-defined profiles.
- Section 4.4 describes how the AEDT GUI's export functionality can be used to generate ASIF files that can subsequently be edited by the user to create their own or custom ANP and BADA 4 flight profiles.

Three Different Methods of Adding User-Defined Profiles

	Validation & error checking	ANP procedural profile for fixed-wing aircraft	BADA 4 procedural profile for fixed-wing aircraft	ANP fixed-point profile for fixed-wing aircraft	ANP profiles for helicopters	Overflight profiles
Profile Editor in AEDT GUI	✓	✓	✓			
ASIF	✓	✓	✓	✓	✓	✓
Direct DB Injection		✓	✓	✓	✓	✓

It is expected that users who create and use user-defined profiles are knowledgeable about the physics of flight performance modeling and understand the significance and use of individual profile elements. Users are responsible for entering valid values that are within the expected ranges for each type of parameter. For detailed explanations of flight profiles, please refer to the AEDT Technical Manual and the AEDT User Manual.

Using non-default profiles, for review of FAA federal actions or other FAA regulatory purposes, require prior approval by the FAA office of Environment and Energy (AEE). Please refer to the AEDT User Manual, Appendix J for further information on requesting approval for use of non-default profiles

4.2 User-Defined ANP Profiles

4.2.1 Key Requirements for a New ANP Profile

User-defined ANP profiles can be added to an existing ANP aircraft or created in conjunction with a new ANP aircraft definition. A key requirement for a new profile is that the Profile Name cannot be a duplicate of an existing record for that aircraft type. The primary key that uniquely defines a Profile is composed of the Operation Type, Profile Name, and the Stage Length.

In addition, any user-defined ANP profiles should have a PROFILE_ID value in the FLT_ANP_AIRPLANE_PROFILES table that is both unique and greater than 100,000. When creating user-defined ANP profiles via the AEDT GUI or importing via ASIF, the requirement that the Profile ID be greater than 100,000 is automatically handled. When the user is creating user-defined ANP profiles via manual database injection, the user must ensure that this requirement is met.

ANP profile entries are stored in the FLT_ANP_AIRPLANE_PROFILES table in a study database. Each unique profile entry in this table is determined by the combination of the ANP Aircraft Type, the Operation Type, the Profile Name, and the Stage Length. The integer value for Profile ID also uniquely identifies each entry in this table. The table below provides a mapping of the input ASIF elements for ANP profiles to specific database columns.

ANP Profile – Mapping of ASIF Element to Database Table & Columns

Parameter	ASIF Element Name	Column in Table FLT_ANP_AIRPLANE _PROFILES	Reference Columns (where applicable)
ANP Aircraft Type	anpAirplaneId	ACFT_ID	FLT_ANP_AIRPLANES.ACFT_ID
Operation Type	operationType	OP_TYPE	
Profile Name	profileGroupId	PROF_ID1	
Stage Length	profileStageLength	PROF_ID2	
Profile ID	n/a	PROFILE_ID	

ANP profiles can consist of either procedure steps or fixed-points. Both types of profiles can be defined for any given ANP aircraft type.

4.2.2 ANP Profile – Procedure Steps

Individual steps for procedural ANP profiles are stored in the FLT_ANP_AIRPLANE_PROCEDURES table. Each unique profile in this table is determined by the combination of the ANP Aircraft Type, the Operation Type, the Profile Name, and the Stage Length. Each unique row in this table is determined by the combination of the previous four fields plus the Step Number. The table below provides a mapping of the input ASIF elements for ANP procedural steps to specific database columns.

ANP Profile, Procedural Steps – Mapping of ASIF Elements to Database Table & Columns

Parameter	ASIF Element Name	Column in Table FLT_ANP_AIRPLANE _PROCEDURES	Reference Columns (where applicable)
ANP Aircraft Type	anpAirplaneId	ACFT_ID	FLT_ANP_AIRPLANES.ACFT_ID
Operation Type	operationType	OP_TYPE	FLT_ANP_AIRPLANE_PROFILES.OP_TYPE
Profile Name	profileGroupId	PROF_ID1	FLT_ANP_AIRPLANE_PROFILES.PROF_ID1
Stage Length	profileStageLength	PROF_ID2	FLT_ANP_AIRPLANE_PROFILES.PROF_ID2
Step Number	stepNum	STEP_NUM	
Flap ID	flapId (optional)	FLAP_ID (nullable)	FLT_ANP_AIRPLANE_FLAPS.FLAP_ID
Step Type	stepType (optional)	STEP_TYPE (nullable)	
Thrust Type	thrustType (optional)	THRUST_TYPE (nullable)	
First Parameter	param1	PARAM1	
Second Parameter	param2	PARAM2	
Third Parameter	param3 (optional)	PARAM3 (nullable)	

Sample ASIF for User-Defined ANP Procedural Profile

Following is a sample ASIF block that allows for the partial import of user-defined ANP procedural profiles. Refer to the accompanying ASIF file named *UserDefinedANPProfiles-ProcedureSteps.xml* for the complete sample file.

```
<fleet>
   <anpProfileSet>
      <anpAirplaneId>1900D</anpAirplaneId>
      <profile>
         <operationType>A</operationType>
         <profileGroupId>USER</profileGroupId>
         <profileStageLength>1</profileStageLength>
         <weight>14000</weight>
         <procedureSteps>
            <step>
               <stepNum>1</stepNum>
               <flapId>ZERO-A</flapId>
               <stepType>D</stepType>
               <param1>6000</param1>
               <param2>160</param2>
               <param3>3</param3>
            </step>
            <step>
               <stepNum>2</stepNum>
               <stepType>B</stepType>
               <thrustType>V</thrustType>
               <param1>515.2</param1>
               <param2>84</param2>
               <param3>40</param3>
            </step>
            <!-- more steps -->
         </procedureSteps>
```

```
      </profile>
      <!-- additional profiles -->
   </anpProfileSet>
</fleet>
```

4.2.3 ANP Profile – Fixed-Point

The points of fixed-point ANP profiles are stored in the FLT_ANP_AIRPLANE_PROFILE_POINTS table. Each unique profile in this table is determined by the combination of the ANP Aircraft Type, the Operation Type, the Profile Name, and the Stage Length. Each unique row in this table is determined by the combination of the previous four fields plus the Point Number. The table below provides a mapping of the input ASIF elements for ANP fixed-point profiles to specific database columns.

ANP Profile, Fixed-Points – Mapping of ASIF Elements to Database Table & Columns

Parameter	ASIF Element Name	Column in Table FLT_ANP_AIRPLANE _PROFILE_POINTS	Reference Columns (where applicable)
ANP Aircraft Type	anpAirplaneId	ACFT_ID	FLT_ANP_AIRPLANES.ACFT_ID
Operation Type	operationType	OP_TYPE	FLT_ANP_AIRPLANE_PROFILES.OP_TYPE
Profile Name	profileGroupId	PROF_ID1	FLT_ANP_AIRPLANE_PROFILES.PROF_ID1
Stage Length	profileStageLength	PROF_ID2	FLT_ANP_AIRPLANE_PROFILES.PROF_ID2
Point Number	pointNum	PT_NUM	
Distance	distance	DISTANCE	
Altitude	altitude	ALTITUDE	
Speed	speed	SPEED	
Net Thrust per Engine	thrustSet	THR_SET	
Operation Mode	opMode (optional)	OP_MODE (nullable)	

Sample ASIF for User-Defined ANP Fixed-Point Profile

Following is a sample ASIF block that allows for the partial import of user-defined ANP fixed-point profiles. Refer to the accompanying ASIF file named *UserDefinedANPProfiles-ProfilePoints.xml* for the complete sample file.

```
<fleet>
   <anpProfileSet>
      <anpAirplaneId>1900D</anpAirplaneId>
      <profile>
         <operationType>A</operationType>
         <profileGroupId>USER</profileGroupId>
         <profileStageLength>1</profileStageLength>
         <weight>14000</weight>
         <profilePoints>
            <point>
               <pointNum>1</pointNum>
               <distance>-114487.00</distance>
               <altitude>6000.00</altitude>
               <speed>250.00</speed>
               <thrustSet>520.00</thrustSet>
```

```
            <opMode>A</opMode>
         </point>
         <point>
            <pointNum>2</pointNum>
            <distance>-57243.00</distance>
            <altitude>3000.00</altitude>
            <speed>124.00</speed>
            <thrustSet>3560.00</thrustSet>
            <opMode>A</opMode>
         </point>
         <!-- more points -->
      </profilePoints>
   </profile>
   <!-- additional profiles -->
</anpProfileSet>
</fleet>
```

4.3 User-Defined BADA 4 Profiles (for Existing BADA 4 Aircraft)

4.3.1 Key Requirements for a New BADA 4 Profile

User-defined BADA 4 profiles can be added to an existing BADA 4 aircraft (either system or user-created) or created in conjunction with a new BADA 4 aircraft definition. BADA 4 profile entries are stored in the FltBada4AirplaneProfile table.

A user-defined BADA 4 profile entry has several key identifiers. The first is a unique Profile ID that is a value greater than or equal to 400,000. When creating user-defined BADA 4 profiles via the AEDT GUI, or when importing new profiles via ASIF, the requirement that the Profile ID be greater than or equal to 400,000 is automatically handled. When the user is creating user-defined BADA 4 profiles via manual database injection, the user must ensure that this requirement is met.

The other required identifying components are the reference ANP Aircraft Type and the reference BADA 4 Aircraft Model. These fields are references to an existing ANP Aircraft from the FLT_ANP_AIRPLANES table (ACFT_ID field) and an existing BADA 4 Aircraft from the FLT_BADA4_ACM table (BADA4_ID). In ASIF, the BADA 4 Aircraft reference field is specified with a combination of the BADA 4 Model and the BADA 4 Engine Model from the FLT_BADA4_ACM table that uniquely identify the BADA 4 Aircraft.

The table below provides a mapping of the input ASIF elements for BADA 4 profiles to specific database columns.

BADA 4 Profile – Mapping of ASIF Elements to Database Table & Columns

Parameter	ASIF Element Name	Field Name in Table FltBada4AirplaneProfile	Reference Fields (where applicable)
Profile ID	n/a	ProfileID	
Profile Name	flightProcedure	FlightProcedure	
Reference ANP Aircraft	anpAirplaneId	AnpAirplaneID	FLT_ANP_AIRPLANES.ACFT_ID
Reference BADA4 Aircraft	bada4AirplaneModel	Bada4AirplaneID	FLT_BADA4_ACM.BADA4_ID matched using the MODEL and ENGINE fields from FLT_BADA4_ACM
Reference BADA4 Engine	bada4Engine		

Operation Type	operationType	OperationType	
Weight Class	weightClass	WeightClass	
Weight	weight	Weight	

Note that unlike the other elements, the bada4AirplaneModel and bada4Engine elements specified in ASIF are only used to determine a specific record match to a BADA4_ID value from the FLT_BADA4_ACM table and are not explicitly persisted as part of the new profile.

In AEDT 3c, only procedural profiles may be defined for user-defined BADA 4 profiles. Individual steps for BADA 4 profiles are stored in the FltBada4AirplaneProcedure table. The records for each unique profile in this table are solely determined by the Profile ID key which references the parent profile in the FltBada4AirplaneProfile table. Each row in this table has a unique identifier in the form of the auto-incremented database field of ProcedureStepID. However, each unique procedure step for any given profile is determined by the combination of the Profile ID and the Step Number.

The table below provides a mapping of the input ASIF elements for BADA 4 procedure steps to specific database columns.

BADA 4 Profile, Procedural Steps – Mapping of ASIF Elements to Database Table & Columns

Parameter	ASIF Element Name	Field Name in Table FltBada4AirplaneProcedure	Reference Fields (where applicable)
Step ID	n/a	ProcedureStepID	
Profile ID	n/a	ProfileID	FltBada4AirplaneProfile.ProfileID
Step Number	stepNumber	StepNumber	
Reference Configuration ID	configId	ConfigurationID	FLT_BADA4_AFCM_CONFIG.CONFIG_ID
Reference ANP Aircraft for Flaps	anpAirplaneId	AnpAirplaneID	FLT_ANP_AIRPLANE_FLAPS.ACFT_ID
Reference ANP Flap Setting	anpFlapId	AnpFlapID	FLT_ANP_AIRPLANE_FLAPS.FLAP_ID
Step Type	stepType	StepType	
Thrust Type	thrustType	ThrustType	
Altitude	altitude	Altitude	
Calibrated Airspeed	calibratedAirspeed	CalibratedAirspeed	
Mach Number	mach	MachNumber	
Thrust	thrust	Thrust	
Angle	angle	Angle	
Climb Rate	climbRate	ClimbRate	
Flight Segment Length	distance	Distance	
Percent Acceleration	percent	Percent	
Gear Down	gearDown	GearDown	

Sample ASIF for User-Defined BADA 4 Profile

Following is a sample ASIF block that allows for the partial import of user-defined BADA 4 profiles. Refer to the accompanying ASIF file named *UserDefinedBADA4Profiles.xml* for the complete sample file.

```
<fleet>
   <bada4ProfileSet>
      <anpAirplaneId>737300</anpAirplaneId>
      <bada4AirplaneModel>737-300</bada4AirplaneModel>
      <bada4Engine>CFM56-3B1 (20K)</bada4Engine>
      <bada4profile>
        <operationType>A</operationType>
        <flightProcedure>UserBADA4_A</flightProcedure>
        <weightClass>1</weightClass>
        <weight>102600</weight>
        <bada4ProcedureSteps>
          <step>
            <stepNumber>1</stepNumber>
            <configId>229</configId>
            <anpAirplaneId>737300</anpAirplaneId>
            <anpFlapId>ZERO</anpFlapId>
            <stepType>D</stepType>
            <altitude>6000</altitude>
            <calibratedAirspeed>250</calibratedAirspeed>
            <mach>0</mach>
            <thrust>0</thrust>
            <angle>3</angle>
            <climbRate>0</climbRate>
            <distance>0</distance>
            <percent>0</percent>
            <gearDown>0</gearDown>
          </step>
          <!-- more steps -->
         </bada4ProcedureSteps>
      </bada4profile>
      <!-- additional profiles -->
   </bada4ProfileSet>
</fleet>
```

4.4 Create User-Defined ANP and BADA 4 Profiles for New or Existing Aircraft by Using the GUI Export Aircraft Feature

AEDT 3c GUI supports adding and editing user-defined ANP and BADA 4 flight profiles of existing fixed-wing aircraft as well as creating new user-defined aircraft. This section explains how to add custom ANP and BADA 4 flight profiles to existing and new aircraft by exporting existing aircraft, modifying the exported ASIF, and reimporting the modified ASIF.

4.4.1 Create a New User-Defined Aircraft with Custom Profiles

Follow the steps below to create a new user-defined aircraft with custom ANP and/or BADA 4 flight profiles:

1. Copy an existing system aircraft to create a new user-defined aircraft

1. In AEDT, go to the *Equipment* tab, *Aircraft*.
2. Select the aircraft to modify and click *Copy*.
3. Enter a suffix and click *Save*.
4. A new user-defined aircraft is created.

2. Export the new aircraft then delete it

1. Select the new aircraft and click *Export Aircraft* button.
2. The aircraft data is exported as a partial ASIF.
3. Click the *Delete* button to delete the new aircraft. This aircraft is no longer needed, because it will be edited in the ASIF and imported back into AEDT.

3. Open and edit the exported ASIF

1. Open the exported ASIF.
2. Under the <anpProfileSet> or the <bada4ProfileSet>, copy and paste one of the existing <profile> or <bada4Profile> sections.
3. Modify the new <profile> and/or <bada4profile> section by editing the profile properties. Ensure that profile names within each section are unique. Refer to the AEDT User Manual Appendix for details on how to define profiles for civil airplanes and helicopters.
4. Add additional profiles as needed.
5. Save the ASIF.

4. Import the ASIF

1. In AEDT, in the *Equipment* tab, click *Import Aircraft* button, select the updated ASIF and click *Open*.The new aircraft is listed in the *Equipment* tab.
2. Select the new aircraft and confirm that custom profiles have been added.

4.4.2 Add Custom Profiles to Existing Aircraft

Follow the steps below to add user-defined ANP and/or BADA 4 flight profiles to existing system or user-defined aircraft:

1. Export an existing aircraft and its profiles

1. In AEDT, go to the *Equipment* tab, *Aircraft*.
2. Select the aircraft to export.
3. Select the new aircraft and click *Export Aircraft* button.
4. The aircraft data is exported as a partial ASIF.

2. Open and edit the exported ASIF

1. Open the exported ASIF.
2. Edit the file to only keep the <anpProfileSet> and/or the <bada4ProfileSet> sections and remove all the other sections.
3. Modify the <profile> or <bada4profile> sections by editing each profile's properties. Ensure that the Profile Name is changed for each profile to be different from any of the profile names that already exist for that aircraft. Refer to the AEDT User Manual Appendix for details on how to define profiles for civil airplanes and helicopters.
4. Add additional profiles as needed.
5. Save the ASIF.

3. Import the ASIF

1. In AEDT, in the *Equipment* tab, click *Import Aircraft* button, select the updated ASIF and click *Open*.
2. Select the relevant aircraft and confirm that custom profiles have been added.

5 ASIF Design Consideration

5.1 Airport Layout and Runways

When defining an airport under the ***airportLayout*** element, users have the option to specify runway definitions using the ***runwaySet*** element. If runways are not specified in ASIF, then the runway data from the AEDT Airport database will be copied during the ASIF import.

When you add an existing airport to a study in AEDT GUI, AEDT will create a new airport layout for each instance when there has been a runway modification (e.g., extended runways or renamed runways). For example, add the KATL airport in AEDT GUI and confirm that multiple airport layouts are listed, each with different effective - expiration date range.

However, if you import such airport using ASIF without providing runway specifications, then AEDT will copy all the runways (both expired and the latest) from the Airport database into a single airport layout instead of creating multiple layouts. This means that the single airport layout will contain duplicate runway items once such airport is imported into AEDT.

In the example below, KATL is defined without any runway specifications. During ASIF import, AEDT will copy the entire history of KATL runways from the Airport database into the study database.

```
<airportLayout>
 <airportCode type="ICAO">KATL</airportCode>
</airportLayout>
```

The following screenshot shows the single airport layout for the KATL airport in AEDT GUI after importing the above ASIF example. Note that some items are listed twice – runway ends 09L and 27R, runways 09L-27R, and helipad H1.

In such a case, it is recommended to delete the duplicate runway ends and runways from the study. Review the effective date and expiration date of the runway ends/runways in the study database to determine which ones are expired vs. latest. Alternatively, specify runways in the ASIF using the ***runwaySet*** element.

Layout: KATL
Effective date: 1/1/1900 **Taxi-in time:** 0 minutes 0 seconds
Expiration date: 6/6/2079 **Taxi-out time:** 0 minutes 0 seconds

Ground Elements | Tracks

Choose Columns

Drag a column header and drop it here to group by that column

Type	ID	Name
Runway end	72254	08L
Runway end	84857	26R
Runway end	72255	08R
Runway end	84858	26L
Runway end	72256	09L
Runway end	84859	27R
Runway end	72257	09R
Runway end	84860	27L
Runway end	72258	10
Runway end	84861	28
Runway end	121432	27R
Runway end	122606	09L
Runway	36926	08L - 26R
Runway	36927	08R - 26L
Runway	36928	09L - 27R
Runway	36929	09R - 27L
Runway	36930	10 - 28
Runway	36931	H1
Runway	67816	27R - 09L
Runway	69090	H1
Helipad	72259	H1
Helipad	124455	H1

22 of 22 item(s) shown. 1 item(s) selected.

5.2 Event Consolidation

AEDT calculates noise for all air operations (e.g. all instances of an aircraft and track) in a given case, which differs from the legacy tool, NIRS. In order to optimize noise modeling performance in AEDT, it is suggested to combine like operations in a case into a representative single air operation for entry into the ASIF.

5.3 Control Codes

The altitude and/or speed of an airplane as it passes over a track node can be controlled to some extent by assigning track controls to that track node. Track controls are an optional feature that are used to specify targets and restrictions on altitude and/or speed on tracks – altitude controls affect airplane altitude; and speed controls affect airplane speed.

Each track control has two components: a value and a code. The value establishes a reference altitude or speed (appropriate to the control type), and the code specifies how that value should be interpreted in flight analysis.

In the ASIF schema, an altitude control is assigned to a ***trackNode*** by providing the control altitude as ***trackNode/altitude***, and the control code as ***trackNode/altitude/control***. Likewise, a speed control is defined by providing ***trackNode/speed***, and the control code as ***trackNode/speed/control***. Note that no control is defined if any of the following are true:

- A value is not provided;
- A code is not provided; or
- The code provided has a value of "0" or "None".

Furthermore, AEDT will ignore the following controls:

- Altitude controls with altitude values below 500 ft. AFE.
- All speed controls, if using the Doc 29/BADA 3 performance model.
- All speed controls, if the operation is an overflight.
- All controls, if the operation is a circuit or touch-and-go.

Also note that if there are any controls defined on an overflight, there must be controls defined (and observed, per the control-ignoring rules above) on the first and last nodes of the track.

AEDT computes performance to the following extents:

- Departure and approach performance is computed between ground roll and the observed control that is trackwise furthest from ground roll.
- Overflight performance is computed from the first track point to the last track point (both of which must have observed controls).

Performance is computed as close as possible to the observed control values, subject to the airplane's performance capabilities, as described in the AEDT Technical Manual. The computed best effort to achieve these targeted values is checked against the restrictions implied by the control codes:

- Control code "1" or "At or Below": the airplane is not allowed above the value
- Control code "2" or "Match": the airplane is not allowed above or below the value
- Control code "3" or "At or Above": the airplane is not allowed below the value

If the best effort fails to comply with the restriction, the flight's performance is discarded by AEDT, logged in the error log, and its impact is excluded from environmental metrics. For more information on track controls, refer to Section 3.9.1 Track Control Flights in the AEDT Technical Manual.

When translating NIRS inputs to ASIF, omitting altitude controls with altitude values below 3000 ft AFE will lead to the most comparable result, as NIRS ignored these controls. When modeling runway to runway operations using sensor path data, define the flight path using the ASIF ***sensorPath*** element rather than the track element. Sensor paths provide more direct control of altitude for an aircraft trajectory.

5.4 Assign Default Ground Suport Equipment (GSE) to Aircraft Operations

The ***assignDefaultGse*** element in the ASIF schema is used to assign default ground support equipment (GSE) to aircraft operation instead of writing out each GSE operation.

In this departure operation example, the ***assignDefaultGse*** is set to true. This will assign the default GSE for "Airbus A319-100 Series" to the operation. The default GSEs for the Airbus A319-100 Series, departure operation are listed in the table below. The default GSE assignments for airframe is stored in the FLT_GSE_AC_DEFAULTS table.

```
<operation>
  <id>D_1</id>
  <aircraftType>
    <airframeModel>Airbus A319-100 Series</airframeModel>
    <engineCode>3CM028</engineCode>
    <apuName>APU GTCP 36-300 (80HP)</apuName>
    <assignDefaultGse>true</assignDefaultGse>
  </aircraftType>
  <numOperations>1</numOperations>
  <opType>D</opType>
  .........
  .........
```

Default GSEs for Airbus A319-100 Series – Departure Operation

GSE Name	Duration (mins)	Horsepower	Load Factor	Manufacture Year
Electric - None - Air Conditioner	23	0	0.75	NA
Diesel - ACE 180 - Air Start	7	425	0.9	NA
"Diesel - Stewart & Stevenson TUG GT-35, Douglas TBL-180 - Aircraft Tractor"	8	88	0.8	NA
Gasoline - Stewart & Stevenson TUG MA 50 - Baggage Tractor	38	107	0.55	NA
Gasoline - Stewart & Stevenson TUG 660 - Belt Loader	24	107	0.5	NA
Diesel - Hi-Way F650 - Cabin Service Truck	10	210	0.53	NA
Diesel - Hi-Way F650 - Catering Truck	8	210	0.53	NA
Diesel - F250 / F350 - Hydrant Truck	12	235	0.7	NA
Diesel - TLD 1410 - Lavatory Truck	0	56	0.25	NA
Diesel - F250 / F350 - Service Truck	8	235	0.2	NA
Electric - Gate Service - Water Service	12	0	0.2	NA

To specify individual GSEs for the aircraft operation, use the ***groundSupportEquipmentLTOOperationSet***, as follows:

```
<operation>
  <id>D_1</id>
  <aircraftType>
    <airframeModel>Airbus A319-100 Series</airframeModel>
    <engineCode>3CM028</engineCode>
    <apuName>APU GTCP 36-300 (80HP)</apuName>
    <groundSupportEquipmentLTOOperationSet>
      <groundSupportEquipmentLTOOperation>
        <gseID>8</gseID>
        <fuelType>Diesel</fuelType>
        <horsepower>88</horsepower>
        <loadFactor>0.8</loadFactor>
        <departureOpTime>3.9</departureOpTime>
      </groundSupportEquipmentLTOOperation>
      <groundSupportEquipmentLTOOperation>
        <gseID>13</gseID>
        <fuelType>Gasoline</fuelType>
        <horsepower>107</horsepower>
        <loadFactor>0.55</loadFactor>
        <departureOpTime>8</departureOpTime>
        <arrivalOpTime>8</arrivalOpTime>
      </groundSupportEquipmentLTOOperation>
      <groundSupportEquipmentLTOOperation>
        <gseID>14</gseID>
        <fuelType>Gasoline</fuelType>
        <horsepower>107</horsepower>
        <loadFactor>0.5</loadFactor>
        <departureOpTime>11</departureOpTime>
        <arrivalOpTime>12</arrivalOpTime>
      </groundSupportEquipmentLTOOperation>
      <groundSupportEquipmentLTOOperation>
        <gseID>17</gseID>
        <fuelType>Diesel</fuelType>
        <horsepower>210</horsepower>
        <loadFactor>0.53</loadFactor>
        <departureOpTime>9.7</departureOpTime>
      </groundSupportEquipmentLTOOperation>
      <groundSupportEquipmentLTOOperation>
        <gseID>29</gseID>
        <fuelType>Diesel</fuelType>
        <horsepower>175</horsepower>
        <loadFactor>0.25</loadFactor>
        <departureOpTime>14</departureOpTime>
      </groundSupportEquipmentLTOOperation>
      <groundSupportEquipmentLTOOperation>
        <gseID>36</gseID>
        <fuelType>Diesel</fuelType>
        <horsepower>56</horsepower>
        <loadFactor>0.25</loadFactor>
        <arrivalOpTime>2.1</arrivalOpTime>
```

```
      </groundSupportEquipmentLTOOperation>
      <groundSupportEquipmentLTOOperation>
        <gseID>41</gseID>
        <fuelType>Diesel</fuelType>
        <horsepower>235</horsepower>
        <loadFactor>0.2</loadFactor>
        <departureOpTime>8</departureOpTime>
        <arrivalOpTime>7</arrivalOpTime>
      </groundSupportEquipmentLTOOperation>
    </groundSupportEquipmentLTOOperationSet>
  </aircraftType>
  <numOperations>1</numOperations>
  <opType>D</opType>
  .........
  .........
```

5.5 Import User-Defined Spectral Class Data

Sample ASIF for User-Defined Spectral Class Data

Following is a sample ASIF block that allows for the partial import of user-defined spectral class data. Refer to the accompanying ASIF file named *UserDefinedSpectralClass.xml* for the complete sample file, which is located in *C:\Program Files\FAA\AEDT3d\Examples* directory.

```
<fleet>
  <spectralClass>
    <!--ID -->
    <spectralClassId>20000</spectralClassId>
    <flightTypes>AL</flightTypes>
    <frequencyBand17>25.1</frequencyBand17>
    <frequencyBand18>26.1</frequencyBand18>
  .........
  .........
```

- The ***spectralClassId*** element specifies the user-defined Spectral Class ID. Valid value is in the range of 20,000 to 30,000 - inclusive.
- The ***flightTypes*** element is used to indicate flight types: A (arrival), D (departure), L (Level/Afterburner), or U (Unknown). In the example above, the ***flightTypes*** is set to “AL”, indicating Arrival and Level/Afterburner.

To import this file:

1. In the Equipment tab, *Aircraft* screen, then click the *Import Aircraft* button.
2. Select this file and click *Open*.
3. The Equipment list will be refreshed.

To assign the user-defined spectral classes to an aircraft:

1. Select an aircraft and click the *Copy* button to create a user-defined aircraft.
2. Go to the *ANP Airplane*, *Noise* screen (for a helicopter, go to the *ANP Helicopter*, *Noise* screen).
3. From the *Spectral class approach* dropdown menu, select the desired user-defined class ID.
4. From the *Spectral class departure* dropdown menu, select the desired user-defined class ID.
5. Enter a Suffix for the new aircraft and make other changes, then click the *Save* button.

6 ASIF Schema Documentation

Click on the following links to view descriptions for ASIF elements, groups, complex types and simple types.

Schema **AsifMerge.xsd**

schema location: **AsifMerge.xsd**
attributeFormDefault: **unqualified**
elementFormDefault: **qualified**

Elements

activityProfile
activityProfileSet
airportCapacity
airportConfig
airportConfigSet
airportLayoutSet
airportWeather
airportWeatherStation
annualization
annualizationCase
annualizationGroup
areaStationarySource
AsifXml
backbone
backboneNode
backboneNodes
boilerHeaterTypeCode
boundary
building
buildingSet
capacityPoint
case
caseSet
categoryAircraftEngine
categoryBoilerHeater
categoryDeicingArea
categoryFuelTank
categoryGenerator
categoryIncinerator
categoryOther
categoryRecordCode
categorySandSaltPile
categorySolventDegreaser
categorySurfaceCoatingPainting
categoryTrainingFire
centroid
climate
dailyProfile
dailyProfileSet
dispersionWeight
emissionsUsage
engineModeEmissionFactors
gate
gateSet
grid
groundSupportEquipmentGateAssignment
groundSupportEquipmentGateAssignmentSet
groundSupportEquipmentLTOOperation
groundSupportEquipmentLTOOperationSet
groundSupportEquipmentPopulationOperation
groundSupportEquipmentPopulationOperationSet
monthlyProfile
monthlyProfileSet
operation
operationalProfileSet
operations
options
parkingFacility
parkingFacilityOperation
parkingFacilityOperationSet
parkingFacilitySet
pointReceptor
pointStationarySource
polarGrid
polarReceptor
quarterHourlyProfile
quarterHourlyProfileSet

Groups

airportActivityGroup
annualizationGroupCase
coord2DGroup
latlonCoordGroup
nodeIdGroup
oneOrThreeCoords2DGroupSet
receptorGroup
utmCoordGroup

Complex types

aircraft
aircraftEngine
aircraftEngineMod
aircraftType
airframe
airport
airportCode
airportLayoutType
anpAirplane
anpFlaps
anpFlapsSet
anpHelicopter
anpHeloDirectivity
anpHeloDirectivitySet
anpHeloNoiseGroup
anpHeloNPDCurve
anpHeloNPDCurves
anpHeloProcedureStep
anpHeloProfile
anpHeloProfileSet
anpNoiseGroup
anpNPDCurve
anpNPDCurves
anpProcedureStep
anpProcedureSteps
anpProfile
anpProfilePoint
anpProfilePoints
anpProfileSet
anpThrustGeneral
anpThrustJet
anpThrustProp
anpThrustSet
anpTsfcCoefficients
auxiliaryPowerUnit
bada4ProcedureStep
bada4ProcedureSteps
bada4Profile
bada4ProfileSet
badaAirplane
badaAltitudeDistribution
badaAltitudeDistributionSet
badaConfig
badaConfigSet
badaFuel
badaProfile
badaProfileSet
badaThrust
coord2DType
coord3DElevationType
dispersionWeight1Type
dispersionWeight3Type
dispersionWeight5Type
dispersionWeight7Type
dispersionWeight9Type
emissionFactorSet
energyShare
engineModeEmissions
fleet
latitudeDecimalType
longitudeDecimalType
polygon2DType
polygon3DElevationType
profiles
runup
runwayEnd
scenarioAirportLayoutType

Simple types

aircraftPerformanceModelType
AircraftSizeType
airframeModel
airportCodeType
anpAirplaneId
anpCoeffType
anpFlapId
anpHeloDirectId
anpHeloDirectivityId
anpHeloGroundType
anpHeloId
anpHeloNoiseId
anpHeloSideType
anpNoiseId
anpNpdNoiseType
anpNpdOpMode
anpOwnerType
anpSizeCode
apuName
bada4AirplaneModel
bada4Engine
bada4Suffix
badaAirplaneId
badaPhaseType
badaWakeType
directionType
doubleExclusive0Inclusive10
doubleExclusive10
doubleExclusive100
doubleExclusive1000
doubleExclusive10000
doubleExclusive2000
doubleExclusiveRange100
doubleInclusive1
doubleInclusive100
doubleInclusive1000
doubleInclusive10000
doubleInclusive2000
doubleInclusive24
doubleInclusive4000
doubleInclusiveRange0to600
doubleInclusiveRange1to30
doubleMin0
emissionsSourceType
emissionsUnitsType
empty-string
engineCode
engineModCode
engineModel
engineType
floatExclusive0Inclusive10
floatExclusive10
floatExclusive100
floatExclusive1000
floatExclusive10000
floatExclusive2000
floatExclusiveRange100
floatInclusive1
floatInclusive100
floatInclusive1000
floatInclusive10000
floatInclusive2000
floatInclusive24
floatInclusive4000
floatInclusiveRange1to30
floatInclusiveRange32to600
fuelType

receptorSet
recordCode
roadway
roadwayOperation
roadwayOperationSet
roadwaySet
runway
runwayAssignment
runwayAssignmentSet
runwaySet
scenario
scenarioAirportLayoutSet
sensorNode
sensorPath
stationarySource
stationarySourceOperation
stationarySourceOperationSet
stationarySourceSet
study
subtrack
taxiNode
taxiNodeSet
taxipath
taxipathSet
taxiTime
taxiway
taxiwaySet
track
trackNode
trackNodes
trackOpSet
trackref
trackSet
trackVector
trackVectors
userDefinedAirportSet
userGroundSupportEquipment
userGroundSupportEquipmentSet
vehicleEmissionFactors
volumeStationarySource
weatherData
windRose
windRoseData
windRoseStation

spectralClass

groundVehicleType
int0to23
int0to360
int0to5
int0to87
int1to13
int1to15
int1to2
int1to25
int1to4
int1to5
int1to8
int1to93
int5to65
int6to13
int89to148
latitudeDMSType
longitudeDMSType
nodeControlType
opType
originSourceType
profileType
quarterHourMinutes
spectralClassId
spectralFlightType
string1
string10
string100
string11
string12
string14
string15
string16
string2
string20
string200
string25
string255
string3
string30
string32
string4
string40
string42
string5
string50
string6
string64
string66
string7
string8
string9
studyType
taxiModelType
timeInModeBasisType
trackType
trainingFireFuelType
vectorTrackType
weatherDataYear
wingType
yesNoType

element **activityProfile**

diagram	

properties	content complex
children	**quarterHourlyProfile** **dailyProfile** **monthlyProfile**
used by	element **activityProfileSet**
attributes	Name Type Use Default Fixed Annotation name **string100** required
annotation	documentation Supports legacy EDMS studies relating to content combinations of QUARTER_HOURLY_PROFILES, DAILY_PROFILES, and MONTHLY_PROFILES.

attribute **activityProfile/@name**

type	**string100**
properties	use required
facets	Kind Value Annotation minLength 0 maxLength 100

element **activityProfile/quarterHourlyProfile**

diagram	**quarterHourlyProfile** Defines scaling factors for operations during a particular quarter-hour.
type	**string100**
properties	content simple
used by	element **quarterHourlyProfileSet**
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Defines scaling factors for operations during a particular quarter-hour.

element **activityProfile/dailyProfile**

diagram	**dailyProfile** Defines scaling factors for operations on a particular day.
type	**string100**
properties	content simple
used by	element **dailyProfileSet**
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Defines scaling factors for operations on a particular day.

element **activityProfile/monthlyProfile**

diagram	
type	**string100**
properties	content simple
used by	element **monthlyProfileSet**
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Defines scaling factors for operations during a particular month.

element **activityProfileSet**

diagram	
properties	content complex
children	**activityProfile**
used by	element **operationalProfileSet** complexType **airportLayoutType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports the definition and use of QUARTER_HOURLY_PROFILES, DAILY_PROFILES, and MONTHLY_PROFILES variation of operations.

attribute **activityProfileSet/@dummy**

type	**xs:int**
properties	use optional

element **airportCapacity**

diagram	
properties	content complex
children	**capacityPoint**
used by	element **airportConfig** complexTypes **airportLayoutType** **scenarioAirportLayoutType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional

annotation	documentation Supports legacy EDMS studies relating to content contained in the RUNWAY_CONFIGURATIONS table. This element supports the definition of airport capacities based on various points within an airport.

attribute **airportCapacity/@dummy**

type	**xs:int**
properties	use optional

element **airportConfig**

diagram	

properties	content complex
children	**configurationName** **useDistribution** **weight** **startWindAngle** **endWindAngle** **minWindSpeed** **maxWindSpeed** **startHour** **endHour** **minCeiling** **maxCeiling** **minVisibility** **maxVisibility** **minTemperature** **maxTemperature** **airportCapacity** **runwayAssignmentSet**
used by	element **airportConfigSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the RUNWAY_CONFIGURATIONS table. This element supports the definition of airports and their runway configurations for a given scenario layout. Airports operate under different configurations (the pattern of aircraft arrivals and departures on specific runways) over the course of a

	year depending on the weather, capacity, and noise abatement issues.

element **airportConfig/configurationName**

diagram	**configurationName** Runway configuration name.
type	**string100**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Runway configuration name.

element **airportConfig/useDistribution**

diagram	**useDistribution** Flag to use a distribution for the configuration.
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Flag to use a distribution for the configuration.

element **airportConfig/weight**

diagram	**weight** Runway configuration weight factor.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Runway configuration weight factor.

element **airportConfig/startWindAngle**

diagram	**startWindAngle** Start wind angle. Valid values: 0.00 to 359.00. UNITS: decimal degrees
type	**int0to360**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxExclusive 360
annotation	documentation Start wind angle. Valid values: 0.00 to 359.00. UNITS: decimal degrees

element **airportConfig/endWindAngle**

diagram	**endWindAngle** End wind angle. Valid values: 0.00 to 359.00. UNITS: decimal degrees
type	**int0to360**
properties	minOcc 0

	maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxExclusive 360
annotation	documentation End wind angle. Valid values: 0.00 to 359.00. UNITS: decimal degrees

element **airportConfig/minWindSpeed**

diagram	**minWindSpeed** Minimum wind speed. Valid values: 0.00 to 100.00. UNITS: knots
type	**doubleExclusive100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Minimum wind speed. Valid values: 0.00 to 100.00. UNITS: knots

element **airportConfig/maxWindSpeed**

diagram	**maxWindSpeed** Maximum wind speed. Valid values: 0.00 to 100.00. UNITS: knots
type	**doubleExclusive100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Maximum wind speed. Valid values: 0.00 to 100.00. UNITS: knots

element **airportConfig/startHour**

diagram	**startHour** Start hour. Valid values: 0.00 to 23.00.
type	**doubleInclusive24**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 24
annotation	documentation Start hour. Valid values: 0.00 to 23.00.

element **airportConfig/endHour**

diagram	**endHour** End hour. Valid values: 0.00 to 23.00.
type	**doubleInclusive24**
properties	minOcc 0 maxOcc 1

	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 24
annotation	documentation End hour. Valid values: 0.00 to 23.00.

element **airportConfig/minCeiling**

diagram	**minCeiling** Minimum ceiling AFE. Valid values: 0.00 to 100000.00. UNITS: feet
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Minimum ceiling AFE. Valid values: 0.00 to 100000.00. UNITS: feet

element **airportConfig/maxCeiling**

diagram	**maxCeiling** Maximum ceiling AFE. Valid values: 0.00 to 100000.00. UNITS: feet
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Maximum ceiling AFE. Valid values: 0.00 to 100000.00. UNITS: feet

element **airportConfig/minVisibility**

diagram	**minVisibility** Minimum visibility. Valid values: 0.00 to 100.00. UNITS: statute miles
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Minimum visibility. Valid values: 0.00 to 100.00. UNITS: statute miles

element **airportConfig/maxVisibility**

diagram	**maxVisibility** Maximum visibility. Valid values: 0.00 to 100.00. UNITS: statute miles
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Maximum visibility. Valid values: 0.00 to 100.00. UNITS: statute miles

element **airportConfig/minTemperature**

diagram	**minTemperature** Minimum temperature. Valid values: -100.00 to 150.00. (°F)

type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Minimum temperature. Valid values: -100.00 to 150.00. (°F)

element **airportConfig/maxTemperature**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Maximum temperature. Valid values: -100.00 to 150.00. (°F)

element **airportConfigSet**

diagram	
properties	content complex
children	**airportConfig**
used by	complexTypes **airportLayoutType** **scenarioAirportLayoutType**
annotation	documentation Contains one or more airportConfig elements.

element **airportLayoutSet**

diagram	
properties	content complex
children	**airportLayout**
used by	elements **AsifXml** **study**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Contains layouts for ASIF partial import into an existing study.

attribute **airportLayoutSet/@dummy**

type	**xs:int**
properties	use optional

element **airportLayoutSet/airportLayout**

diagram

point source plumes by essentially serving as obstacles to those sources, and therefore have a significant impact on concentrations resulting from stationary source emissions. Buildings have no effect on the concentrations estimated from volume and area sources such as aircraft, APU, GSE, roadways, and parking facilities.
airportLayout
1..∞
Contains information about the available layout of each airport in the study.
parkingFacilitySet
Supports legacy EDMS studies relating to content contained in the PARKING table. This element supports the definition of parking lot and parking garage activities for scenario layouts.
stationarySourceSet
Container of stationary sources contributing emissions.
gateSet
Supports legacy EDMS studies relating to content contained in the GATES table. This element supports the definition of gates within an airport layout. In dispersion analyses, GSE, AGE, and APU emissions originate from the gate locations. Gates are needed for sequence modeling, which includes all dispersion analyses.
roadwaySet
Supports legacy EDMS studies relating to content contained in the ROADWAYS table. This element supports the definition of vehicle activity on roadways for scenario layouts.
taxiwaySet
Supports legacy EDMS studies relating to the TAXIWAYS table. Taxiways determine the ground segments where the aircraft operates.
runwaySet
Container for runways.
taxipathSet
Supports legacy EDMS studies relating to the TAXIPATHS table. A taxipath is a sequence of taxiways, possibly just one, that connects a gate to a runway or vice versa. Taxipaths are used to do the modeling of aircraft ground movement. They are needed for sequence modeling, which includes all dispersion analyses. Gates, taxiways and runways must be defined before taxipaths can be specified.
trackSet
A set of flight tracks.
airportConfigSet
Contains one or more airportConfig elements.
airportCapacity
Supports legacy EDMS studies relating to content contained in the RUNWAY_CONFIGURATIONS table. This element supports the definition of airport capacities based on

type	**airportLayoutType**
properties	minOcc 1 maxOcc unbounded content complex
children	**name** **airportCode** **startDate** **elevation** **peakMonthAverageDayScalingFactor** **taxiInTime** **taxiOutTime** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **buildingSet** **parkingFacilitySet** **stationarySourceSet** **gateSet** **roadwaySet** **taxiwaySet** **runwaySet** **taxipathSet** **trackSet** **airportConfigSet** **airportCapacity** **quarterHourlyProfileSet** **dailyProfileSet** **monthlyProfileSet** **activityProfileSet**
annotation	documentation Contains information about the available layout of each airport in the study.

element **airportWeather**

diagram	
properties	content complex
children	**airportWeatherStationId** **airportWeatherStation**
used by	complexType **airport**

element **airportWeather/airportWeatherStationId**

diagram	
type	**xs:int**
properties	content simple

element **airportWeatherStation**

diagram	

properties	content complex
children	**airportWeatherStationId** **startDate** **endDate** **weatherStationCode** **weatherStationName** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **weatherStationElevationFeet** **distanceToStation** **cooperativeId** **wbanId** **weatherData**
used by	element **airportWeather**

element **airportWeatherStation/airportWeatherStationId**

diagram	
type	**xs:int**
properties	content simple

element **airportWeatherStation/startDate**

diagram	
type	**xs:date**
properties	content simple

element **airportWeatherStation/endDate**

diagram	endDate
type	**xs:date**
properties	content simple

element **airportWeatherStation/weatherStationCode**

diagram	weatherStationCode
type	**string5**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 5

element **airportWeatherStation/weatherStationName**

diagram	weatherStationName
type	**string25**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 25

element **airportWeatherStation/weatherStationElevationFeet**

diagram	weatherStationElevationFeet
type	**xs:int**
properties	content simple

element **airportWeatherStation/distanceToStation**

diagram	distanceToStation
type	**xs:double**
properties	content simple

element **airportWeatherStation/cooperativeId**

diagram	cooperativeId
type	**string6**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 6

element **airportWeatherStation/wbanId**

diagram	wbanId
type	**string5**
properties	minOcc 0 maxOcc 1

	content simple
facets	Kind Value Annotation minLength 0 maxLength 5

element **annualization**

diagram	
properties	content complex
children	**name** **annualizationGroup**
used by	elements **AsifXml** **scenario**
annotation	documentation Contains annualizations for ASIF partial import into an existing study.

element **annualization/name**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Name of annualization.

element **annualizationCase**

diagram	
properties	content complex
children	**name** **weight** **scaleFactor**
used by	group **annualizationGroupCase**
annotation	documentation Collection of study cases whose results are weighted in the scenario annualization rollup.

element **annualizationCase/name**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Description of the case.

element **annualizationCase/weight**

diagram	**weight** Weight associated with the case.
type	**xs:double**
properties	content simple
annotation	documentation Weight associated with the case.

element **annualizationCase/scaleFactor**

diagram	**scaleFactor** Scale factor applied to results for the case.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Scale factor applied to results for the case.

element **annualizationGroup**

diagram	
properties	content complex
children	**weight** **scaleFactor** **annualizationGroup** **annualizationCase**
used by	element **annualization** group **annualizationGroupCase**
annotation	documentation Contains one or more weighted annualization group cases.

element **annualizationGroup/weight**

diagram	**weight** Weight associated with the annualization group.
type	**xs:double**
properties	content simple
annotation	documentation Weight associated with the annualization group.

element **annualizationGroup/scaleFactor**

diagram	

	scaleFactor Scale factor applied to results for the annualization group.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Scale factor applied to results for the annualization group.

element **areaStationarySource**

diagram	
properties	content complex
children	**pointCoord** **polygonCoords** **baseElevation** **releaseHeight** **sigmaZ**
used by	element **stationarySource**
annotation	documentation Specifies the area in space occupied by a stationary source of emissions.

element **areaStationarySource/baseElevation**

diagram	**baseElevation** Elevation in MSL of area, valid values -500 to 5000 (m)
type	**xs:double**
properties	content simple
annotation	documentation Elevation in MSL of area, valid values -500 to 5000 (m)

element **areaStationarySource/releaseHeight**

diagram	**releaseHeight** Height at which emissions are released into the atmosphere. Valid values: 0 to 100 (m)
type	**doubleInclusive100**
properties	minOcc 0 maxOcc 1 content simple default 0
facets	Kind Value Annotation minInclusive 0

	maxInclusive 100
annotation	documentation Height at which emissions are released into the atmosphere. Valid values: 0 to 100 (m)

element **areaStationarySource/sigmaZ**

diagram	**sigmaZ** Vertical dispersion parameter. For additional information, see the EDMS Application Manual. Valid values: 0.1 to 100.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Vertical dispersion parameter. For additional information, see the EDMS Application Manual. Valid values: 0.1 to 100.

element **AsifXml**

diagram

properties	content complex
children	**options** **airportLayoutSet** **annualization** **boundary** **case** **fleet** **operation** **runup** **receptorSet** **scenario** **study** **trackOpSet** **userGroundSupportEquipmentSet** **stationarySourceSet** **operationalProfileSet**

attributes	Name	Type	Use	Default	Fixed	Annotation
	version	**string16**	optional			documentation Study version. Used for revision control of a study.
	content	**derived by: xs:string**	required			

annotation	documentation Root node of the ASIF tree.

attribute **AsifXml/@version**

type	**string16**
properties	use optional
facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation Study version. Used for revision control of a study.

attribute **AsifXml/@content**

type	restriction of **xs:string**
properties	use required
facets	Kind Value Annotation enumeration airportLayoutSet enumeration annualization enumeration case enumeration fleet enumeration receptorSets enumeration scenario enumeration study enumeration boundary enumeration trackOpSet enumeration runup enumeration userGroundSupportEquipmentSet enumeration stationarySourceSet enumeration operationalProfileSet

element **AsifXml/fleet**

diagram	

fleet
Contains study fleet data for ASIF partial import into existing study.
auxiliaryPowerUnit
0..∞
Describes a custom auxiliary power unit (APU). These are typically on-board generators providing power to a parked aircraft.
airframe
0..∞
Supports the definition of custom airframes.
engine
0..∞
User defined engine information containing custom parameters that reflect an aircraft engine. This engine definition can then be used within a user-defined aircraft.
engineMod
0..∞
User defined engine modification information containing custom parameters that reflect an aircraft engine modification. This engine modification definition can that be used within a user defined aircraft.
spectralClass
0..∞
This element contains user-defined spectral class data.
anpNoiseGroup
0..∞
This element contains the three spectral class references for a given aircraft noise group with the corresponding thrust setting type and model type.
anpAirplane
0..∞
Creates a new ANP aircraft.
anpFlapsSet
0..∞
Flap settings for an ANP aircraft type.
anpThrustSet
0..∞
Specifies a set of thrust records for an ANP aircraft.
anpProfileSet
0..∞
The profile set for an ANP aircraft.
anpHeloNoiseGroup
0..∞
This element contains the three spectral class references for a given helicopter noise group with the corresponding thrust setting type and model type.
anpHelicopter
0..∞
Creates a new ANP helicopter.
anpHeloDirectivitySet
0..∞
A set of helicopter directivities.
anpHeloProfileSet
0..∞

type	**fleet**
properties	minOcc 0 maxOcc 1 content complex
children	**auxiliaryPowerUnit** **airframe** **engine** **engineMod** **spectralClass** **anpNoiseGroup** **anpAirplane** **anpFlapsSet** **anpThrustSet** **anpProfileSet** **anpHeloNoiseGroup** **anpHelicopter** **anpHeloDirectivitySet** **anpHeloProfileSet** **badaAirplane** **badaAltitudeDistributionSet** **badaDefaultAltitudeDistributionSet** **badaProfileSet** **badaConfigSet** **badaFuel** **badaThrust** **bada4ProfileSet** **aircraft** **energyShare**
annotation	documentation Contains study fleet data for ASIF partial import into existing study.

element **AsifXml/runup**

diagram	

type	**runup**
properties	minOcc 1 maxOcc unbounded

	content complex
children	**id** **aircraftType** **flightNumber** **tailNumber** **numOperations** **airport** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **opTime** **duration** **heading** **thrust**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation An aircraft runup operation type.

element **backbone**

diagram	
properties	content complex
children	**dispersionWeight** **backboneNodes**
used by	element **track**
annotation	documentation Represents the centerline of a set of dispersed tracks.

element **backboneNode**

diagram	
properties	content complex
children	**trackNode** **halfwidth**
used by	element **backboneNodes**
annotation	documentation A 3D node that is part of a backbone.

element **backboneNode/halfwidth**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Halfwidth in nautical miles. (nmi)

element **backboneNodes**

diagram	
properties	content complex
children	**backboneNode**

used by	element **backbone**
annotation	documentation The set of 3D nodes for the backbone.

element **boilerHeaterTypeCode**

diagram	
type	union of (restriction of **xs:integer**, restriction of **xs:integer**, restriction of **xs:integer**)
properties	content simple
used by	element **categoryBoilerHeater**
annotation	documentation An integer value for the Boiler/Heater type represented. This value comes from the SUBCATEGORY_ID column of the STN_CATEGORY table in the AEDT FLEET database. Valid values: 1 to 37, 50 to 75, 80 to 93.

element **boundary**

diagram	
properties	content complex
children	**polygon**
used by	elements **AsifXml** **study**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Specifies the boundaries of a study or other element contained within a study. When a study boundary is specified, all flight paths resulting from departure, arrival, and overflight operations are calculated to and/or from the study boundary.

attribute **boundary/@dummy**

type	**xs:int**
properties	use optional

element **boundary/polygon**

diagram	
type	**polygon2DType**
properties	minOcc 1 maxOcc unbounded content complex
children	**dummy** **vertex**

annotation	documentation Set of coordinates defining the boundary.

element **building**

diagram	
properties	content complex
children	**name** **elevation** **height** **releaseHeight** **pointCoord** **polygonCoords**
used by	element **buildingSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the BUILDINGS table. This element supports the definition of airport buildings. These building sources affect the emitted point source plumes by essentially serving as obstacles to those sources, and therefore have a significant impact on concentrations resulting from stationary source emissions. Buildings have no effect on the concentrations estimated from volume and area sources such as aircraft, APU, GSE, roadways, and parking facilities.

element **building/name**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Name of the building.

element **building/elevation**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Elevation of building. Valid values: -500 to 5000. (m)

element **building/height**

diagram	

type	**xs:double**
properties	content simple
annotation	documentation Height of building. Valid values: 0 to 100 (m)

element **building/releaseHeight**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Height at which emissions are released into the atmosphere. Valid values 0 to 100 (m)

element **buildingSet**

diagram	
properties	content complex
children	**building**
used by	complexType **airportLayoutType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the BUILDINGS table. This element supports the definition of airport buildings. These building sources affect the emitted point source plumes by essentially serving as obstacles to those sources, and therefore have a significant impact on concentrations resulting from stationary source emissions. Buildings have no effect on the concentrations estimated from volume and area sources such as aircraft, APU, GSE, roadways, and parking facilities.

attribute **buildingSet/@dummy**

type	**xs:int**
properties	use optional

element **capacityPoint**

diagram	

properties	content complex
children	**arrivalsPerHour departuresPerHour**
used by	element **airportCapacity**
annotation	documentation Supports legacy EDMS studies relating to content contained in the RUNWAY_CONFIGURATIONS table. This element supports the definition of airport capacities based on various points within an airport.

element **capacityPoint/arrivalsPerHour**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Number of arrivals per hour. Valid values: 0.00 to 400.00. (operations per hour)

element **capacityPoint/departuresPerHour**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Number of departures per hour. Valid values: 0.00 to 400.00. (operations per hour)

element **case**

diagram	

properties	content complex
children	**caseId** **name** **source** **startTime** **duration** **climateId** **hourlyWxFile** **hourlyWxMD5** **description** **case** **trackOpSet** **operation** **runup** **parkingFacilityOperationSet** **roadwayOperationSet** **stationarySourceOperationSet** **groundSupportEquipmentPopulationOperationSet** **reference**
used by	elements **AsifXml** **case** **caseSet**
annotation	documentation Describes general parameters for a case.

element **case/caseId**

diagram	**caseId** Case ID.
type	**xs:int**
properties	content simple
annotation	documentation Case ID.

element **case/name**

diagram	**name** The name of the case (must be unique within the scenario).
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The name of the case (must be unique within the scenario).

element **case/source**

diagram	**source**
type	**emissionsSourceType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation enumeration Container enumeration Aircraft enumeration GSE Population enumeration Parking Facilities enumeration Roadways enumeration Stationary Sources

element **case/startTime**

diagram	**startTime** Case's start time. If not defined, the value specified in the scenario element will be used. Must match the value for startTime for the scenario. Accepts dateTime string.
type	**xs:dateTime**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Case's start time. If not defined, the value specified in the scenario element will be used. Must match the value for startTime for the scenario. Accepts dateTime string.

element **case/duration**

diagram	**duration** Case's duration. If not defined, the value specified in the scenario element will be used. Must match the value for duration for the scenario. For AEDT this is restricted to 24 hours (1 day). All cases within a scenario must have the same duration as the scenario. (hr).

type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Case's duration. If not defined, the value specified in the scenario element will be used. Must match the value for duration for the scenario. For AEDT this is restricted to 24 hours (1 day). All cases within a scenario must have the same duration as the scenario. (hr).

element **case/climateId**

diagram	**climateId** ID of a climate condition.
type	**string8**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation ID of a climate condition.

element **case/hourlyWxFile**

diagram	**hourlyWxFile** The file containing the hourly weather data used for emissions calculations. This element is not supported in AEDT.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The file containing the hourly weather data used for emissions calculations. This element is not supported in AEDT.

element **case/hourlyWxMD5**

diagram	**hourlyWxMD5** The weather file's MD5 checksum. If not present, the MD5 checksum will be computed for the user at the time of importing the ASIF. This element is not supported in AEDT.
type	**string16**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation The weather file's MD5 checksum. If not present, the MD5 checksum will be computed for the user at the time of importing the ASIF. This element is not supported in AEDT.

element **case/description**

diagram	**description** Description of the case.
type	**string255**

properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Description of the case.

element **case/runup**

diagram	

type	**runup**
properties	minOcc 1 maxOcc unbounded

	content complex
children	**id aircraftType flightNumber tailNumber numOperations airport latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone opTime duration heading thrust**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional

element **case/reference**

diagram	
properties	content complex
children	**refScenario refCase**
annotation	documentation Refers to a case by its scenario name and case name. Conditions required: a) all airport layouts in the referenced scenario must be assigned to the target scenario, and b) the referenced case must have a unique name in the new scenario.

element **case/reference/refScenario**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Scenario under which an existing case appears.

element **case/reference/refCase**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Existing case that appears under the refScenario.

element **caseSet**

diagram	
properties	content complex
children	**case**
used by	element **scenario**

attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Placeholder for one or more cases.

attribute **caseSet/@dummy**

type	**xs:int**
properties	use optional

element **categoryAircraftEngine**

diagram	
properties	content complex
children	**engineCode** **timePercentPower7** **timePercentPower30** **timePercentPower85** **timePercentPower100**
used by	element **stationarySource**
annotation	documentation Describes a category for the time an aircraft engine is at various power levels.

element **categoryAircraftEngine/engineCode**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255

element **categoryAircraftEngine/timePercentPower7**

diagram	
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Time at which engine is operating at 7% (taxi) power. Valid values: 0 to 1000. (min)

element **categoryAircraftEngine/timePercentPower30**

diagram	**timePercentPower30** Time at which engine is operating at 30% (approach) power. Valid values: 0 to 1000. (min)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Time at which engine is operating at 30% (approach) power. Valid values: 0 to 1000. (min)

element **categoryAircraftEngine/timePercentPower85**

diagram	**timePercentPower85** Time at which engine is operating at 85% (climbout) power. Valid values: 0 to 1000. (min)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Time at which engine is operating at 85% (climbout) power. Valid values: 0 to 1000. (min)

element **categoryAircraftEngine/timePercentPower100**

diagram	**timePercentPower100** Time at which engine is operating at 100% (takeoff) power. Valid values: 0 to 1000. (min)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Time at which engine is operating at 100% (takeoff) power. Valid values: 0 to 1000. (min)

element **categoryBoilerHeater**

diagram	**boilerHeaterTypeCode** An integer value for the Boiler/Heater type represented. This value comes from the SUBCATEGORY_ID column of the STN_CATEGORY table in the AEDT FLEET database. Valid values: 1 to 37, 50 to 75, 80 to 93. **CO_EI** CO emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3) **pollutionControlFactorCO** Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000.

(%)
TNMOC_EI
TNMOC emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
pollutionControlFactorTNMOC
Percent of total non-methane organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)
VOC_EI
VOC emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
pollutionControlFactorVOC
Percent of volatile organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)
TOC_EI
Total organic compound emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
pollutionControlFactorTOC
Percent of total organic compounds removed by pollution control measures. Valid values: 0 to 100.(%)
THC_EI
Total hydrocarbon emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
pollutionControlFactorHC
Percent of hydrocarbons removed by pollution control measures. Valid values: 0 to 100. (%)
categoryBoilerHeater
Describes the operational characteristics of a source in the boiler/heater category.
NOx_EI
NOx emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
pollutionControlFactorNOx
Percent of nitrous oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
constantTermSOx
SOx emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
sulfurTermSOx
SOx sulfur EI term, fuel dependent. Valid values: 0 to 1000. (Kg/1000 m^3 - %Sulfur, or Kg/Kiloliter - %Sulfur, or Kg/Metric Ton - %Sulfur)
pollutionControlFactorSOx
Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
constantTermPm10
PM10 emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
sulfurTermPm10
PM10 sulfur EI term, fuel dependent. Valid values: 0

properties	content complex
children	**boilerHeaterTypeCode** **CO_EI** **pollutionControlFactorCO** **TNMOC_EI** **pollutionControlFactorTNMOC** **VOC_EI** **pollutionControlFactorVOC** **TOC_EI** **pollutionControlFactorTOC** **THC_EI** **pollutionControlFactorHC** **NOx_EI** **pollutionControlFactorNOx** **constantTermSOx** **sulfurTermSOx** **pollutionControlFactorSOx** **constantTermPm10** **sulfurTermPm10** **ashTermPm10** **fuelAshContent** **pollutionControlFactorPM10** **pm25ToPm10Ratio** **fuelCalciumSulfurRatio** **fuelSulfurContent**
used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the boiler/heater category.

element **categoryBoilerHeater/CO_EI**

diagram	**CO_EI** CO emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation CO emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/pollutionControlFactorCO**

diagram	**pollutionControlFactorCO** Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryBoilerHeater/TNMOC_EI**

diagram	**TNMOC_EI** TNMOC emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation TNMOC emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/pollutionControlFactorTNMOC**

diagram	**pollutionControlFactorTNMOC** Percent of total non-methane organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of total non-methane organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryBoilerHeater/VOC_EI**

diagram	**VOC_EI** VOC emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation VOC emissions index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/pollutionControlFactorVOC**

diagram	**pollutionControlFactorVOC** Percent of volatile organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of volatile organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryBoilerHeater/TOC_EI**

diagram	**TOC_EI** Total organic compound emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation Total organic compound emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/pollutionControlFactorTOC**

diagram	**pollutionControlFactorTOC** Percent of total organic compounds removed by pollution control measures. Valid values: 0 to 100.(%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of total organic compounds removed by pollution control measures. Valid values: 0 to 100.(%)

element **categoryBoilerHeater/THC_EI**

diagram	**THC_EI** Total hydrocarbon emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation Total hydrocarbon emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/pollutionControlFactorHC**

diagram	**pollutionControlFactorHC** Percent of hydrocarbons removed by pollution control measures. Valid values: 0 to 100. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of hydrocarbons removed by pollution control measures. Valid values: 0 to 100. (%)

element **categoryBoilerHeater/NOx_EI**

diagram	**NOx_EI** NOx emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation NOx emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/pollutionControlFactorNOx**

diagram	**pollutionControlFactorNOx** Percent of nitrous oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of nitrous oxides removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryBoilerHeater/constantTermSOx**

diagram	**constantTermSOx** SOx emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation SOx emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/sulfurTermSOx**

diagram	**sulfurTermSOx** SOx sulfur EI term, fuel dependent. Valid values: 0 to 1000. (Kg/1000 m^3 - %Sulfur, or Kg/Kiloliter - %Sulfur, or Kg/Metric Ton - %Sulfur)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation

	SOx sulfur EI term, fuel dependent. Valid values: 0 to 1000. (Kg/1000 m^3 - %Sulfur, or Kg/Kiloliter - %Sulfur, or Kg/Metric Ton - %Sulfur)

element **categoryBoilerHeater/pollutionControlFactorSOx**

diagram	**pollutionControlFactorSOx** Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryBoilerHeater/constantTermPm10**

diagram	**constantTermPm10** PM10 emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation PM10 emissions Index, dependent on fuel type. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter or Kg/1000 m^3)

element **categoryBoilerHeater/sulfurTermPm10**

diagram	**sulfurTermPm10** PM10 sulfur EI term, fuel dependent. Valid values: 0 to 1000. (Kg/1000 m^3 - %Sulfur, or Kg/Kiloliter - %Sulfur, or Kg/Metric Ton - %Sulfur)
type	**doubleInclusive1000**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation PM10 sulfur EI term, fuel dependent. Valid values: 0 to 1000. (Kg/1000 m^3 - %Sulfur, or Kg/Kiloliter - %Sulfur, or Kg/Metric Ton - %Sulfur)

element **categoryBoilerHeater/ashTermPm10**

diagram	**ashTermPm10** PM10 ash term. Valid values: 0 to 1000.(Kg/Metric Ton - %Ash)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000

annotation	documentation PM10 ash term. Valid values: 0 to 1000.(Kg/Metric Ton - %Ash)

element **categoryBoilerHeater/fuelAshContent**

diagram	**fuelAshContent** Percent of fuel that is ash. Valid values: 0 to 1000. (%)
type	**doubleExclusive100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Percent of fuel that is ash. Valid values: 0 to 1000. (%)

element **categoryBoilerHeater/pollutionControlFactorPM10**

diagram	**pollutionControlFactorPM10** Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryBoilerHeater/pm25ToPm10Ratio**

diagram	**pm25ToPm10Ratio** PM 2.5 to PM 10 ratio. Valid values: 0 to 1000. (dimensionless)
type	**doubleInclusive1**
properties	content simple default 1
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation PM 2.5 to PM 10 ratio. Valid values: 0 to 1000. (dimensionless)

element **categoryBoilerHeater/fuelCalciumSulfurRatio**

diagram	**fuelCalciumSulfurRatio** Ratio of calcium to sulfur within the fuel. Valid values: 0 to 1000. (dimensionless)
type	**doubleExclusive1000**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation

	Ratio of calcium to sulfur within the fuel. Valid values: 0 to 1000. (dimensionless)

element **categoryBoilerHeater/fuelSulfurContent**

diagram	**fuelSulfurContent** Percent of fuel that is sulfur. Valid values 0 to 1000. (%)
type	**doubleExclusive100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Percent of fuel that is sulfur. Valid values 0 to 1000. (%)

element **categoryDeicingArea**

diagram	
properties	content complex
children	**typeCode** **VOC_EI** **ethyleneGlycolDensity** **propyleneGlycolDensity** **solutionConcentrationPercent**
used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the deicing area category.

element **categoryDeicingArea/typeCode**

diagram	**typeCode** Describes this category.
type	**int1to4**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 4
annotation	documentation Describes this category.

element **categoryDeicingArea/VOC_EI**

diagram	**VOC_EI** VOC emissions index, fuel type dependent. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter)
type	**doubleInclusive1000**

properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation VOC emissions index, fuel type dependent. Valid values: 0 to 1000. (Kg/Metric Ton or Kg/Kiloliter)

element **categoryDeicingArea/ethyleneGlycolDensity**

diagram	**ethyleneGlycolDensity** Ethylene glycol solution density. Valid values: 0 to 1000. (g/L)
type	**doubleExclusive2000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 2000
annotation	documentation Ethylene glycol solution density. Valid values: 0 to 1000. (g/L)

element **categoryDeicingArea/propyleneGlycolDensity**

diagram	**propyleneGlycolDensity** Propylene glycol solution density. Valid values: 0 to 1000. (g/L)
type	**doubleExclusive2000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 2000
annotation	documentation Propylene glycol solution density. Valid values: 0 to 1000. (g/L)

element **categoryDeicingArea/solutionConcentrationPercent**

diagram	**solutionConcentrationPercent** Concentration of deicing solution. Valid values: 0 to 1000. (%)
type	**doubleExclusive100**
properties	content simple default 50
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Concentration of deicing solution. Valid values: 0 to 1000. (%)

element **categoryFuelTank**

diagram	

properties	content complex
children	**typeCode** **tankDiameter** **horizontalTank** **verticalTank** **reidVaporPressure**
used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the fuel tank category.

element **categoryFuelTank/typeCode**

diagram	
type	**int1to25**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 25
annotation	documentation Describes this category.

element **categoryFuelTank/tankDiameter**

diagram	
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Diameter of tank. Valid values: 0 to 1000. (m)

element **categoryFuelTank/horizontalTank**

diagram	
properties	content complex
children	**tankLength**
annotation	documentation Describes a horizontal tank.

element **categoryFuelTank/horizontalTank/tankLength**

diagram	

	tankLength Length of tank. Valid values: 0 to 1000. (m)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Length of tank. Valid values: 0 to 1000. (m)

element **categoryFuelTank/verticalTank**

diagram	
properties	content complex
children	**maximumSolutionLevel** **tankHeight** **averageSolutionLevel** **meanWindSpeed**
annotation	documentation Describes a vertical tank.

element **categoryFuelTank/verticalTank/maximumSolutionLevel**

diagram	**maximumSolutionLevel** Maximum height of solution inside the tank. Valid values: 0 to 1000. (m)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Maximum height of solution inside the tank. Valid values: 0 to 1000. (m)

element **categoryFuelTank/verticalTank/tankHeight**

diagram	**tankHeight** Height of tank. Valid values: 0 to 1000. (m)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Height of tank. Valid values: 0 to 1000. (m)

element **categoryFuelTank/verticalTank/averageSolutionLevel**

diagram	**averageSolutionLevel** Average height of solution inside the tank. Valid values: 0 to 1000. (m)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation Average height of solution inside the tank. Valid values: 0 to 1000. (m)

element **categoryFuelTank/verticalTank/meanWindSpeed**

diagram	**meanWindSpeed** Average wind speed at the tank. Valid values: 0 to 1000. (m/s)
type	**doubleExclusive100**
properties	minOcc 0 maxOcc 1 content simple default 5
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Average wind speed at the tank. Valid values: 0 to 1000. (m/s)

element **categoryFuelTank/reidVaporPressure**

diagram	**reidVaporPressure** Reid vapor pressure. Valid values: 0 to 1000. (PSI)
type	**int6to13**
properties	minOcc 0 maxOcc 1 content simple default 10
facets	Kind Value Annotation minInclusive 6 maxInclusive 13
annotation	documentation Reid vapor pressure. Valid values: 0 to 1000. (PSI)

element **categoryGenerator**

diagram

properties	content complex

children	**typeCode** **powerRatingHorsepower** **CO_EF** **TOC_EF** **NOx_EF** **SOx_EF** **PM10_EF** **pollutionControlFactorTOC** **CO_EI** **VOC_EI** **NOx_EI** **SOx_EI** **PM10_EI** **pollutionControlFactorVOC** **fuelSulfurContent** **pollutionControlFactorCO** **pollutionControlFactorNOx** **pollutionControlFactorSOx** **pollutionControlFactorPM10** **pm25ToPm10Ratio**
used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the generator category.

element **categoryGenerator/typeCode**

diagram	**typeCode** Describes this category.
type	**int1to8**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 8
annotation	documentation Describes this category.

element **categoryGenerator/powerRatingHorsepower**

diagram	**powerRatingHorsepower** The rated power of the generator in horsepower. Valid values: 0 to 10000. (hp)
type	**doubleInclusive10000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 10000
annotation	documentation The rated power of the generator in horsepower. Valid values: 0 to 10000. (hp)

element **categoryGenerator/CO_EF**

diagram	**CO_EF** CO emissions factor. Valid values: 0 to 1000. (grams/hp-hr)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation CO emissions factor. Valid values: 0 to 1000. (grams/hp-hr)

element **categoryGenerator/TOC_EF**

diagram	**TOC_EF** TOC emissions factor. Valid values: 0 to 1000. (grams/hp-hr)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation

	TOC emissions factor. Valid values: 0 to 1000. (grams/hp-hr)

element **categoryGenerator/NOx_EF**

diagram	**NOx_EF** NOx emissions factor. Valid values: 0 to 1000. (grams/hp-hr)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation NOx emissions factor. Valid values: 0 to 1000. (grams/hp-hr)

element **categoryGenerator/SOx_EF**

diagram	**SOx_EF** SOx emissions factor. Valid values: 0 to 1000. (grams/hp-hr)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation SOx emissions factor. Valid values: 0 to 1000. (grams/hp-hr)

element **categoryGenerator/PM10_EF**

diagram	**PM10_EF** PM10 emissions factor. Valid values: 0 to 1000. (grams/hp-hr)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation PM10 emissions factor. Valid values: 0 to 1000. (grams/hp-hr)

element **categoryGenerator/pollutionControlFactorTOC**

diagram	**pollutionControlFactorTOC** Percent of total organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of total organic compounds removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryGenerator/CO_EI**

diagram	CO_EI CO emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation CO emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)

element **categoryGenerator/VOC_EI**

diagram	VOC_EI VOC emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation VOC emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)

element **categoryGenerator/NOx_EI**

diagram	NOx_EI NOx emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation NOx emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)

element **categoryGenerator/SOx_EI**

diagram	SOx_EI SOx emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation SOx emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)

element **categoryGenerator/PM10_EI**

diagram	**PM10_EI** PM10 emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation PM10 emissions index. Valid values: 0 to 1000. (Kg/Kiloliter or Kg/1000 m^3)

element **categoryGenerator/pollutionControlFactorVOC**

diagram	**pollutionControlFactorVOC** Amount of volatile organic compounds emitted. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Amount of volatile organic compounds emitted. Valid values: 0 to 1000. (%)

element **categoryGenerator/fuelSulfurContent**

diagram	**fuelSulfurContent** Percentage, by weight, of sulfur in the fuel used for emissions calculations as % or grains per 100 cu ft of gas vapor (fuel dependent). Valid values: 0 to 1000. (%)
type	**doubleExclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Percentage, by weight, of sulfur in the fuel used for emissions calculations as % or grains per 100 cu ft of gas vapor (fuel dependent). Valid values: 0 to 1000. (%)

element **categoryGenerator/pollutionControlFactorCO**

diagram	**pollutionControlFactorCO** Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryGenerator/pollutionControlFactorNOx**

diagram	**pollutionControlFactorNOx** Percent of nitrous oxides removed by pollution control measures. Valid values 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of nitrous oxides removed by pollution control measures. Valid values 0 to 1000. (%)

element **categoryGenerator/pollutionControlFactorSOx**

diagram	**pollutionControlFactorSOx** Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryGenerator/pollutionControlFactorPM10**

diagram	**pollutionControlFactorPM10** Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryGenerator/pm25ToPm10Ratio**

diagram	**pm25ToPm10Ratio** PM 2.5 to PM 10 ratio. (dimensionless)
type	**doubleInclusive1**
properties	content simple default 1
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation PM 2.5 to PM 10 ratio. (dimensionless)

element **categoryIncinerator**

diagram	

properties	content complex
children	**typeCode** **CO_EI** **VOC_EI** **NOx_EI** **SOx_EI** **PM10_EI** **pollutionControlFactorCO** **pollutionControlFactorVOC** **pollutionControlFactorNOx** **pollutionControlFactorSOx** **pollutionControlFactorPM10** **pm25ToPm10Ratio**
used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the incinerator category.

element **categoryIncinerator/typeCode**

diagram	**typeCode** Describes this category.
type	**int1to2**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 2
annotation	documentation Describes this category.

element **categoryIncinerator/CO_EI**

diagram	CO_EI CO emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation CO emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)

element **categoryIncinerator/VOC_EI**

diagram	VOC_EI VOC emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation VOC emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)

element **categoryIncinerator/NOx_EI**

diagram	NOx_EI NOx emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation NOx emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)

element **categoryIncinerator/SOx_EI**

diagram	SOx_EI SOx emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation SOx emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)

element **categoryIncinerator/PM10_EI**

diagram	

	PM10_EI PM10 emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation PM10 emissions index. Valid values: 0 to 1000. (Kg/Metric Ton)

element **categoryIncinerator/pollutionControlFactorCO**

diagram	**pollutionControlFactorCO** Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryIncinerator/pollutionControlFactorVOC**

diagram	**pollutionControlFactorVOC** Amount of volatile organic compounds emitted (kg/unit). Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Amount of volatile organic compounds emitted (kg/unit). Valid values: 0 to 1000. (%)

element **categoryIncinerator/pollutionControlFactorNOx**

diagram	**pollutionControlFactorNOx** Percent of nitrous oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of nitrous oxides removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryIncinerator/pollutionControlFactorSOx**

diagram	

	pollutionControlFactorSOx Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryIncinerator/pollutionControlFactorPM10**

diagram	**pollutionControlFactorPM10** Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryIncinerator/pm25ToPm10Ratio**

diagram	**pm25ToPm10Ratio** PM2.5 to PM10 ratio. Valid values: 0 to 1000.
type	**doubleInclusive1**
properties	content simple default 1
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation PM2.5 to PM10 ratio. Valid values: 0 to 1000.

element **categoryOther**

diagram	

properties	content complex
children	**fuelUnits** **CO_EI** **THC_EI** **NOx_EI** **SOx_EI** **PM10_EI** **pollutionControlFactorCO** **pollutionControlFactorHC** **pollutionControlFactorNOx** **pollutionControlFactorSOx** **pollutionControlFactorPM10** **pm25ToPm10Ratio**
used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the “other” category.

element **categoryOther/fuelUnits**

diagram	**fuelUnits** Defines fuel units. Also defined in the STN_FUEL_UNITS table in FLEET. Valid values: 0 = Metric Tons, 1=Kiloliters, 2 = 1000s of m3, 3 = Hours, 4 = Test Cyles, 5 = Gallons.
type	**int0to5**

properties	minOcc 0 maxOcc 1 content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 5
annotation	documentation Defines fuel units. Also defined in the STN_FUEL_UNITS table in FLEET. Valid values: 0 = Metric Tons, 1=Kiloliters, 2 = 1000s of m3, 3 = Hours, 4 = Test Cyles, 5 = Gallons.

element **categoryOther/CO_EI**

diagram	CO_EI CO emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation CO emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)

element **categoryOther/THC_EI**

diagram	THC_EI Hydrocarbon emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation Hydrocarbon emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)

element **categoryOther/NOx_EI**

diagram	NOx_EI NOx emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation NOx emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)

element **categoryOther/SOx_EI**

diagram	SOx_EI SOx emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)
type	**doubleInclusive1000**
properties	content simple

	default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation SOx emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)

element **categoryOther/PM10_EI**

diagram	**PM10_EI** PM10 emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation PM10 emissions index per unit of fuel. Valid values: 0 to 1000. (kg/unit)

element **categoryOther/pollutionControlFactorCO**

diagram	**pollutionControlFactorCO** Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of carbon monoxide removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryOther/pollutionControlFactorHC**

diagram	**pollutionControlFactorHC** Percent of hydrocarbons removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of hydrocarbons removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryOther/pollutionControlFactorNOx**

diagram	**pollutionControlFactorNOx** Percent of nitrous oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation

	minInclusive 0 maxInclusive 100
annotation	documentation Percent of nitrous oxides removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryOther/pollutionControlFactorSOx**

diagram	**pollutionControlFactorSOx** Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of sulfur oxides removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryOther/pollutionControlFactorPM10**

diagram	**pollutionControlFactorPM10** Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percent of 10-micron particulate matter removed by pollution control measures. Valid values: 0 to 1000. (%)

element **categoryOther/pm25ToPm10Ratio**

diagram	**pm25ToPm10Ratio** PM2.5 to PM10 Ratio. Valid values: 0 to 1000.
type	**doubleInclusive1**
properties	content simple default 1
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation PM2.5 to PM10 Ratio. Valid values: 0 to 1000.

element **categoryRecordCode**

diagram	**categoryRecordCode** — **recordCode** An integer value for a category to use as the basis of a new stationary source operation. This value comes from the CATEGORY_REC_ID column in the STN_CATEGORY table in the AEDT FLEET database. An integer value for a category to use as the basis of a new stationary source operation. This value comes from the CATEGORY_REC_ID column in the STN_CATEGORY table in the AEDT FLEET database. Valid values: 0 to 87, 89 to 148.
properties	content complex
children	**recordCode**

used by	element **stationarySource**
annotation	documentation An integer value for a category to use as the basis of a new stationary source operation. This value comes from the CATEGORY_REC_ID column in the STN_CATEGORY table in the AEDT FLEET database.

element **categorySandSaltPile**

diagram	
properties	content complex
children	**typeCode** **surfaceWindSpeedFraction** **surfaceRoughness** **frictionVelocity** **fastestMileOfWind** **meanWindSpeed** **moistureContent** **massDisturbedPerDisturbance** **erodedSurfaceArea**
used by	element **stationarySource**
annotation	documentation Describes the emissions characteristics of a source in the sand or salt pile category.

element **categorySandSaltPile/typeCode**

diagram	
type	**int1to5**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 5
annotation	documentation Describes this category.

element **categorySandSaltPile/surfaceWindSpeedFraction**

diagram	
type	**doubleInclusive1**

properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation Surface wind speed fraction. Valid values: 0 to 1000. (unitless)

element **categorySandSaltPile/surfaceRoughness**

diagram	**surfaceRoughness** The surface roughness of the pile. Valid values: 0 to 1000. (cm)
type	**doubleExclusiveRange100**
properties	content simple default 0.01
facets	Kind Value Annotation minExclusive 0 maxExclusive 100
annotation	documentation The surface roughness of the pile. Valid values: 0 to 1000. (cm)

element **categorySandSaltPile/frictionVelocity**

diagram	**frictionVelocity** Friction velocity. Valid values: 0 to 1000. (m/s)
type	**doubleExclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Friction velocity. Valid values: 0 to 1000. (m/s)

element **categorySandSaltPile/fastestMileOfWind**

diagram	**fastestMileOfWind** Fastest mile of wind. Valid values: 0 to 1000. (m/s)
type	**doubleExclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Fastest mile of wind. Valid values: 0 to 1000. (m/s)

element **categorySandSaltPile/meanWindSpeed**

diagram	**meanWindSpeed** Average wind speed at sand or salt pile. Valid values: 0 to 1000. (m/s)
type	**doubleExclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0

	maxExclusive 100
annotation	documentation Average wind speed at sand or salt pile. Valid values: 0 to 1000. (m/s)

element **categorySandSaltPile/moistureContent**

diagram	**moistureContent** Percentage of sand or salt pile that is moisture. Valid values: 0 to 1000. (%)
type	**doubleExclusiveRange100**
properties	content simple default 0.01
facets	Kind Value Annotation minExclusive 0 maxExclusive 100
annotation	documentation Percentage of sand or salt pile that is moisture. Valid values: 0 to 1000. (%)

element **categorySandSaltPile/massDisturbedPerDisturbance**

diagram	**massDisturbedPerDisturbance** The mass disturbed per disturbance. Valid values: 0 to 1000. (Metric Tons)
type	**doubleExclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation The mass disturbed per disturbance. Valid values: 0 to 1000. (Metric Tons)

element **categorySandSaltPile/erodedSurfaceArea**

diagram	**erodedSurfaceArea** Eroded surface area of pile. Valid values: 0 to 1000. (meters^2)
type	**doubleExclusive10000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 10000
annotation	documentation Eroded surface area of pile. Valid values: 0 to 1000. (meters^2)

element **categorySolventDegreaser**

diagram	**categorySolventDegreaser** Describes the operational characteristics of a source in the solvent degreaser category. **typeCode** Describes this category. **solutionDensity** Density of the deicing solution. Valid values: 0 to 1000. (g/L) **percentSolventDisposed** Percentage of solvent removed by environmental controls. Valid values: 0 to 1000. (%)
properties	content complex
children	**typeCode** **solutionDensity** **percentSolventDisposed**

used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the solvent degreaser category.

element **categorySolventDegreaser/typeCode**

diagram	**typeCode** Describes this category.
type	**int1to13**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 13
annotation	documentation Describes this category.

element **categorySolventDegreaser/solutionDensity**

diagram	**solutionDensity** Density of the deicing solution. Valid values: 0 to 1000. (g/L)
type	**doubleExclusive2000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxExclusive 2000
annotation	documentation Density of the deicing solution. Valid values: 0 to 1000. (g/L)

element **categorySolventDegreaser/percentSolventDisposed**

diagram	**percentSolventDisposed** Percentage of solvent removed by environmental controls. Valid values: 0 to 1000. (%)
type	**xs:double**
properties	content simple default 0
annotation	documentation Percentage of solvent removed by environmental controls. Valid values: 0 to 1000. (%)

element **categorySurfaceCoatingPainting**

diagram	
properties	content complex
children	**typeCode** **VOC_EI** **pollutionControlFactorVOC**
used by	element **stationarySource**
annotation	documentation Describes the operational characteristics of a source in the surface coating or painting category.

element **categorySurfaceCoatingPainting/typeCode**

diagram	**typeCode** Describes this category.
type	**int1to8**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 8
annotation	documentation Describes this category.

element **categorySurfaceCoatingPainting/VOC_EI**

diagram	**VOC_EI** VOC emissions index. Valid values: 0 to 1000. (kg/kiloliter)
type	**doubleInclusive1000**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation VOC emissions index. Valid values: 0 to 1000. (kg/kiloliter)

element **categorySurfaceCoatingPainting/pollutionControlFactorVOC**

diagram	**pollutionControlFactorVOC** Percentage of volatile organic compounds removed by environmental controls. Valid values: 0 to 1000. (%)
type	**doubleInclusive100**
properties	content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percentage of volatile organic compounds removed by environmental controls. Valid values: 0 to 1000. (%)

element **categoryTrainingFire**

diagram	

properties	content complex
children	**typeCode CO VOC NOx SOx PM10**
used by	element **stationarySource**
annotation	documentation Supports legacy EDMS studies relating to content contained in the TRAINING_FIRES table. This element supports the definition of training fires for scenario layouts. Training fire data are used in both emissions and dispersion analyses.

element **categoryTrainingFire/typeCode**

diagram	
type	**int1to5**
properties	content simple
facets	Kind Value Annotation minInclusive 1 maxInclusive 5
annotation	documentation Describes this category.

element **categoryTrainingFire/CO**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Amount of carbon monoxide emitted. Valid values: 0 to 3000. (g/gal)

element **categoryTrainingFire/VOC**

diagram	
type	**xs:double**
properties	content simple

annotation	documentation Amount of volatile organic compounds emitted. Valid values: 0 to 100. (g/gal)

element **categoryTrainingFire/NOx**

diagram	NOx Amount of nitrous oxides emitted. Valid values: 0 to 100. (g/gal)
type	**xs:double**
properties	content simple
annotation	documentation Amount of nitrous oxides emitted. Valid values: 0 to 100. (g/gal)

element **categoryTrainingFire/SOx**

diagram	SOx Amount of sulfur oxides emitted. Valid values: 0 to 10. (g/gal)
type	**xs:double**
properties	content simple
annotation	documentation Amount of sulfur oxides emitted. Valid values: 0 to 10. (g/gal)

element **categoryTrainingFire/PM10**

diagram	PM10 Amount of 10-micron particulate matter emitted. Valid values: 0 to 1000. (g/gal)
type	**xs:double**
properties	content simple
annotation	documentation Amount of 10-micron particulate matter emitted. Valid values: 0 to 1000. (g/gal)

element **centroid**

diagram	

properties	content complex
children	**stateFips countyFips blockId bnaId latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone elevation count**
used by	group **receptorGroup**
annotation	documentation Describes the geometric center of a polygon.

element **centroid/stateFips**

diagram	
type	**xs:int**
properties	content simple
annotation	documentation Optional census state identifier.

element **centroid/countyFips**

diagram	**countyFips** Optional census county identifier.
type	**xs:int**
properties	content simple
annotation	documentation Optional census county identifier.

element **centroid/blockId**

diagram	**blockId** Optional census BLOCK ID.
type	**xs:int**
properties	content simple
annotation	documentation Optional census BLOCK ID.

element **centroid/bnaId**

diagram	**bnaId** Optional census BNA ID.
type	**string6**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 6
annotation	documentation Optional census BNA ID.

element **centroid/elevation**

diagram	**elevation** The centroid's elevation above MSL (ft) if terrain not used. If not specified, AEDT will use elevation of operation airport.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The centroid's elevation above MSL (ft) if terrain not used. If not specified, AEDT will use elevation of operation airport.

element **centroid/count**

diagram	**count** The population count of the centroid. Valid values: 0 to 999999.
type	**xs:int**
properties	content simple
annotation	documentation The population count of the centroid. Valid values: 0 to 999999.

element **climate**

diagram	

properties	content complex
children	**identifier** **temperature** **pressure** **humidity** **headWind** **seaLevelPressure** **dewPoint** **windDirection** **visibility**
used by	element **study**
annotation	documentation Characterizes the climate during the study.

element **climate/identifier**

diagram	
type	**string8**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation Identifier of the climate condition.

element **climate/temperature**

diagram	
type	**xs:float**
properties	content simple
annotation	documentation Temperature in the climate condition. (°F)

element **climate/pressure**

diagram	

type	**xs:float**
properties	content simple
annotation	documentation Atmospheric pressure in the climate condition. (in Hg)

element **climate/humidity**

diagram	**humidity** Humidity in the climate condition. (%)
type	**xs:double**
properties	content simple
annotation	documentation Humidity in the climate condition. (%)

element **climate/headWind**

diagram	**headWind** Velocity of headwind. (knots)
type	**xs:float**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Velocity of headwind. (knots)

element **climate/seaLevelPressure**

diagram	**seaLevelPressure** Atmospheric pressure at sea level. (in Hg)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Atmospheric pressure at sea level. (in Hg)

element **climate/dewPoint**

diagram	**dewPoint** Dew point in the climate condition. (°F)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Dew point in the climate condition. (°F)

element **climate/windDirection**

diagram	**windDirection** Wind direction. Valid values: 0-360. (decimal degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple

annotation	documentation Wind direction. Valid values: 0-360. (decimal degrees)

element **climate/visibility**

diagram	**visibility** Visibility in the climate condition. (mi)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Visibility in the climate condition. (mi)

element **dailyProfile**

diagram

properties	content complex
children	**profileName** **temporalFactorSunday** **temporalFactorMonday** **temporalFactorTuesday** **temporalFactorWednesday** **temporalFactorThursday** **temporalFactorFriday** **temporalFactorSaturday**
used by	element **dailyProfileSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the DAILY_PROFILES. This element supports the definition of temporal factors on a daily operational basis.

element **dailyProfile/profileName**

diagram	**profileName** Name of profile.
type	**string100**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 100

annotation	documentation Name of profile.

element **dailyProfile/temporalFactorSunday**

diagram	**temporalFactorSunday** Factor applied to activity for operations on Sundays. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations on Sundays. Valid values: 0.0000 to 1.0000.

element **dailyProfile/temporalFactorMonday**

diagram	**temporalFactorMonday** Factor applied to activity for operations on Mondays. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations on Mondays. Valid values: 0.0000 to 1.0000.

element **dailyProfile/temporalFactorTuesday**

diagram	**temporalFactorTuesday** Factor applied to activity for operations on Tuesdays. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations on Tuesdays. Valid values: 0.0000 to 1.0000.

element **dailyProfile/temporalFactorWednesday**

diagram	**temporalFactorWednesday** Factor applied to activity for operations on Wednesdays. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations on Wednesdays. Valid values: 0.0000 to 1.0000.

element **dailyProfile/temporalFactorThursday**

diagram	**temporalFactorThursday** Factor applied to activity for operations on Thursdays. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations on Thursdays. Valid values: 0.0000 to 1.0000.

element **dailyProfile/temporalFactorFriday**

diagram	**temporalFactorFriday** Factor applied to activity for operations on Fridays. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations on Fridays. Valid values: 0.0000 to 1.0000.

element **dailyProfile/temporalFactorSaturday**

diagram	**temporalFactorSaturday** Factor applied to activity for operations on Saturdays. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations on Saturdays. Valid values: 0.0000 to 1.0000.

element **dailyProfileSet**

diagram	
properties	content complex
children	**dailyProfile**
used by	element **operationalProfileSet** complexType **airportLayoutType**

attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports the definition and use of DAILY_PROFILES for the daily variation of operations.

attribute **dailyProfileSet/@dummy**

type	**xs:int**
properties	use optional

element **dispersionWeight**

diagram	
properties	content complex
children	**dispersionWeight1** **dispersionWeight3** **dispersionWeight5** **dispersionWeight7** **dispersionWeight9**
used by	element **backbone**
annotation	documentation Dispersion weights associated with the subtracks for this backbone. Subtracks are numbered in increasing order from the backbone outward. The allowable number of subtracks for a backbone are 1, 3, 5, 7 and 9. Valid dispersion weight values are greater than one and less than or equal to 1. The sum of the dispersion weights for this backbone must equal 1.

element **dispersionWeight/dispersionWeight1**

diagram	
type	**dispersionWeight1Type**
properties	content complex
children	**backbone**

element **dispersionWeight/dispersionWeight3**

diagram	
type	**dispersionWeight3Type**
properties	content complex
children	**backbone** **weightl1** **weightr1**

element **dispersionWeight/dispersionWeight5**

diagram	
type	**dispersionWeight5Type**
properties	content complex
children	**backbone** **weightl1** **weightr1** **weightl2** **weightr2**

element **dispersionWeight/dispersionWeight7**

diagram	
type	**dispersionWeight7Type**
properties	content complex
children	**backbone** **weightl1** **weightr1** **weightl2** **weightr2** **weightl3** **weightr3**

element **dispersionWeight/dispersionWeight9**

diagram	

type	**dispersionWeight9Type**
properties	content complex
children	**backbone** **weightl1** **weightr1** **weightl2** **weightr2** **weightl3** **weightr3** **weightl4** **weightr4**

element **emissionsUsage**

diagram	
properties	content complex
children	**yearlyValue** **hourlyValue** **byPeakQuarterHour** **activityProfile**
used by	elements **parkingFacilityOperation** **roadwayOperation** **stationarySourceOperation**
annotation	documentation Describes the amount of emissions for a given activity profile.

element **emissionsUsage/yearlyValue**

diagram	

	yearlyValue Annualized amount of emissions.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Annualized amount of emissions.

element **emissionsUsage/hourlyValue**

diagram	**hourlyValue** Hourly amount of emissions.
type	**xs:double**
properties	content simple
annotation	documentation Hourly amount of emissions.

element **emissionsUsage/byPeakQuarterHour**

diagram	**byPeakQuarterHour** Indicates if the hourly value is the peak hourly value.
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Indicates if the hourly value is the peak hourly value.

element **emissionsUsage/activityProfile**

diagram	**activityProfile** An activity profile type (e.g. reference to one of hourlyProfile, dailyProfile or weeklyProfile).
type	**string40**
properties	minOcc 0 maxOcc 1 content simple
used by	element **activityProfileSet**
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation An activity profile type (e.g. reference to one of hourlyProfile, dailyProfile or weeklyProfile).

element **engineModeEmissionFactors**

diagram	

properties	content complex
children	**time fuel CO HC NOx PM SN**
annotation	documentation Supports legacy EDMS studies relating to content contained in the USER_CREATED_AIRCRAFT table. This element supports the definition of custom emission factor elements.

element **engineModeEmissionFactors/time**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Time engine operates in a given mode. Valid values: nonnegative. (minutes)

element **engineModeEmissionFactors/fuel**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Rate of fuel burn in given mode. Valid values: nonnegative. (kg/s)

element **engineModeEmissionFactors/CO**

diagram	

type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of carbon monoxide emitted. Valid values: nonnegative. (kg/s)

element **engineModeEmissionFactors/HC**

diagram	HC Amount of hydrocarbons emitted. Valid values: nonnegative. (kg/s)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of hydrocarbons emitted. Valid values: nonnegative. (kg/s)

element **engineModeEmissionFactors/NOx**

diagram	NOx Amount of nitrous oxide emitted. Valid values: nonnegative. (kg/s)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of nitrous oxide emitted. Valid values: nonnegative. (kg/s)

element **engineModeEmissionFactors/PM**

diagram	PM Amount of particulate matter emitted. Valid values: nonnegative. (kg/s)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of particulate matter emitted. Valid values: nonnegative. (kg/s)

element **engineModeEmissionFactors/SN**

diagram	SN Smoke number for the engine mode. Valid values: nonnegative. (kg/s)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Smoke number for the engine mode. Valid values: nonnegative. (kg/s)

element **gate**

diagram	
properties	content complex
children	**name** **elevation** **releaseHeight** **sigmaY** **sigmaZ** **pointCoord** **polygonCoords**
used by	element **gateSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the GATES table. This element supports the definition of gates within an airport layout. In dispersion analyses, GSE, AGE, and APU emissions originate from the gate locations. Gates are needed for sequence modeling, which includes all dispersion analyses.

element **gate/name**

diagram	
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Identifying name of gate.

element **gate/elevation**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation

	Gate's elevation above mean sea level in meters. Valid values: -500 to 5000. (m)

element **gate/releaseHeight**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Height above ground level at which emissions are released into the atmosphere. Valid values: Variable, by airport. (m)

element **gate/sigmaY**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Horizontal dispersion parameter. For additional information, see the EDMS Application Manual. Valid values: Variable, by airport. (m)

element **gate/sigmaZ**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Vertical dispersion parameter. For additional information, see the EDMS Application Manual. Valid values: Variable, by airport. (m)

element **gateSet**

diagram	
properties	content complex
children	**gate**
used by	complexType **airportLayoutType**
annotation	documentation Supports legacy EDMS studies relating to content contained in the GATES table. This element supports the definition of gates within an airport layout. In dispersion analyses, GSE,

	AGE, and APU emissions originate from the gate locations. Gates are needed for sequence modeling, which includes all dispersion analyses.

element **grid**

diagram

	xrOffset The X-offset of the receptor grid in nautical miles. **ydOffset** The Y-offset of the receptor grid in nautical miles.
properties	content complex
children	**dynamic latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone elevation receptorHeight width height numWidth numHeight xrOffset ydOffset**
used by	group **receptorGroup**
annotation	documentation Describes a grid of points.

element **grid/dynamic**

diagram	**dynamic** Marks the grid as either a dynamic grid or a receptor grid.
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Marks the grid as either a dynamic grid or a receptor grid.

element **grid/elevation**

diagram	**elevation** The grid's elevation above MSL (ft) if terrain not used. If not specified, AEDT will use elevation of operation airport.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The grid's elevation above MSL (ft) if terrain not used. If not specified, AEDT will use elevation of operation airport.

element **grid/receptorHeight**

diagram	**receptorHeight** The height of the receptor above ground. (m)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The height of the receptor above ground. (m)

element **grid/width**

diagram	**width** Width of the grid. (nmi).
type	**xs:double**
properties	content simple
annotation	documentation Width of the grid. (nmi).

element **grid/height**

diagram	**height** Height of the grid (nmi).
type	**xs:double**
properties	content simple
annotation	documentation Height of the grid (nmi).

element **grid/numWidth**

diagram	**numWidth** Number of points to spread across the width of the grid. The total number of points in the grid is numWidth × numHeight. Points will be located along width of grid using the formula i × (width÷numWidth) where i is the index of the point (0 … numWidth − 1). Valid values: 1 to 999.
type	**xs:int**
properties	content simple
annotation	documentation Number of points to spread across the width of the grid. The total number of points in the grid is numWidth × numHeight. Points will be located along width of grid using the formula i × (width÷numWidth) where i is the index of the point (0 … numWidth − 1). Valid values: 1 to 999.

element **grid/numHeight**

diagram	**numHeight** Number of points to spread across the height of the grid. The total number of points in the grid is numWidth × numHeight. Points will be located along height of grid using the formula: i × (width÷numHeight) where i is the index of the point (0 … numHeight − 1). Valid values: 1 to 999.
type	**xs:int**
properties	content simple
annotation	documentation Number of points to spread across the height of the grid. The total number of points in the grid is numWidth × numHeight. Points will be located along height of grid using the formula: i × (width÷numHeight) where i is the index of the point (0 … numHeight − 1). Valid values: 1 to 999.

element **grid/xrOffset**

diagram	**xrOffset** The X-offset of the receptor grid in nautical miles.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation The X-offset of the receptor grid in nautical miles.

element **grid/ydOffset**

diagram	**ydOffset** The Y-offset of the receptor grid in nautical miles.

type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation The Y-offset of the receptor grid in nautical miles.

element **groundSupportEquipmentGateAssignment**

diagram	
properties	content complex
children	**gate** **fractionAssigned**
used by	element **groundSupportEquipmentGateAssignmentSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the USER_CREATED_GSE table. This element supports the definition of user defined ground support equipment.

element **groundSupportEquipmentGateAssignment/gate**

diagram	
type	**string20**
properties	content simple
used by	element **gateSet**
facets	Kind Value Annotation minLength 0 maxLength 20
annotation	documentation Gate to which GSE is assigned.

element **groundSupportEquipmentGateAssignment/fractionAssigned**

diagram	
type	**doubleInclusive1**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation Fraction of GSE assigned to this gate. Must sum to 1.0 for all gate assignments for the GSE. Valid values: 0.0 to 1.0.

element **groundSupportEquipmentGateAssignmentSet**

diagram	

properties	content complex
children	**groundSupportEquipmentGateAssignment**
used by	element **groundSupportEquipmentPopulationOperation**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the GSE_POPULATION_GATE_ASSIGNMENTS table. This element supports the definition of gate to ground support equipment assignments.

attribute **groundSupportEquipmentGateAssignmentSet/@dummy**

type	**xs:int**
properties	use optional

element **groundSupportEquipmentLTOOperation**

diagram

properties	content complex
children	**gseID fuelType horsepower loadFactor manufactureYear departureOpTime arrivalOpTime**
used by	element **groundSupportEquipmentLTOOperationSet**
annotation	documentation Describes operation of GSE operation.

element **groundSupportEquipmentLTOOperation/gseID**

diagram

type	**xs:int**

properties	content simple
annotation	documentation The GSE ID.

element **groundSupportEquipmentLTOOperation/fuelType**

diagram	fuelType
type	**fuelType**
properties	content simple
facets	Kind Value Annotation pattern G|Gasoline|D|Diesel|C|Compressed Natural Gas|L|Liquefied Petroleum Gas|E|Electric

element **groundSupportEquipmentLTOOperation/horsepower**

diagram	horsepower GSE horsepower in bore hp. Valid values: 0.00 to 10000.00. (hp)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation GSE horsepower in bore hp. Valid values: 0.00 to 10000.00. (hp)

element **groundSupportEquipmentLTOOperation/loadFactor**

diagram	loadFactor Load factor of GSE (will be empty for APU). Valid values: 0.00 to 100.00.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Load factor of GSE (will be empty for APU). Valid values: 0.00 to 100.00.

element **groundSupportEquipmentLTOOperation/manufactureYear**

diagram	manufactureYear The manufacture year and age of the equipment, if not using system defaults. Valid values: 1940 to 2050. (Latest valid year will the year of the study.)
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The manufacture year and age of the equipment, if not using system defaults. Valid values: 1940 to 2050. (Latest valid year will the year of the study.)

element **groundSupportEquipmentLTOOperation/departureOpTime**

diagram	departureOpTime The number of minutes used for a departure aircraft operation. Valid values: 0.00 to 480.00. (min)
type	**xs:double**
properties	minOcc 0 maxOcc 1

	content simple
annotation	documentation The number of minutes used for a departure aircraft operation. Valid values: 0.00 to 480.00. (min)

element **groundSupportEquipmentLTOOperation/arrivalOpTime**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The number of minutes used for an arrival aircraft operation. Valid values: 0.00 to 480.00. (min)

element **groundSupportEquipmentLTOOperationSet**

diagram	
properties	content complex
children	**groundSupportEquipmentLTOOperation**
used by	complexType **aircraftType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the GSE_POPULATION table. This element supports the definition of user defined ground support equipment in operational usage.

attribute **groundSupportEquipmentLTOOperationSet/@dummy**

type	**xs:int**
properties	use optional

element **groundSupportEquipmentPopulationOperation**

diagram	

properties	content complex
children	**gseID** **fuelType** **gseType** **numUnits** **annualOpTime** **pkQtrHourOpTime** **activityProfile** **horsepower** **loadFactor** **useNonRoad** **manufactureYear** **groundSupportEquipmentGateAssignmentSet**
used by	element **groundSupportEquipmentPopulationOperationSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the GSE_POPULATION table. This element supports the definition of user defined ground support equipment in operational usage.

element **groundSupportEquipmentPopulationOperation/gseID**

diagram	**gseID** The GSE ID.
type	**xs:int**
properties	content simple
annotation	documentation The GSE ID.

element **groundSupportEquipmentPopulationOperation/fuelType**

diagram	**fuelType**
type	**fuelType**

properties	content simple
facets	Kind Value Annotation pattern G|Gasoline|D|Diesel|C|Compressed Natural Gas|L|Liquefied Petroleum Gas|E|Electric

element **groundSupportEquipmentPopulationOperation/gseType**

diagram	**gseType** The type of GSE.
type	**xs:string**
properties	content simple
annotation	documentation The type of GSE.

element **groundSupportEquipmentPopulationOperation/numUnits**

diagram	**numUnits** GSE number of units. Valid values: 0 to 10000.
type	**xs:double**
properties	content simple
annotation	documentation GSE number of units. Valid values: 0 to 10000.

element **groundSupportEquipmentPopulationOperation/annualOpTime**

diagram	**annualOpTime** Operation time, yearly. Valid values: 0 to 8784. (hr)
type	**xs:double**
properties	content simple
annotation	documentation Operation time, yearly. Valid values: 0 to 8784. (hr)

element **groundSupportEquipmentPopulationOperation/pkQtrHourOpTime**

diagram	**pkQtrHourOpTime** Peak quarter hour operation time. Valid values: 0 to 15. (min/hr)
type	**xs:double**
properties	content simple
annotation	documentation Peak quarter hour operation time. Valid values: 0 to 15. (min/hr)

element **groundSupportEquipmentPopulationOperation/activityProfile**

diagram	**activityProfile** Activity profile; (quarterly, daily, monthly).
type	**string40**
properties	content simple
used by	element **activityProfileSet**
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Activity profile; (quarterly, daily, monthly).

element **groundSupportEquipmentPopulationOperation/horsepower**

diagram	**horsepower** Horsepower is in hp units. Valid values: 0 to 10000. (hp)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Horsepower is in hp units. Valid values: 0 to 10000. (hp)

element **groundSupportEquipmentPopulationOperation/loadFactor**

diagram	**loadFactor** Load factor of GSE. (Will be empty for APU.) Valid values: 0 to 100.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Load factor of GSE. (Will be empty for APU.) Valid values: 0 to 100.

element **groundSupportEquipmentPopulationOperation/useNonRoad**

diagram	**useNonRoad** User non-road version flag.
type	**xs:boolean**
properties	content simple
annotation	documentation User non-road version flag.

element **groundSupportEquipmentPopulationOperation/manufactureYear**

diagram	**manufactureYear** The manufacture year and age of the equipment, if not using system defaults. Valid values: 1940 to 2050. (Latest valid date will be the year of the study.)
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The manufacture year and age of the equipment, if not using system defaults. Valid values: 1940 to 2050. (Latest valid date will be the year of the study.)

element **groundSupportEquipmentPopulationOperationSet**

diagram	
properties	content complex
children	**groundSupportEquipmentPopulationOperation**
used by	group **airportActivityGroup**

attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the GSE_POPULATION table. This element supports the definition of user defined ground support equipment in operational usage.

attribute **groundSupportEquipmentPopulationOperationSet/@dummy**

type	**xs:int**
properties	use optional

element **monthlyProfile**

diagram

properties	content complex
children	**profileName** **temporalFactorJanuary** **temporalFactorFebruary** **temporalFactorMarch** **temporalFactorApril** **temporalFactorMay** **temporalFactorJune** **temporalFactorJuly** **temporalFactorAugust** **temporalFactorSeptember** **temporalFactorOctober** **temporalFactorNovember** **temporalFactorDecember**

used by	element **monthlyProfileSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the MONTHLY_PROFILES. This element supports the definition of temporal factors on a monthly operational basis.

element **monthlyProfile/profileName**

diagram	**profileName** Name of profile.
type	**string100**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Name of profile.

element **monthlyProfile/temporalFactorJanuary**

diagram	**temporalFactorJanuary** Factor applied to activity for operations during January. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during January. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorFebruary**

diagram	**temporalFactorFebruary** Factor applied to activity for operations during February. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during February. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorMarch**

diagram	**temporalFactorMarch** Factor applied to activity for operations during March. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during March. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorApril**

diagram	**temporalFactorApril** Factor applied to activity for operations during April. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during April. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorMay**

diagram	**temporalFactorMay** Factor applied to activity for operations during May. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during May. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorJune**

diagram	**temporalFactorJune** Factor applied to activity for operations during June. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during June. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorJuly**

diagram	**temporalFactorJuly** Factor applied to activity for operations during July.Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during July.Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorAugust**

diagram	

	temporalFactorAugust Factor applied to activity for operations during August. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during August. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorSeptember**

diagram	**temporalFactorSeptember** Factor applied to activity for operations during September. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during September. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorOctober**

diagram	**temporalFactorOctober** Factor applied to activity for operations during October. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during October. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorNovember**

diagram	**temporalFactorNovember** Factor applied to activity for operations during November. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during November. Valid values: 0.0000 to 1.0000.

element **monthlyProfile/temporalFactorDecember**

diagram	

	temporalFactorDecember Factor applied to activity for operations during December. Valid values: 0.0000 to 1.0000.
type	**doubleMin0**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0
annotation	documentation Factor applied to activity for operations during December. Valid values: 0.0000 to 1.0000.

element **monthlyProfileSet**

diagram	
properties	content complex
children	**monthlyProfile**
used by	element **operationalProfileSet** complexType **airportLayoutType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports the definition and use of MONTHLY_PROFILES for the monthly variation of operations.

attribute **monthlyProfileSet/@dummy**

type	**xs:int**
properties	use optional

element **operation**

diagram	

suggested approach is to just set the UserID field to unique number or set of characters. This will allow the user to distinguish the AirOperations if the need ever arises. Nevertheless, one can leave all the id fields empty or non-unique set of ids; however, in doing so, the user will be forced to use other identifying fields of the AirOperation if they should ever want to distinguish between AirOperations.

aircraftType

Type of aircraft in the flight.

cruiseAltitude

Override aircraft cruise altitude MSL for this operation. UNITS: feet.

numOperations

Number of operations comprising this operation.

opType

carrier

Carrier flying the flight. Not fully supported in AEDT.

flightNumber

Flight number. Not fully supported in AEDT.

tailNumber

Flight's tail number. Not fully supported in AEDT.

userType

User-defined aircraft type. Cannot be an aircraftType. Not fully supported in AEDT.

userParam

User-defined parameter associated with the operation. Not fully supported in AEDT.

departureAirport

Departure airport's ICAO code. Required if the operation is used with a <flight> or <operation> element. Also required if used with a <trackOpSet> modeling departures, circuits, runups, or touch-and-goes.

departureRunway

Airport's departure runway ID. Required if the operation is used with a <flight> or a <trackOpSet> modeling departures, circuits, runups, or touch-and-goes.

departureGate

Airport's departure gate. Not fully supported in AEDT.

departureApuTime

Number of minutes the auxiliary power unit is attached to a departing aircraft. (min)

arrivalAirport

Arrival airport's ICAO code. Required if the operation is used with a <flight> or <operation> element. Also required if used with a <trackOpSet> modeling arrivals, circuits, runups, or touch-and-goes.

arrivalRunway

Airport's arrival runway ID.

operation
Describes an aircraft flight operation.
Required if the operation is used with a <flight> or a <trackOpSet> modeling arrivals, circuits, runups, or touch-and-goes.
arrivalGate
Airport's arrival gate. Not fully supported in AEDT.
arrivalApuTime
Number of minutes the auxiliary power unit is attached to an arrival aircraft. (min)
offTime
Wheels-off time. Required for any departure or runup, circuit, runup, or touch-and-go operation.
onTime
Wheels on time. Required for any arrival operation.
enrouteStartTime
Time aircraft reaches the first en route node. Required for en route or overflight flights. Not fully supported in AEDT
outTime
Time aircraft pushed back from the gate for a departure. When present, taxiOutDuration = (offTime − outTime). Not fully supported in AEDT.
taxiOutDuration
Number of seconds during taxi-out. Required for emissions modeling, optional for noise modeling. Not fully supported in AEDT. (s)
inTime
Time aircraft arrives at arrival gate. When present, taxiInDuration = (onTime – inTime).
taxiInDuration
Number of seconds during taxi-in. Required for emissions modeling, optional for noise modeling. (s)
activityProfile
References an existing hourly, daily, or monthly profile.
saeProfile
Overrides default profile assignment for a flight's arrival and departure phases using characteristics specified by SAE International. Applicable when the override is unambiguously arrival or departure.
saeProfiles
Overrides default profile assignment for a flight's arrival and departure phases using characteristics specified by SAE International. Applicable when it is necessary to specify both the arrival and departure profiles.
badaProfile
Overrides default profile assignment for a flight's arrival and departure phases using characteristics specified by BADA. Applicable when the override is unambiguously arrival or departure.
badaProfiles

properties	content complex
children	**id** **aircraftType** **cruiseAltitude** **numOperations** **opType** **carrier** **flightNumber** **tailNumber** **userType** **userParam** **departureAirport** **departureRunway** **departureGate** **departureApuTime** **arrivalAirport** **arrivalRunway** **arrivalGate** **arrivalApuTime** **offTime** **onTime** **enrouteStartTime** **outTime** **taxiOutDuration** **inTime** **taxiInDuration** **activityProfile** **saeProfile** **saeProfiles** **badaProfile** **badaProfiles** **stageLength** **actypeWeight** **departureStageLength** **arrivalStageLength** **glideSlope** **fuelSulfurContent**
used by	elements **AsifXml** **case** **operations**
annotation	documentation Describes an aircraft flight operation.

element **operation/id**

diagram	

	id User specified identifier for the operation. One purpose served by this field is to allow the user to tie the AEDT AirOperations back to some original data source by setting the id field to an identifying identifier from the original data source. Another purpose is to set each ID to a project-specific value for each AirOperation. The ID field is used in several AEDT lists and reports that print out the AirOperations. In addition, the Impact Evaluation dialog uses the ID as its main method of distinguishing AirOperations when allowing the user to pick and choose operations to be moved to alternative flight tracks. If, however, the user has no outside data sources that need to be tied to the AEDT AirOperations, or if each AirOperation is identical in the sense that no specific AirOperation is more valuable than another or that there will be no intent to distinguish one AirOperation over another, then the suggested approach is to just set the UserID field to unique number or set of characters. This will allow the user to distinguish the AirOperations if the need ever arises. Nevertheless, one can leave all the id fields empty or non-unique set of ids; however, in doing so, the user will be forced to use other identifying fields of the AirOperation if they should ever want to distinguish between AirOperations.
type	**string16**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation User specified identifier for the operation. One purpose served by this field is to allow the user to tie the AEDT AirOperations back to some original data source by setting the id field to an identifying identifier from the original data source. Another purpose is to set each ID to a project-specific value for each AirOperation. The ID field is used in several AEDT lists and reports that print out the AirOperations. In addition, the Impact Evaluation dialog uses the ID as its main method of distinguishing AirOperations when allowing the user to pick and choose operations to be moved to alternative flight tracks. If, however, the user has no outside data sources that need to be tied to the AEDT AirOperations, or if each AirOperation is identical in the sense that no specific AirOperation is more valuable than another or that there will be no intent to distinguish one AirOperation over another, then the suggested approach is to just set the UserID field to unique number or set of characters. This will allow the user to distinguish the AirOperations if the need ever arises. Nevertheless, one can leave all the id fields empty or non-unique set of ids; however, in doing so, the user will be forced to use other identifying fields of the AirOperation if they should ever want to distinguish between AirOperations.

element **operation/aircraftType**

diagram	

type	**aircraftType**
properties	content complex
children	**anpAircraftId airframeModel engineCode engineModCode apuName groundSupportEquipmentLTOOperationSet assignDefaultGse**
annotation	documentation Type of aircraft in the flight.

element **operation/cruiseAltitude**

diagram	**cruiseAltitude** Override aircraft cruise altitude MSL for this operation. UNITS: feet.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Override aircraft cruise altitude MSL for this operation. UNITS: feet.

element **operation/numOperations**

diagram	**numOperations** Number of operations comprising this operation.
type	**xs:double**
properties	content simple
annotation	documentation Number of operations comprising this operation.

element **operation/opType**

diagram	**opType**
type	**opType**
properties	minOcc 0

	maxOcc 1 content simple
facets	Kind Value Annotation pattern A|Arrival|D|Departure|V|Overflight|F|Circuit|T|TouchAndGo|R|Runup|W|RunwayToRunway|L|LTO|LandingTakoff|X|Taxi

element **operation/carrier**

diagram	carrier Carrier flying the flight. Not fully supported in AEDT.
type	**string4**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 4
annotation	documentation Carrier flying the flight. Not fully supported in AEDT.

element **operation/flightNumber**

diagram	flightNumber Flight number. Not fully supported in AEDT.
type	**string16**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation Flight number. Not fully supported in AEDT.

element **operation/tailNumber**

diagram	tailNumber Flight's tail number. Not fully supported in AEDT.
type	**string8**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation Flight's tail number. Not fully supported in AEDT.

element **operation/userType**

diagram	userType User-defined aircraft type. Cannot be an aircraftType. Not fully supported in AEDT.
type	**string12**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0

	maxLength 12
annotation	documentation User-defined aircraft type. Cannot be an aircraftType. Not fully supported in AEDT.

element **operation/userParam**

diagram	
type	**string16**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation User-defined parameter associated with the operation. Not fully supported in AEDT.

element **operation/departureAirport**

diagram	
type	**airportCode**
properties	minOcc 0 maxOcc 1 content complex
facets	Kind Value Annotation minLength 0 maxLength 4
attributes	Name Type Use Default Fixed Annotation type **airportCodeType** optional ANY country **string3** optional ANY
annotation	documentation Departure airport's ICAO code. Required if the operation is used with a <flight> or <operation> element. Also required if used with a <trackOpSet> modeling departures, circuits, runups, or touch-and-goes.

element **operation/departureRunway**

diagram	
type	**string8**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation Airport's departure runway ID. Required if the operation is used with a <flight> or a <trackOpSet> modeling departures, circuits, runups, or touch-and-goes.

element **operation/departureGate**

diagram	**departureGate** Airport's departure gate. Not fully supported in AEDT.
type	**string40**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Airport's departure gate. Not fully supported in AEDT.

element **operation/departureApuTime**

diagram	**departureApuTime** Number of minutes the auxiliary power unit is attached to a departing aircraft. (min)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Number of minutes the auxiliary power unit is attached to a departing aircraft. (min)

element **operation/arrivalAirport**

diagram

type	**airportCode**
properties	minOcc 0 maxOcc 1 content complex
facets	Kind Value Annotation minLength 0 maxLength 4

attributes

Name	Type	Use	Default	Fixed	Annotation
type	**airportCodeType**	optional	ANY		
country	**string3**	optional	ANY		

annotation	documentation Arrival airport's ICAO code. Required if the operation is used with a <flight> or <operation> element. Also required if used with a <trackOpSet> modeling arrivals, circuits, runups, or touch-and-goes.

element **operation/arrivalRunway**

diagram	**arrivalRunway** Airport's arrival runway ID. Required if the operation is used with a <flight> or a <trackOpSet> modeling arrivals, circuits, runups, or touch-and-goes.
type	**string8**

properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation Airport's arrival runway ID. Required if the operation is used with a <flight> or a <trackOpSet> modeling arrivals, circuits, runups, or touch-and-goes.

element **operation/arrivalGate**

diagram	**arrivalGate** Airport's arrival gate. Not fully supported in AEDT.
type	**string40**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Airport's arrival gate. Not fully supported in AEDT.

element **operation/arrivalApuTime**

diagram	**arrivalApuTime** Number of minutes the auxiliary power unit is attached to an arrival aircraft. (min)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Number of minutes the auxiliary power unit is attached to an arrival aircraft. (min)

element **operation/offTime**

diagram	**offTime** Wheels-off time. Required for any departure or runup, circuit, runup, or touch-and-go operation.
type	**xs:dateTime**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Wheels-off time. Required for any departure or runup, circuit, runup, or touch-and-go operation.

element **operation/onTime**

diagram	**onTime** Wheels on time. Required for any arrival operation.
type	**xs:dateTime**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Wheels on time. Required for any arrival operation.

element **operation/enrouteStartTime**

diagram	**enrouteStartTime** Time aircraft reaches the first en route node. Required for en route or overflight flights. Not fully supported in AEDT
type	**xs:dateTime**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Time aircraft reaches the first en route node. Required for en route or overflight flights. Not fully supported in AEDT

element **operation/outTime**

diagram	**outTime** Time aircraft pushed back from the gate for a departure. When present, taxiOutDuration = (offTime − outTime). Not fully supported in AEDT.
type	**xs:dateTime**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Time aircraft pushed back from the gate for a departure. When present, taxiOutDuration = (offTime − outTime). Not fully supported in AEDT.

element **operation/taxiOutDuration**

diagram	**taxiOutDuration** Number of seconds during taxi-out. Required for emissions modeling, optional for noise modeling. Not fully supported in AEDT. (s)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Number of seconds during taxi-out. Required for emissions modeling, optional for noise modeling. Not fully supported in AEDT. (s)

element **operation/inTime**

diagram	**inTime** Time aircraft arrives at arrival gate. When present, taxiInDuration = (onTime – inTime).
type	**xs:dateTime**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Time aircraft arrives at arrival gate. When present, taxiInDuration = (onTime – inTime).

element **operation/taxiInDuration**

diagram	**taxiInDuration** Number of seconds during taxi-in. Required for emissions modeling, optional for noise modeling. (s)
type	**xs:double**

properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Number of seconds during taxi-in. Required for emissions modeling, optional for noise modeling. (s)

element **operation/activityProfile**

diagram	
type	**string100**
properties	minOcc 0 maxOcc 1 content simple
used by	element **activityProfileSet**
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation References an existing hourly, daily, or monthly profile.

element **operation/saeProfile**

diagram	
type	**profileType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Overrides default profile assignment for a flight's arrival and departure phases using characteristics specified by SAE International. Applicable when the override is unambiguously arrival or departure.

element **operation/saeProfiles**

diagram	
type	**profiles**
properties	minOcc 0 maxOcc 1 content complex
children	**departureProfile arrivalProfile**
annotation	documentation Overrides default profile assignment for a flight's arrival and departure phases using characteristics specified by SAE International. Applicable when it is necessary to specify both the arrival and departure profiles.

element **operation/badaProfile**

diagram	
type	**profileType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Overrides default profile assignment for a flight's arrival and departure phases using characteristics specified by BADA. Applicable when the override is unambiguously arrival or departure.

element **operation/badaProfiles**

diagram	
type	**profiles**
properties	minOcc 0 maxOcc 1 content complex
children	**departureProfile** **arrivalProfile**
annotation	documentation Overrides default profile assignment for a flight's arrival and departure phases using characteristics specified by BADA. Applicable when it is necessary to specify both the arrival and departure profiles.

element **operation/stageLength**

diagram	
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Overrides default departure and arrival stage length values. Applicable when the override is unambiguously arrival or departure. If operation type is Arrival, then AEDT will always use 1 for stage length.

element **operation/actypeWeight**

diagram	

	actypeWeight Aircraft's weight. (lb)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Aircraft's weight. (lb)

element **operation/departureStageLength**

diagram	**departureStageLength** Overrides default departure stage length. Applicable if the phase is a departure phase.
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Overrides default departure stage length. Applicable if the phase is a departure phase.

element **operation/arrivalStageLength**

diagram	**arrivalStageLength** Overrides default arrival stage length. Applicable if the phase is an arrival phase. If operation type is Arrival, then AEDT will always use 1 for stage length.
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Overrides default arrival stage length. Applicable if the phase is an arrival phase. If operation type is Arrival, then AEDT will always use 1 for stage length.

element **operation/glideSlope**

diagram	**glideSlope** Glide slope angle for this operation. (decimal degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Glide slope angle for this operation. (decimal degrees)

element **operation/fuelSulfurContent**

diagram	**fuelSulfurContent** Sulfur content of the fuel used in this operation. (%)
type	**xs:double**

properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Sulfur content of the fuel used in this operation. (%)

element **operationalProfileSet**

diagram	
properties	content complex
children	**quarterHourlyProfileSet** **dailyProfileSet** **monthlyProfileSet** **activityProfileSet**
used by	element **AsifXml**

element **operations**

diagram	
properties	content complex
children	**operation**
used by	element **trackOpSet**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Contains a list of aircraft flight operations.

attribute **operations/@dummy**

type	**xs:int**
properties	use optional

element **options**

diagram	
properties	content complex
children	**utmZoneDefault**

used by	element **AsifXml**
annotation	documentation Contains default option values applied to the study.

element **options/utmZoneDefault**

diagram	**utmZoneDefault** Default UTM zone number.
type	**xs:int**
properties	content simple default -1
annotation	documentation Default UTM zone number.

element **parkingFacility**

diagram	
properties	content complex
children	**name numberOfLevels topReleaseHeight spacing elevation pointCoord polygonCoords**
used by	element **parkingFacilitySet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the PARKING table. This element supports the definition of parking lot and parking garage geometries for scenario layouts.

element **parkingFacility/name**

diagram	**name** Identifying name of parking facility.
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Identifying name of parking facility.

element **parkingFacility/numberOfLevels**

diagram	**numberOfLevels** Number of levels in the parking facility. Valid values: 1 to 20.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Number of levels in the parking facility. Valid values: 1 to 20.

element **parkingFacility/topReleaseHeight**

diagram	**topReleaseHeight** Height AGL at which emissions are released into the atmosphere. Valid values 0 to 100 (m)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Height AGL at which emissions are released into the atmosphere. Valid values 0 to 100 (m)

element **parkingFacility/spacing**

diagram	**spacing** Distance between two parking spaces. (m)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Distance between two parking spaces. (m)

element **parkingFacility/elevation**

diagram	**elevation** Elevation of parking facility in MSL. Valid values: range of 0 - 328, airport specific.(m)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Elevation of parking facility in MSL. Valid values: range of 0 - 328, airport specific.(m)

element **parkingFacilityOperation**

diagram	

properties	content complex
children	**refName** **useAnnualFigures** **vehicleType** **fuelType** **emissionsUsage** **averageSpeed** **averageDistanceTraveled** **averageIdleTime** **vehicleEmissionFactors**
used by	element **parkingFacilityOperationSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the PARKING table. This element supports the definition of parking lot and parking garage activities for scenario layouts.

element **parkingFacilityOperation/refName**

diagram	**refName** Identifying name of parking facility.
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Identifying name of parking facility.

element **parkingFacilityOperation/useAnnualFigures**

diagram	**useAnnualFigures** Indicates if the quantities in the element are annualized.
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Indicates if the quantities in the element are annualized.

element **parkingFacilityOperation/vehicleType**

diagram	**vehicleType** Type of vehicle involved in the operation. Valid values: 0 = Default Fleet Mix, 1 = Passenger Cars, 2 = Light Trucks 1, 3 = Light Trucks 2, 4 = Light Trucks 3, 5 = Light Trucks 4, 6 = Class 2b Heavy Trucks, 7 = Class 3 Heavy Trucks, 8 = Class 4 Heavy Trucks, 9 = Class 5 Heavy Trucks, 10 = Class 6 Heavy Trucks, 11 = Class 7 Heavy Trucks, 12 = Class 8a Heavy Trucks, 13 = Class 8b Heavy Trucks, 14 = School Buses, 15 = Transit and Urban Buses, 16 = Motorcycle.
type	**groundVehicleType**
properties	content simple
facets	Kind Value Annotation pattern 0|Default Fleet Mix|1|Passenger Cars|2|Light Trucks 1|3|Light Trucks 2|4|Light Trucks 3|5|Light Trucks 4|6|Class 2b Heavy Trucks|7|Class 3 Heavy Trucks|8|Class 4 Heavy Trucks|9|Class 5 Heavy Trucks|10|Class 6 Heavy Trucks|11|Class 7 Heavy Trucks|12|Class 8a Heavy Trucks|13|Class 8b Heavy Trucks|14|School Busses|15|Transit and Urban Busses|16|Motorcycle
annotation	documentation Type of vehicle involved in the operation. Valid values: 0 = Default Fleet Mix, 1 = Passenger Cars, 2 = Light Trucks 1, 3 = Light Trucks 2, 4 = Light Trucks 3, 5 = Light Trucks 4, 6 = Class 2b Heavy Trucks, 7 = Class 3 Heavy Trucks, 8 = Class 4 Heavy Trucks, 9 = Class 5 Heavy Trucks, 10 = Class 6 Heavy Trucks, 11 = Class 7 Heavy Trucks, 12 = Class 8a Heavy Trucks, 13 = Class 8b Heavy Trucks, 14 = School Buses, 15 = Transit and Urban Buses, 16 = Motorcycle.

element **parkingFacilityOperation/fuelType**

diagram	**fuelType** Type of fuel involved in the operation.
type	**fuelType**
properties	minOcc 0 maxOcc 1 content simple default G
facets	Kind Value Annotation pattern G|Gasoline|D|Diesel|C|Compressed Natural Gas|L|Liquefied Petroleum Gas|E|Electric
annotation	documentation Type of fuel involved in the operation.

element **parkingFacilityOperation/averageSpeed**

diagram	**averageSpeed** Average speed during the operation. Valid values: 2.5 to 40. (mph)
type	**xs:double**
properties	minOcc 0 maxOcc 1

	content simple default 10
annotation	documentation Average speed during the operation. Valid values: 2.5 to 40. (mph)

element **parkingFacilityOperation/averageDistanceTraveled**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Average distance traveled during the operation. Valid values: 0 to 32808. (m)

element **parkingFacilityOperation/averageIdleTime**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Average time vehicle is idle while conducting the operation. Valid values: 0 to 30. (min)

element **parkingFacilityOperationSet**

diagram	
properties	content complex
children	**parkingFacilityOperation**
used by	group **airportActivityGroup**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the PARKING table. This element supports the definition of parking lot and parking garage activities for scenario layouts.

attribute **parkingFacilityOperationSet/@dummy**

type	**xs:int**
properties	use optional

element **parkingFacilitySet**

diagram	

properties	content complex
children	**parkingFacility**
used by	complexType **airportLayoutType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the PARKING table. This element supports the definition of parking lot and parking garage activities for scenario layouts.

attribute **parkingFacilitySet/@dummy**

type	**xs:int**
properties	use optional

element **pointReceptor**

diagram

properties	content complex

children	**name** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **elevation** **receptorHeight**
used by	group **receptorGroup**
annotation	documentation Element specification for a point receptor.

element **pointReceptor/name**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255

element **pointReceptor/elevation**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Elevation of the receptor above MSL. (ft.)

element **pointReceptor/receptorHeight**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Height of the receptor above ground (ft.)

element **pointStationarySource**

diagram	

properties	content complex
children	**pointCoord** **baseElevation** **releaseHeight** **gasVelocity** **stackDiameter** **temperature** **aboveAmbientTemperature**
used by	element **stationarySource**
annotation	documentation Specifies the point in space occupied by a stationary source of emissions.

element **pointStationarySource/pointCoord**

diagram

type	**coord2DType**

properties	content complex
children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone**
annotation	documentation Type of 2-D coordinates specifying the point.

element **pointStationarySource/baseElevation**

diagram	**baseElevation** Elevation of point. Valid values: -500 to 5000. (m)
type	**xs:double**
properties	content simple
annotation	documentation Elevation of point. Valid values: -500 to 5000. (m)

element **pointStationarySource/releaseHeight**

diagram	**releaseHeight** Height above ground level at which emissions are released into the atmosphere. Valid values 0 to 100 (m)
type	**doubleInclusive100**
properties	minOcc 0 maxOcc 1 content simple default 0
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Height above ground level at which emissions are released into the atmosphere. Valid values 0 to 100 (m)

element **pointStationarySource/gasVelocity**

diagram	**gasVelocity** Velocity at which gas escapes from the source. Valid values: 1 to 30. (m/s)
type	**doubleInclusiveRange1to30**
properties	minOcc 0 maxOcc 1 content simple default 1
facets	Kind Value Annotation minInclusive 1 maxInclusive 30
annotation	documentation Velocity at which gas escapes from the source. Valid values: 1 to 30. (m/s)

element **pointStationarySource/stackDiameter**

diagram	**stackDiameter** Diameter of stack where gas escapes from the source. Valid values: 0.1 to 50 (m)
type	**doubleExclusive0Inclusive10**
properties	minOcc 0 maxOcc 1 content simple default 0.1
facets	Kind Value Annotation

	maxInclusive 10 minExclusive 0
annotation	documentation Diameter of stack where gas escapes from the source. Valid values: 0.1 to 50 (m)

element **pointStationarySource/temperature**

diagram	**temperature** Temperature at point. Valid values: 0 to 600. (°F)
type	**doubleInclusiveRange0to600**
properties	minOcc 0 maxOcc 1 content simple default 32
facets	Kind Value Annotation minInclusive 0 maxInclusive 600
annotation	documentation Temperature at point. Valid values: 0 to 600. (°F)

element **pointStationarySource/aboveAmbientTemperature**

diagram	**aboveAmbientTemperature** Indicates if temperature is absolute (False) or if temperature is relative to current ambient temperature (True).
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Indicates if temperature is absolute (False) or if temperature is relative to current ambient temperature (True).

element **polarGrid**

diagram

properties	content complex
children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **originSource** **originName** **elevation** **height** **ringStart** **ringSpacing** **ringCount** **vectorStart** **vectorSpacing** **vectorCount** **xrOffset** **ydOffset**
used by	group **receptorGroup**
annotation	documentation Supports legacy EDMS studies relating to the NETWORK_POLAR_RECEPTORS table. Two-Dimensional grid of individual receptors over an annular sector (polar) of the airport or study area.

element **polarGrid/originSource**

diagram	**originSource** (m)
type	**originSourceType**
properties	content simple
facets	Kind Value Annotation pattern Gate|Parking Facility|Roadway|Runway|Stionary Source|Taxiway|Training Fire
annotation	documentation (m)

element **polarGrid/originName**

diagram	

	originName Refers to an existing gate, parking facility, roadway, runway, stationary source, taxiway, or training fire.
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Refers to an existing gate, parking facility, roadway, runway, stationary source, taxiway, or training fire.

element **polarGrid/elevation**

diagram	**elevation** Altitude of point (meters).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Altitude of point (meters).

element **polarGrid/height**

diagram	**height** Height of point (meters).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Height of point (meters).

element **polarGrid/ringStart**

diagram	**ringStart** Initial radius of first ring from center point.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Initial radius of first ring from center point.

element **polarGrid/ringSpacing**

diagram	**ringSpacing** Spacing between rings starting from the first ring. Valid values: 0 to 1000.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Spacing between rings starting from the first ring. Valid values: 0 to 1000.

element **polarGrid/ringCount**

diagram	**ringCount** Total number of rings, including first ring. Valid values: 0 to 100.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Total number of rings, including first ring. Valid values: 0 to 100.

element **polarGrid/vectorStart**

diagram	**vectorStart** Angle of point along a ring. 0 = north. Valid values: 0 to 360. (degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Angle of point along a ring. 0 = north. Valid values: 0 to 360. (degrees)

element **polarGrid/vectorSpacing**

diagram	**vectorSpacing** Number of degrees between receptors. Valid values: 1 to 90. (degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Number of degrees between receptors. Valid values: 1 to 90. (degrees)

element **polarGrid/vectorCount**

diagram	**vectorCount** Number of receptors along the ring. Valid values: 1 to 36.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple default 1
annotation	documentation Number of receptors along the ring. Valid values: 1 to 36.

element **polarGrid/xrOffset**

diagram	**xrOffset** The X-offset of the receptor grid in nautical miles.
type	**xs:double**
properties	minOcc 0

	maxOcc 1 content simple default 0
annotation	documentation The X-offset of the receptor grid in nautical miles.

element **polarGrid/ydOffset**

diagram	**ydOffset** The Y-offset of the receptor grid in nautical miles.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation The Y-offset of the receptor grid in nautical miles.

element **polarReceptor**

diagram	

properties	content complex
children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **originSource** **originName** **distanceFromSource** **directionFromSource** **elevation** **height**
used by	group **receptorGroup**
annotation	documentation Supports legacy EDMS studies relating to the NETWORK_POLAR_RECEPTORS and DISCRETE_POLAR_RECEPTORS table. Defines receptor points within a polar grid.

element **polarReceptor/originSource**

diagram	**originSource**
type	**originSourceType**
properties	content simple
facets	Kind Value Annotation pattern Gate|Parking Facility|Roadway|Runway|Stionary Source|Taxiway|Training Fire

element **polarReceptor/originName**

diagram	

	originName Refers to an existing gate, parking facility, roadway, runway, stationary source, taxiway, or training fire.
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Refers to an existing gate, parking facility, roadway, runway, stationary source, taxiway, or training fire.

element **polarReceptor/distanceFromSource**

diagram	**distanceFromSource** Distance of point from polar origin. Valid values: 0 through 999999.999999. (ft)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Distance of point from polar origin. Valid values: 0 through 999999.999999. (ft)

element **polarReceptor/directionFromSource**

diagram	**directionFromSource** Direction of point from polar origin. Valid values: 0 through 360. (degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Direction of point from polar origin. Valid values: 0 through 360. (degrees)

element **polarReceptor/elevation**

diagram	**elevation** Altitude of point. (meters).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Altitude of point. (meters).

element **polarReceptor/height**

diagram	**height** Height of point. (meters).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Height of point. (meters).

element **quarterHourlyProfile**

diagram	
properties	content complex
children	**profileName** **temporalFactor**
used by	element **quarterHourlyProfileSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the QUARTER_HOURLY_PROFILES. This element supports the definition of temporal factors on a quarter-hourly operational basis.

element **quarterHourlyProfile/profileName**

diagram	
type	**string100**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Name of profile.

element **quarterHourlyProfile/temporalFactor**

diagram	
type	extension of **doubleMin0**
properties	minOcc 0 maxOcc unbounded content complex
facets	Kind Value Annotation minInclusive 0
attributes	Name / Type / Use / Default / Fixed / Annotation startHour / **int0to23** / required / / / documentation The starting hour as an integer between 0 and 23. startMinutes / **quarterHourMinutes** / required / / / documentation The starting quarter-hourly minute value as either 0, 15, 30, or 45.
annotation	documentation Factor applied to activity for operations during the indicated quarter hour. Valid values: 0.0000 to 1.0000.

attribute **quarterHourlyProfile/temporalFactor/@startHour**

type	**int0to23**
properties	use required
facets	Kind Value Annotation

	minInclusive 0 maxInclusive 23
annotation	documentation The starting hour as an integer between 0 and 23.

attribute **quarterHourlyProfile/temporalFactor/@startMinutes**

type	**quarterHourMinutes**
properties	use required
facets	Kind Value Annotation enumeration 0 enumeration 15 enumeration 30 enumeration 45
annotation	documentation The starting quarter-hourly minute value as either 0, 15, 30, or 45.

element **quarterHourlyProfileSet**

diagram	
properties	content complex
children	**quarterHourlyProfile**
used by	element **operationalProfileSet** complexType **airportLayoutType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports the definition and use of QUARTER_HOURLY_PROFILES for the quarter hourly variation of operations.

attribute **quarterHourlyProfileSet/@dummy**

type	**xs:int**
properties	use optional

element **receptorSet**

diagram	

properties	content complex
children	**name** **centroid** **pointReceptor** **grid** **polarReceptor** **polarGrid**
used by	elements **AsifXml** **study**
annotation	documentation Contains one or more receptor sets at various locations.

element **receptorSet/name**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Descriptive name of the receptor set.

element **recordCode**

diagram	
type	union of (restriction of **xs:int**, restriction of **xs:int**)
properties	content simple
used by	element **categoryRecordCode**
annotation	documentation An integer value for a category to use as the basis of a new stationary source operation. This value comes from the CATEGORY_REC_ID column in the STN_CATEGORY table in the

	AEDT FLEET database. Valid values: 0 to 87, 89 to 148.

element **roadway**

diagram	
properties	content complex
children	**name** **width** **coordinates**
used by	element **roadwaySet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the ROADWAYS table. This element supports the definition of vehicle geometry on roadways for scenario layouts.

element **roadway/name**

diagram	
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Identifying name for the roadway.

element **roadway/width**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Roadway's width. Valid values: 1 to 99. (m)

element **roadway/coordinates**

diagram	
properties	minOcc 0 maxOcc 1 content complex
children	**vertex**
annotation	documentation Set of three-dimensional coordinates describing the roadway.

element **roadway/coordinates/vertex**

diagram	

type	**coord3DElevationType**
properties	minOcc 2 maxOcc unbounded content complex
children	**latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone elevation**
annotation	documentation A point representing one of the coordinates.

element **roadwayOperation**

diagram	

properties	content complex
children	**refName** **useAnnualFigures** **vehicleType** **fuelType** **emissionsUsage** **vehicleEmissionFactors** **speed** **roundTripDistance**
used by	element **roadwayOperationSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the ROADWAYS table. This element supports the definition of vehicle activity on roadways for scenario layouts.

element **roadwayOperation/refName**

diagram	**refName** Identifying name of roadway operation.
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Identifying name of roadway operation.

element **roadwayOperation/useAnnualFigures**

diagram	**useAnnualFigures** Indicates if the quantities in the element are annualized.

type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Indicates if the quantities in the element are annualized.

element **roadwayOperation/vehicleType**

diagram	**vehicleType** Type of vehicle involved in the operation. Valid values (the numeral corresponds to the text value; either are valid): 0 = Default Fleet Mix, 1 = Passenger Cars, 2 = Light Trucks 1, 3 = Light Trucks 2, 4 = Light Trucks 3, 5 = Light Trucks 4, 6 = Class 2b Heavy Trucks, 7 = Class 3 Heavy Trucks, 8 = Class 4 Heavy Trucks, 9 = Class 5 Heavy Trucks, 10 = Class 6 Heavy Trucks, 11 = Class 7 Heavy Trucks, 12 = Class 8a Heavy Trucks, 13 = Class 8b Heavy Trucks, 14 = School Busses, 15 = Transit and Urban Busses, 16 = Motorcycle.
type	**groundVehicleType**
properties	content simple
facets	Kind Value Annotation pattern 0|Default Fleet Mix|1|Passenger Cars|2|Light Trucks 1|3|Light Trucks 2|4|Light Trucks 3|5|Light Trucks 4|6|Class 2b Heavy Trucks|7|Class 3 Heavy Trucks|8|Class 4 Heavy Trucks|9|Class 5 Heavy Trucks|10|Class 6 Heavy Trucks|11|Class 7 Heavy Trucks|12|Class 8a Heavy Trucks|13|Class 8b Heavy Trucks|14|School Busses|15|Transit and Urban Busses|16|Motorcycle
annotation	documentation Type of vehicle involved in the operation. Valid values (the numeral corresponds to the text value; either are valid): 0 = Default Fleet Mix, 1 = Passenger Cars, 2 = Light Trucks 1, 3 = Light Trucks 2, 4 = Light Trucks 3, 5 = Light Trucks 4, 6 = Class 2b Heavy Trucks, 7 = Class 3 Heavy Trucks, 8 = Class 4 Heavy Trucks, 9 = Class 5 Heavy Trucks, 10 = Class 6 Heavy Trucks, 11 = Class 7 Heavy Trucks, 12 = Class 8a Heavy Trucks, 13 = Class 8b Heavy Trucks, 14 = School Busses, 15 = Transit and Urban Busses, 16 = Motorcycle.

element **roadwayOperation/fuelType**

diagram	**fuelType** Type of fuel involved in the operation. Valid values: G = gasoline, D = diesel.
type	**fuelType**
properties	minOcc 0 maxOcc 1 content simple default G
facets	Kind Value Annotation pattern G|Gasoline|D|Diesel|C|Compressed Natural Gas|L|Liquefied Petroleum Gas|E|Electric
annotation	documentation Type of fuel involved in the operation. Valid values: G = gasoline, D = diesel.

element **roadwayOperation/speed**

diagram	**speed** Speed during the operation. Valid values: 5 to 65. (mph)
type	**int5to65**
properties	minOcc 0 maxOcc 1 content simple default 35
facets	Kind Value Annotation minInclusive 5 maxInclusive 65

annotation	documentation Speed during the operation. Valid values: 5 to 65. (mph)

element **roadwayOperation/roundTripDistance**

diagram	 Round trip vehicle distance. (mi)
type	**doubleInclusive4000**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 4000
annotation	documentation Round trip vehicle distance. (mi)

element **roadwayOperationSet**

diagram	
properties	content complex
children	**roadwayOperation**
used by	group **airportActivityGroup**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the ROADWAYS table. This element supports the definition of vehicle activity on roadways for scenario layouts.

attribute **roadwayOperationSet/@dummy**

type	**xs:int**
properties	use optional

element **roadwaySet**

diagram	
properties	content complex
children	**roadway**
used by	complexType **airportLayoutType**
attributes	Name Type Use Default Fixed Annotation

	dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the ROADWAYS table. This element supports the definition of vehicle activity on roadways for scenario layouts.

attribute **roadwaySet/@dummy**

type	**xs:int**
properties	use optional

element **runway**

diagram	
properties	content complex
children	**length** **width** **runwayEnd**
used by	element **runwaySet**
annotation	documentation Describes dimensions of a runway.

element **runway/length**

diagram	
type	**xs:short**
properties	content simple
annotation	documentation Length of runway. Valid values: nonnegative. (feet)

element **runway/width**

diagram	
type	**xs:short**
properties	content simple
annotation	documentation Width of runway. Valid values: nonnegative. (feet)

element **runway/runwayEnd**

diagram	

type	**runwayEnd**
properties	minOcc 1

	maxOcc 2 content complex
children	**name** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **elevation** **threshCrossHeight** **threshElevation** **glideSlope** **intAltitude** **depDispThresh** **appDispThresh** **percentWind** **isHelipad**
annotation	documentation Characterizes the runway's endpoint.

element **runwayAssignment**

diagram	
properties	content complex
children	**aircraftSize** **runway** **arrivalPercentage** **departurePercentage** **tgoPercentage**
used by	element **runwayAssignmentSet**
annotation	documentation Defines a assignment of operations to runways, by aircraft size.

element **runwayAssignment/aircraftSize**

diagram	
type	**AircraftSizeType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation enumeration S enumeration L enumeration H

element **runwayAssignment/runway**

diagram	 Name of the runway.
type	**string8**
properties	content simple
used by	element **runwaySet**
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation Name of the runway.

element **runwayAssignment/arrivalPercentage**

diagram	

	arrivalPercentage Percentage of arrivals of the given aircraft size using this runway. Valid values: 0 to 100.(%)
type	**doubleInclusive100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percentage of arrivals of the given aircraft size using this runway. Valid values: 0 to 100.(%)

element **runwayAssignment/departurePercentage**

diagram	**departurePercentage** Percentage of departures of the given aircraft size using this runway. Valid values: 0 to 100. (%)
type	**doubleInclusive100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percentage of departures of the given aircraft size using this runway. Valid values: 0 to 100. (%)

element **runwayAssignment/tgoPercentage**

diagram	**tgoPercentage** Percentage of touch and gos of the given aircraft size using this runway. Valid values: 0 to 100. (%)
type	**doubleInclusive100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Percentage of touch and gos of the given aircraft size using this runway. Valid values: 0 to 100. (%)

element **runwayAssignmentSet**

diagram	**runwayAssignmentSet** — **runwayAssignment** 1..∞ Contains a set of runway assignments. Defines a assignment of operations to runways, by aircraft size.
properties	content complex
children	**runwayAssignment**
used by	element **airportConfig**
annotation	documentation Contains a set of runway assignments.

element **runwaySet**

diagram	
properties	content complex
children	**runway**
used by	complexType **airportLayoutType**
annotation	documentation Container for runways.

element **scenario**

diagram	
properties	content complex

children	**name** **startTime** **duration** **taxiModel** **timeInModeBasis** **acftPerfModel** **bankAngle** **altitudeCutoff** **sulfurConversionRate** **fuelSulfurContent** **description** **scenarioAirportLayoutSet** **caseSet** **annualization**
used by	elements **AsifXml** **study**
annotation	documentation Encapsulates a scenario - such as Baseline or Alternative

element **scenario/name**

diagram	**name** Description of scenario.
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Description of scenario.

element **scenario/startTime**

diagram	**startTime** Start time of scenario. Accepts dateTime string.
type	**xs:dateTime**
properties	content simple
annotation	documentation Start time of scenario. Accepts dateTime string.

element **scenario/duration**

diagram	**duration** Scenario's duration (hr).
type	**xs:int**
properties	content simple
annotation	documentation Scenario's duration (hr).

element **scenario/taxiModel**

diagram	**taxiModel** Taxi model for scenario.
type	**taxiModelType**
properties	content simple
facets	Kind Value Annotation enumeration UserSpecified enumeration Delayed enumeration Sequencing
annotation	documentation Taxi model for scenario.

element **scenario/timeInModeBasis**

diagram	**timeInModeBasis**
type	**timeInModeBasisType**
properties	minOcc 0 maxOcc 1 content simple default ICAO

facets	Kind Value Annotation enumeration Performance enumeration ICAO

element **scenario/acftPerfModel**

diagram	**acftPerfModel** Aircraft performance model.
type	**aircraftPerformanceModelType**
properties	content simple
facets	Kind Value Annotation enumeration ICAO enumeration SAE1845
annotation	documentation Aircraft performance model.

element **scenario/bankAngle**

diagram	**bankAngle** Indicates if bank angle calculations should be included in calculations. NOTE: AEDT ignores this value and treats all scenarios as if their bank angle value was set to true.
type	**xs:boolean**
properties	content simple
annotation	documentation Indicates if bank angle calculations should be included in calculations. NOTE: AEDT ignores this value and treats all scenarios as if their bank angle value was set to true.

element **scenario/altitudeCutoff**

diagram	**altitudeCutoff** Altitude in MSL (feet) to cutoff trajectory modeling for this scenario. The scenario altitude cutoff only affects noise impact calculation in AEDT. Fuel burn and emissions will be calculated until a flight reaches the study boundary.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 18000
annotation	documentation Altitude in MSL (feet) to cutoff trajectory modeling for this scenario. The scenario altitude cutoff only affects noise impact calculation in AEDT. Fuel burn and emissions will be calculated until a flight reaches the study boundary.

element **scenario/sulfurConversionRate**

diagram	**sulfurConversionRate** Portion of sulfur in the fuel that, when combusted, becomes sulfuric acid used for emissions calculations. (%)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Portion of sulfur in the fuel that, when combusted, becomes sulfuric acid used for emissions calculations. (%)

element **scenario/fuelSulfurContent**

diagram	

	fuelSulfurContent Percentage, by weight, of sulfur in the fuel used for emissions calculations. Default Values: 0.0006 (0.06%) (%)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Percentage, by weight, of sulfur in the fuel used for emissions calculations. Default Values: 0.0006 (0.06%) (%)

element **scenario/description**

diagram	**description** A description of the scenario.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation A description of the scenario.

element **scenarioAirportLayoutSet**

diagram	
properties	content complex
children	**scenarioAirportLayout**
used by	element **scenario**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Contains a set of airport layout types.

attribute **scenarioAirportLayoutSet/@dummy**

type	**xs:int**
properties	use optional

element **scenarioAirportLayoutSet/scenarioAirportLayout**

diagram	

type	**scenarioAirportLayoutType**
properties	minOcc 1 maxOcc unbounded content complex
children	**airportLayoutName** **mixingHeight** **useHourlyMetData** **averageTemperature** **dailyHighTemperature** **dailyLowTemperature** **pressure** **pressureMSL** **humidty** **windSpeed** **windDirection** **ceiling** **visibility** **airportConfigSet** **airportCapacity**
annotation	documentation Airport layout type.

element **sensorNode**

diagram	
properties	content complex
children	**lat** **long** **altitude** **messageTime** **sequenceNum** **speed** **thrust** **source**
used by	element **sensorPath**
annotation	documentation Describes a single node of a radar flight path.

element **sensorNode/lat**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Latitude for this location (decimal degrees).

element **sensorNode/long**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Longitude for this location (decimal degrees).

element **sensorNode/altitude**

diagram	
type	**xs:double**

properties	content simple
annotation	documentation Altitude in MSL at this location. UNITS: feet

element **sensorNode/messageTime**

diagram	**messageTime** Time aircraft reaches this location. NOTE: Not used in AEDT.
type	**xs:dateTime**
properties	content simple
annotation	documentation Time aircraft reaches this location. NOTE: Not used in AEDT.

element **sensorNode/sequenceNum**

diagram	**sequenceNum** Order of this location in node list.
type	**xs:int**
properties	content simple
annotation	documentation Order of this location in node list.

element **sensorNode/speed**

diagram	**speed** Ground speed of aircraft at this location. UNITS: knots.
type	**xs:double**
properties	content simple
annotation	documentation Ground speed of aircraft at this location. UNITS: knots.

element **sensorNode/thrust**

diagram	**thrust** Thrust of aircraft at this location. NOTE: Not used in AEDT. (lb)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Thrust of aircraft at this location. NOTE: Not used in AEDT. (lb)

element **sensorNode/source**

diagram	**source** Source of the data for this node. NOTE: Not used in AEDT.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation

	Source of the data for this node. NOTE: Not used in AEDT.

element **sensorPath**

diagram	
properties	content complex
children	**sensorNode**
used by	element **trackOpSet**
annotation	documentation Describes a flight path based on radar data.

element **stationarySource**

diagram

properties	content complex
children	**name** **pointStationarySource** **areaStationarySource** **volumeStationarySource** **categoryRecordCode** **categoryBoilerHeater** **categoryGenerator** **categoryIncinerator** **categoryAircraftEngine** **categoryFuelTank** **categorySurfaceCoatingPainting** **categoryDeicingArea** **categorySolventDegreaser** **categorySandSaltPile** **categoryTrainingFire** **categoryOther**
used by	element **stationarySourceSet**
annotation	documentation Specifies a stationary source.

element **stationarySource/name**

diagram	
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Identifying name of the stationary source.

element **stationarySourceOperation**

diagram	
properties	content complex
children	**refName** **elevation** **pointCoord** **emissionsUsage**
used by	element **stationarySourceOperationSet**
annotation	documentation Defines an operation at a stationary source that generates emissions.

element **stationarySourceOperation/refName**

diagram	
type	**string40**

properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Identifier of the operation.

element **stationarySourceOperation/elevation**

diagram	elevation
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple

element **stationarySourceOperation/pointCoord**

diagram	
type	**coord2DType**
properties	minOcc 0 maxOcc 1 content complex
children	**latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone**

element **stationarySourceOperationSet**

diagram	
properties	content complex

children	**stationarySourceOperation**
used by	group **airportActivityGroup**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Container of operations conducted at a stationary source contributing emissions.

attribute **stationarySourceOperationSet/@dummy**

type	**xs:int**
properties	use optional

element **stationarySourceSet**

diagram	
properties	content complex
children	**stationarySource**
used by	element **AsifXml** complexType **airportLayoutType**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Container of stationary sources contributing emissions.

attribute **stationarySourceSet/@dummy**

type	**xs:int**
properties	use optional

element **study**

diagram	

properties	content complex
children	**name** **studyType** **emissionsUnits** **description** **boundary** **climate** **userDefinedAirportSet** **airportLayoutSet** **terrainFiles** **receptorSet** **fleet** **userGroundSupportEquipmentSet** **scenario**
used by	element **AsifXml**
annotation	documentation Contains specific information about a study.

element **study/name**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0

	maxLength 255
annotation	documentation Name of the study.

element **study/studyType**

diagram	studyType
type	**studyType**
properties	content simple
facets	Kind Value Annotation enumeration Emissions enumeration Dispersion enumeration Noise and Emissions enumeration Noise and Dispersion

element **study/emissionsUnits**

diagram	emissionsUnits
type	**emissionsUnitsType**
properties	content simple
facets	Kind Value Annotation enumeration MetricTonnes enumeration Kilograms enumeration Grams enumeration ImperialTons enumeration Pounds

element **study/description**

diagram	description Optional description of the study.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Optional description of the study.

element **study/terrainFiles**

diagram	terrainFiles List of files containing descriptions of terrain.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation List of files containing descriptions of terrain.

element **study/fleet**

diagram	fleet auxiliaryPowerUnit

0..∞
Describes a custom auxiliary power unit (APU). These are typically on-board generators providing power to a parked aircraft.
airframe
0..∞
Supports the definition of custom airframes.
engine
0..∞
User defined engine information containing custom parameters that reflect an aircraft engine. This engine definition can then be used within a user-defined aircraft.
engineMod
0..∞
User defined engine modification information containing custom parameters that reflect an aircraft engine modification. This engine modification definition can that be used within a user defined aircraft.
spectralClass
0..∞
This element contains user-defined spectral class data.
anpNoiseGroup
0..∞
This element contains the three spectral class references for a given aircraft noise group with the corresponding thrust setting type and model type.
anpAirplane
0..∞
Creates a new ANP aircraft.
anpFlapsSet
0..∞
Flap settings for an ANP aircraft type.
anpThrustSet
0..∞
Specifies a set of thrust records for an ANP aircraft.
anpProfileSet
0..∞
The profile set for an ANP aircraft.
anpHeloNoiseGroup
0..∞
This element contains the three spectral class references for a given helicopter noise group with the corresponding thrust setting type and model type.
anpHelicopter
0..∞
Creates a new ANP helicopter.
anpHeloDirectivitySet
0..∞
A set of helicopter directivities.
anpHeloProfileSet
0..∞
A profile set for an ANP helicopter.
fleet
Defines aircraft fleet participating in the study.

type	**fleet**
properties	minOcc 0 maxOcc 1 content complex
children	**auxiliaryPowerUnit** **airframe** **engine** **engineMod** **spectralClass** **anpNoiseGroup** **anpAirplane** **anpFlapsSet** **anpThrustSet** **anpProfileSet** **anpHeloNoiseGroup** **anpHelicopter** **anpHeloDirectivitySet** **anpHeloProfileSet** **badaAirplane** **badaAltitudeDistributionSet** **badaDefaultAltitudeDistributionSet** **badaProfileSet** **badaConfigSet** **badaFuel** **badaThrust** **bada4ProfileSet** **aircraft** **energyShare**
annotation	documentation Defines aircraft fleet participating in the study.

element **subtrack**

diagram	
properties	content complex

children	**id** **dispersionWeight** **trackVectors** **trackNodes**
used by	element **track**
annotation	documentation Intended to represent a dispersed child track of a parent track.

element **subtrack/id**

diagram	**id** ID for a subtrack.
type	**xs:int**
properties	content simple
annotation	documentation ID for a subtrack.

element **subtrack/dispersionWeight**

diagram	**dispersionWeight** dispersion weight value; must be greater than one and less than or equal to 1.
type	**xs:double**
properties	content simple
used by	element **backbone**
annotation	documentation dispersion weight value; must be greater than one and less than or equal to 1.

element **taxiNode**

diagram

properties	content complex
children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **elevation** **speed**
used by	element **taxiNodeSet**
annotation	documentation Supports legacy EDMS studies relating to the TAXIWAYS table. Taxi nodes define the points for a given taxiway.

element **taxiNode/elevation**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Taxi node's elevation above MSL. Valid values: -500 to 5000. (m)

element **taxiNode/speed**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Speed of aircraft at node. Valid values: 1.00 to 60.00. (mph)

element **taxiNodeSet**

diagram	
properties	content complex
children	**taxiNode**
used by	element **taxiway**
annotation	documentation Supports legacy EDMS studies relating to the TAXIWAYS table. Taxi nodes define the points for a given taxiway.

element **taxipath**

diagram	

properties	content complex
children	**gateName** **runwayName** **direction** **taxiwayName**
used by	element **taxipathSet**
annotation	documentation Supports legacy EDMS studies relating to the TAXIPATHS table. A taxipath is a sequence of taxiways, possibly just one, that connects a gate to a runway or vice versa. Taxipaths are used to do the modeling of aircraft ground movement. They are needed for sequence modeling, which includes all dispersion analyses. Gates, taxiways and runways must be defined before taxipaths can be specified.

element **taxipath/gateName**

diagram	
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation References an existing gate.

element **taxipath/runwayName**

diagram	
type	**string8**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation References an existing runway.

element **taxipath/direction**

diagram	
type	**directionType**
properties	content simple
facets	Kind Value Annotation pattern A|Arrival|D|Departure|I|Inbound|O|Outbound

annotation	documentation Direction of the taxipath. Valid values: Inbound or Outbound.

element **taxipath/taxiwayName**

diagram	
type	**string20**
properties	minOcc 1 maxOcc unbounded content simple
facets	Kind Value Annotation minLength 0 maxLength 20
annotation	documentation References an existing taxiway.

element **taxipathSet**

diagram	
properties	content complex
children	**taxipath**
used by	complexType **airportLayoutType**
annotation	documentation Supports legacy EDMS studies relating to the TAXIPATHS table. A taxipath is a sequence of taxiways, possibly just one, that connects a gate to a runway or vice versa. Taxipaths are used to do the modeling of aircraft ground movement. They are needed for sequence modeling, which includes all dispersion analyses. Gates, taxiways and runways must be defined before taxipaths can be specified.

element **taxiTime**

diagram	
properties	content complex
children	**source** **taxiIn** **taxiOut**
used by	complexType **airport**

element **taxiTime/source**

diagram	
type	**string6**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation

	minLength 0 maxLength 6

element **taxiTime/taxiIn**

diagram	taxiIn
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple

element **taxiTime/taxiOut**

diagram	taxiOut
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple

element **taxiway**

diagram	
properties	content complex
children	**name** **dispersionWidth** **taxiNodeSet**
used by	element **taxiwaySet**
annotation	documentation Supports legacy EDMS studies relating to the TAXIWAYS table. Taxiways determine the ground segments where the aircraft operates.

element **taxiway/name**

diagram	name Identifying name for taxiway.
type	**string20**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 20
annotation	documentation Identifying name for taxiway.

element **taxiway/dispersionWidth**

diagram	dispersionWidth Width of emission dispersion around taxiway. Valid values: 0 to 100. (m)
type	**doubleExclusive100**
properties	minOcc 0

	maxOcc 1 content simple default 1
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation Width of emission dispersion around taxiway. Valid values: 0 to 100. (m)

element **taxiwaySet**

diagram	
properties	content complex
children	**taxiway**
used by	complexType **airportLayoutType**
annotation	documentation Supports legacy EDMS studies relating to the TAXIWAYS table. Taxiways determine the ground segments where the aircraft operates.

element **track**

diagram	
properties	content complex
children	**name** **optype** **wingtype** **airport** **runway** **vectorCourseHelipad** **backbone** **subtrack**
used by	elements **trackOpSet** **trackSet**
annotation	documentation A flight track that can be used for flight operations.

element **track/name**

diagram	

type	**string64**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 64
annotation	documentation The name of the track.

element **track/optype**

diagram	
type	**trackType**
properties	content simple
facets	Kind Value Annotation pattern A|Arrival|D|Departure|V|Overflight|T|TouchAndGo|X|ArrivalHeliTaxi|O|DepartureHeliTaxi
annotation	documentation Type of track. (A = arrival, D = departure, V = overflight, T = Touch and Go)

element **track/wingtype**

diagram	
type	**wingType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern F|FixedWing|R|RotaryWing
annotation	documentation Type of wing. (F = fixed wing, R = rotary wing)

element **track/airport**

diagram	
type	**airportCode**
properties	minOcc 0 maxOcc 1 content complex
facets	Kind Value Annotation minLength 0 maxLength 4
attributes	Name Type Use Default Fixed Annotation type **airportCodeType** optional ANY country **string3** optional ANY
annotation	documentation The IATA airport code.

element **track/runway**

diagram	runway The name of the runway.
type	**string8**
properties	minOcc 0 maxOcc 1 content simple
used by	element **runwaySet**
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation The name of the runway.

element **track/vectorCourseHelipad**

diagram	vectorCourseHelipad Direction for helicopter operations of vector type (angle from North).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Direction for helicopter operations of vector type (angle from North).

element **trackNode**

diagram	

properties	content complex
children	**id** **description** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **altitude** **speed**
used by	elements **backboneNode** **trackNodes**
annotation	documentation A flight track node.

element **trackNode/altitude**

diagram	
type	extension of **xs:double**
properties	minOcc 0 maxOcc 1 content complex
attributes	Name: control; Type: **nodeControlType**; Use: optional; Default; Fixed; Annotation
annotation	documentation Node's altitude above or below MSL (feet). Includes attribute node.

attribute **trackNode/altitude/@control**

type	**nodeControlType**
properties	use optional
facets	Kind Value Annotation pattern 0|None|1|AtOrBelow|2|Match|3|AtOrAbove

element **trackNode/speed**

diagram	
type	extension of **xs:double**
properties	minOcc 0 maxOcc 1 content complex
attributes	Name Type Use Default Fixed Annotation control **nodeControlType** optional
annotation	documentation Speed of aircraft at node (KCAS). Includes attribute node. Valid values: nonnegative, Units: knots

attribute **trackNode/speed/@control**

type	**nodeControlType**
properties	use optional
facets	Kind Value Annotation pattern 0|None|1|AtOrBelow|2|Match|3|AtOrAbove

element **trackNodes**

diagram	
properties	content complex
children	**trackNode**
used by	element **subtrack**
annotation	documentation A set of flight track nodes

element **trackOpSet**

diagram	
properties	content complex
children	**track** **trackref** **sensorPath** **operations**
used by	elements **AsifXml** **case**

annotation	documentation Lists tracks and associated operations.

element **trackref**

diagram	
properties	content complex
children	**airportLayoutName** **trackName** **optype** **runway**
used by	element **trackOpSet**
annotation	documentation Reference to a flight track.

element **trackref/airportLayoutName**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airport layout associated with this track.

element **trackref/trackName**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Name of flight track.

element **trackref/optype**

diagram	
type	**trackType**
properties	content simple
facets	Kind Value Annotation pattern A|Arrival|D|Departure|V|Overflight|T|TouchAndGo|X|ArrivalHeliTaxi|O|DepartureHeliTaxi

element **trackref/runway**

diagram	

type	**string8**
properties	minOcc 0 maxOcc 1 content simple
used by	element **runwaySet**
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation Name of runway on the flight track.

element **trackSet**

diagram	
properties	content complex
children	**track**
used by	complexType **airportLayoutType**
annotation	documentation A set of flight tracks.

element **trackVector**

diagram	
properties	content complex
children	**id** **description** **type** **distance** **angle** **radius**
used by	element **trackVectors**
annotation	documentation A flight track vector.

element **trackVector/type**

diagram	
type	**vectorTrackType**
properties	content simple
facets	Kind Value Annotation pattern S|Straight|L|LeftTurn|R|RightTurn

annotation	documentation Type of vector. Valid values: S = Straight, L = LeftTurn, R = RightTurn.

element **trackVector/distance**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Distance flown along this vector. Valid values: nonnegative. (nmi)

element **trackVector/angle**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Angle of the vector. (decimal degrees)

element **trackVector/radius**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Radius of the vector. Valid values: nonnegative. (nmi)

element **trackVectors**

diagram	
properties	content complex
children	**trackVector**
used by	element **subtrack**
annotation	documentation A list of flight track vectors.

element **userDefinedAirportSet**

diagram	
properties	content complex
children	**userDefinedAirport**
used by	element **study**
attributes	Name Type Use Default Fixed Annotation

	dummy **xs:int** optional
annotation	documentation Contains user-defined airports.

attribute **userDefinedAirportSet/@dummy**

type	**xs:int**
properties	use optional

element **userDefinedAirportSet/userDefinedAirport**

diagram

type	**airport**
properties	minOcc 1 maxOcc unbounded content complex
children	**airportCode** **effDate** **expDate** **name** **state** **facilityType** **cityName** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **elevation** **patternAltitude** **tower** **layout** **archiveFlag** **dafifId** **faaId** **shell1** **smad** **zone** **airportWeather** **windRose** **taxiTime**
annotation	documentation Contains information for each user-defined airport. APT_CODE must not duplicate an existing system airport.

element **userGroundSupportEquipment**

diagram	

properties	content complex
children	**gseID** **gseName** **defaultLoadFactor** **defaultHorsepower** **defaultOpTimeDepartures** **defaultOpTimeArrivals** **defaultAnnualOpTime** **userEmissionFactors**
used by	element **userGroundSupportEquipmentSet**
annotation	documentation Supports legacy EDMS studies relating to content contained in the USER_CREATED_GSE table. This element supports the definition of user defined ground support equipment.

element **userGroundSupportEquipment/gseID**

diagram	**gseID** User GSE ID (used as identifier (System GSE ID) in AIRCRAFT_GSE_ASSIGNMENTS, GSE_POPULATION, GSE_POPULATION_GATE_ASSIGNMENTS).
type	**xs:int**
properties	content simple
annotation	documentation User GSE ID (used as identifier (System GSE ID) in AIRCRAFT_GSE_ASSIGNMENTS, GSE_POPULATION, GSE_POPULATION_GATE_ASSIGNMENTS).

element **userGroundSupportEquipment/gseName**

diagram	**gseName** Custom GSE name.
type	**string40**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation Custom GSE name.

element **userGroundSupportEquipment/defaultLoadFactor**

diagram	**defaultLoadFactor** GSE default load factor. Valid values: 0 to 100. (%)
type	**doubleInclusive1**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation GSE default load factor. Valid values: 0 to 100. (%)

element **userGroundSupportEquipment/defaultHorsepower**

diagram	**defaultHorsepower** GSE default horsepower. Valid values: 0 to 10000. (hp)
type	**xs:double**
properties	content simple
annotation	documentation GSE default horsepower. Valid values: 0 to 10000. (hp)

element **userGroundSupportEquipment/defaultOpTimeDepartures**

diagram	**defaultOpTimeDepartures** GSE default operation time departures. Valid values: 0 to 1000. (min/LTO)
type	**xs:double**
properties	content simple
annotation	documentation GSE default operation time departures. Valid values: 0 to 1000. (min/LTO)

element **userGroundSupportEquipment/defaultOpTimeArrivals**

diagram	**defaultOpTimeArrivals** GSE default operation time arrivals. Valid values: 0 to 1000. (min/LTO)
type	**xs:double**
properties	content simple
annotation	documentation GSE default operation time arrivals. Valid values: 0 to 1000. (min/LTO)

element **userGroundSupportEquipment/defaultAnnualOpTime**

diagram	**defaultAnnualOpTime** GSE default operation time annual. Valid values: 0 to 8784. (min/LTO)
type	**xs:double**
properties	content simple
annotation	documentation GSE default operation time annual. Valid values: 0 to 8784. (min/LTO)

element **userGroundSupportEquipment/userEmissionFactors**

diagram	

properties	content complex
children	**emissionFactorsDiesel** **emissionFactorsGas** **emissionFactorsCNG** **emissionFactorsLPG**
annotation	documentation Describes user-defined fuel emission factors.

element **userGroundSupportEquipment/userEmissionFactors/emissionFactorsDiesel**

diagram	
type	**emissionFactorSet**
properties	minOcc 0 maxOcc 1 content complex
children	**CO** **HC** **NOx** **SOx** **PM10**
annotation	documentation User-defined fuel emission factor for diesel.

element **userGroundSupportEquipment/userEmissionFactors/emissionFactorsGas**

diagram	

type	**emissionFactorSet**
properties	minOcc 0 maxOcc 1 content complex
children	**CO HC NOx SOx PM10**
annotation	documentation User-defined fuel emission factor for gasoline.

element **userGroundSupportEquipment/userEmissionFactors/emissionFactorsCNG**

diagram	
type	**emissionFactorSet**
properties	minOcc 0 maxOcc 1 content complex
children	**CO HC NOx SOx PM10**
annotation	documentation User-defined fuel emission factor for compressed natural gas.

element **userGroundSupportEquipment/userEmissionFactors/emissionFactorsLPG**

diagram	

type	**emissionFactorSet**
properties	minOcc 0 maxOcc 1 content complex
children	**CO HC NOx SOx PM10**
annotation	documentation User-defined fuel emission factor for liquefied petroleum gas.

element **userGroundSupportEquipmentSet**

diagram	
properties	content complex
children	**userGroundSupportEquipment**
used by	elements **AsifXml** **study**
attributes	Name Type Use Default Fixed Annotation dummy **xs:int** optional
annotation	documentation Supports legacy EDMS studies relating to content contained in the USER_CREATED_GSE table. This element supports the definition of user defined ground support equipment.

attribute **userGroundSupportEquipmentSet/@dummy**

type	**xs:int**
properties	use optional

element **vehicleEmissionFactors**

diagram	

properties	content complex
children	**CO** **NMHC** **VOC** **THC** **TOG** **NOx** **SOx** **PM-10** **PM-2.5** **Benzene** **MTBE** **Butadiene** **Formaldehyde** **Acetaldehyde** **Acrolein**
used by	elements **parkingFacilityOperation** **roadwayOperation**
annotation	documentation Supports legacy EDMS studies relating to content contained in the ROADWAYS/PARKING table. This element supports the definition of custom emission factor specifications for roadways and parking.

element **vehicleEmissionFactors/CO**

diagram	CO Amount of carbon monoxide emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of carbon monoxide emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/NMHC**

diagram	NMHC Amount of non-methane hydrocarbons emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of non-methane hydrocarbons emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/VOC**

diagram	VOC Amount of volatile organic compounds emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of volatile organic compounds emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/THC**

diagram	THC Amount of total hydrocarbons emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Amount of total hydrocarbons emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/TOG**

diagram	TOG Amount of total organic gasses emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of total organic gasses emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/NOx**

diagram	NOx Amount of nitrous oxides emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

type	**xs:double**
properties	content simple
annotation	documentation Amount of nitrous oxides emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/SOx**

diagram	**SOx** Amount of sulfur oxides emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of sulfur oxides emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/PM-10**

diagram	**PM-10** Amount of 10-micron particulate matter emitted. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of 10-micron particulate matter emitted. (grams/vehicle-mile)

element **vehicleEmissionFactors/PM-2.5**

diagram	**PM-2.5** Amount of 2.5-micron particulate matter emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of 2.5-micron particulate matter emitted. Valid Values: 0 to 20000. (grams/vehicle-mile)

element **vehicleEmissionFactors/Benzene**

diagram	**Benzene** Amount of benzene emitted. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of benzene emitted. (grams/vehicle-mile)

element **vehicleEmissionFactors/MTBE**

diagram	**MTBE** Amount of methyl tertiary butyl ether emitted. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of methyl tertiary butyl ether emitted. (grams/vehicle-mile)

element **vehicleEmissionFactors/Butadiene**

diagram	**Butadiene** Amount of butadiene emitted. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of butadiene emitted. (grams/vehicle-mile)

element **vehicleEmissionFactors/Formaldehyde**

diagram	**Formaldehyde** Amount of formaldehyde emitted. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of formaldehyde emitted. (grams/vehicle-mile)

element **vehicleEmissionFactors/Acetaldehyde**

diagram	**Acetaldehyde** Amount of acetaldehyde emitted. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of acetaldehyde emitted. (grams/vehicle-mile)

element **vehicleEmissionFactors/Acrolein**

diagram	**Acrolein** Amount of acrolein emitted. (grams/vehicle-mile)
type	**xs:double**
properties	content simple
annotation	documentation Amount of acrolein emitted. (grams/vehicle-mile)

element **volumeStationarySource**

diagram	
properties	content complex

children	**pointCoord** **baseElevation** **releaseHeight** **sigmaZ** **sigmaY**
used by	element **stationarySource**
annotation	documentation Specifies the volume in space occupied by a stationary source of emissions.

element **volumeStationarySource/pointCoord**

diagram

type	**coord2DType**
properties	content complex
children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone**
annotation	documentation Type of 2D coordinates specifying the volume.

element **volumeStationarySource/baseElevation**

diagram

type	**xs:double**
properties	content simple
annotation	documentation Height of volume. (m)

element **volumeStationarySource/releaseHeight**

diagram

type	**doubleInclusive100**
properties	minOcc 0 maxOcc 1 content simple default 0

facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Height at which emissions are released into the atmosphere. Valid values 0 to 100 (m)

element **volumeStationarySource/sigmaZ**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Vertical dispersion parameter. For additional information, see the EDMS Application Manual. Valid values: 0.1 to 100.0. (m)

element **volumeStationarySource/sigmaY**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Horizontal dispersion parameter. For additional information, see the EDMS Application Manual. Valid values: 0.1 to 100.0. (m)

element **weatherData**

diagram	
properties	content complex
children	**year** **temperature** **seaLevelPressure** **stationPressure** **dewPoint** **relativeHumidity** **windSpeed**
used by	element **airportWeatherStation**

element **weatherData/year**

diagram	
type	**weatherDataYear**
properties	content simple

element **weatherData/temperature**

diagram	temperature
type	**xs:decimal**
properties	minOcc 0 maxOcc 1 content simple

element **weatherData/seaLevelPressure**

diagram	seaLevelPressure
type	**xs:decimal**
properties	minOcc 0 maxOcc 1 content simple

element **weatherData/stationPressure**

diagram	stationPressure
type	**xs:decimal**
properties	minOcc 0 maxOcc 1 content simple

element **weatherData/dewPoint**

diagram	dewPoint
type	**xs:decimal**
properties	minOcc 0 maxOcc 1 content simple

element **weatherData/relativeHumidity**

diagram	relativeHumidity
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple

element **weatherData/windSpeed**

diagram	windSpeed
type	**xs:decimal**
properties	content simple

element **windRose**

diagram	windRose windRoseStationId windRoseStation
properties	content complex
children	**windRoseStationId** **windRoseStation**
used by	complexType **airport**

element **windRose/windRoseStationId**

diagram	windRoseStationId

type	**string5**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 5

element **windRoseData**

diagram	
properties	content complex
children	**directionRange centerDirection S01TO04KTS S04TO07KTS S07TO11KTS S11TO17KTS S17TO22KTS S22TO28KTS S28TO34KTS S34TO41KTS S41PLUSKTS DIRTOTAL**
used by	element **windRoseStation**

element **windRoseData/directionRange**

diagram	
type	**string14**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 14

element **windRoseData/centerDirection**

diagram	
type	**xs:int**
properties	content simple

element **windRoseData/S01TO04KTS**

diagram	
type	**xs:int**
properties	content simple

element **windRoseData/S04TO07KTS**

diagram	
type	**xs:int**

properties	content simple

element **windRoseData/S07TO11KTS**

diagram	S07TO11KTS
type	**xs:int**
properties	content simple

element **windRoseData/S11TO17KTS**

diagram	S11TO17KTS
type	**xs:int**
properties	content simple

element **windRoseData/S17TO22KTS**

diagram	S17TO22KTS
type	**xs:int**
properties	content simple

element **windRoseData/S22TO28KTS**

diagram	S22TO28KTS
type	**xs:int**
properties	content simple

element **windRoseData/S28TO34KTS**

diagram	S28TO34KTS
type	**xs:int**
properties	content simple

element **windRoseData/S34TO41KTS**

diagram	S34TO41KTS
type	**xs:int**
properties	content simple

element **windRoseData/S41PLUSKTS**

diagram	S41PLUSKTS
type	**xs:int**
properties	content simple

element **windRoseData/DIRTOTAL**

diagram	DIRTOTAL
type	**xs:int**
properties	content simple

element **windRoseStation**

diagram	

properties	content complex
children	**windRoseStationId** **startDate** **endDate** **windRoseStationDescription** **windRoseDataSource** **windRoseDataSet** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **windRoseStationElevationFeet** **averageWindSpeed** **beginYear** **endYear** **beginDayMonth** **endDayMonth** **directionUnit** **calmCriteria** **calms** **missing** **good** **total**

	userString windRoseData
used by	element **windRose**

element **windRoseStation/windRoseStationId**

diagram	windRoseStationId
type	**string5**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 5

element **windRoseStation/startDate**

diagram	startDate
type	**xs:date**
properties	content simple

element **windRoseStation/endDate**

diagram	endDate
type	**xs:date**
properties	content simple

element **windRoseStation/windRoseStationDescription**

diagram	windRoseStationDescription
type	**string42**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 42

element **windRoseStation/windRoseDataSource**

diagram	windRoseDataSource
type	**string32**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 32

element **windRoseStation/windRoseDataSet**

diagram	windRoseDataSet
type	**string66**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 66

element **windRoseStation/windRoseStationElevationFeet**

diagram	windRoseStationElevationFeet
type	**xs:int**

properties	content simple

element **windRoseStation/averageWindSpeed**

diagram	averageWindSpeed
type	**xs:double**
properties	content simple

element **windRoseStation/beginYear**

diagram	beginYear
type	**xs:int**
properties	content simple

element **windRoseStation/endYear**

diagram	endYear
type	**xs:int**
properties	content simple

element **windRoseStation/beginDayMonth**

diagram	beginDayMonth
type	**string12**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 12

element **windRoseStation/endDayMonth**

diagram	endDayMonth
type	**string11**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 11

element **windRoseStation/directionUnit**

diagram	directionUnit
type	**string9**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 9

element **windRoseStation/calmCriteria**

diagram	calmCriteria
type	**string11**
properties	content simple
facets	Kind Value Annotation minLength 0

	maxLength 11

element **windRoseStation/calms**

diagram	calms
type	**xs:int**
properties	content simple

element **windRoseStation/missing**

diagram	missing
type	**xs:int**
properties	content simple

element **windRoseStation/good**

diagram	good
type	**xs:int**
properties	content simple

element **windRoseStation/total**

diagram	total
type	**xs:int**
properties	content simple

element **windRoseStation/userString**

diagram	userString
type	**string11**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 11

group **airportActivityGroup**

diagram	
children	**parkingFacilityOperationSet** **roadwayOperationSet** **stationarySourceOperationSet** **groundSupportEquipmentPopulationOperationSet**
used by	element **case**

annotation	documentation Contains a set of activities conducted at an airport.

group **annualizationGroupCase**

diagram	
children	**annualizationGroup** **annualizationCase**
used by	element **annualizationGroup**
annotation	documentation Allows for grouping cases into groups, and groups into parent groups.

group **coord2DGroup**

diagram	
children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone**
used by	elements **airportWeatherStation** **centroid** **grid** **pointReceptor** **polarGrid** **polarReceptor** **taxiNode** **trackNode** **windRoseStation** complexTypes **airport** **airportLayoutType** **runup** **runwayEnd**
annotation	documentation Indicates how a two-dimensional group is specified.

group **latlonCoordGroup**

diagram	

children	**latitude** **latitudeDMS** **longitude** **longitudeDMS**
used by	complexType **coord2DType** group **coord2DGroup**
annotation	documentation Specifies a coordinate using latitude and longitude.

element **latlonCoordGroup/latitude**

diagram	
type	**latitudeDecimalType**
properties	content complex
attributes	Name: positive; Type: **derived by: xs:string**; Use: optional; Default: N; Fixed: ; Annotation:
annotation	documentation Latitude specified as degrees in decimal format. Can include optional attribute positive.

element **latlonCoordGroup/latitudeDMS**

diagram	
type	**latitudeDMSType**
properties	content simple
facets	Kind: pattern; Value: [0-9]{2}[\-|:|"][0-9]{2}[\-|:|'][0-9]{2}(.[0-9]{3})?[N|n|S|s]; Annotation:
annotation	documentation Latitude expressed as dd°mm'sss with optional indicator N, n, S, s.

element **latlonCoordGroup/longitude**

diagram	
type	**longitudeDecimalType**
properties	content complex

attributes	Name	Type	Use	Default	Fixed	Annotation
	positive	**derived by: xs:string**	optional	E		

annotation
documentation
Longitude specified as degrees in decimal format. Can include optional attribute positive.

element **latlonCoordGroup/longitudeDMS**

diagram

Longitude expressed as dd"mm'sss with optional indicator N, n, S, s.

type **longitudeDMSType**

properties content simple

facets

Kind	Value	Annotation
pattern	[0-9]?[0-9]{2}[\-|:|"][0-9]{2}[\-|:|'][0-9]{2}(.[0-9]{3})?[E|e|W|w]	

annotation
documentation
Longitude expressed as dd"mm'sss with optional indicator N, n, S, s.

group **nodeIdGroup**

diagram

children **id** **description**

used by elements **trackNode** **trackVector**

annotation
documentation
A group of nodes.

element **nodeIdGroup/id**

diagram

String identifier for the grouping of nodes.

type **string16**

properties
minOcc 0
maxOcc 1
content simple

facets

Kind	Value	Annotation
minLength	0	
maxLength	16	

annotation
documentation
String identifier for the grouping of nodes.

element **nodeIdGroup/description**

diagram

An optional description for the grouping of nodes.

type **string16**

properties
minOcc 0
maxOcc 1
content simple

facets

Kind	Value	Annotation
minLength	0	
maxLength	16	

annotation
documentation
An optional description for the grouping of nodes.

group **oneOrThreeCoords2DGroupSet**

diagram	
children	**pointCoord** **polygonCoords**
used by	elements **areaStationarySource** **building** **gate** **parkingFacility**
annotation	documentation Type of coordinate specifying the area.

element **oneOrThreeCoords2DGroupSet/pointCoord**

diagram	
type	**coord2DType**
properties	content complex
children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone**
annotation	documentation Choice of a single point coordinate.

element **oneOrThreeCoords2DGroupSet/polygonCoords**

diagram	
type	**polygon2DType**
properties	content complex

children	**dummy** **vertex**
annotation	documentation Choice of a 2D polygon.

group **receptorGroup**

diagram	
children	**centroid** **pointReceptor** **grid** **polarReceptor** **polarGrid**
used by	element **receptorSet**
annotation	documentation Description of a receptor group.

group **utmCoordGroup**

diagram	
children	**utmN** **utmE** **utmZone**
used by	complexType **coord2DType** group **coord2DGroup**
annotation	documentation Specifies a point using Universal Transverse Mercator coordinates.

element **utmCoordGroup/utmN**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation

	UTM Northing of the point in decimal meters north of the equator.

element **utmCoordGroup/utmE**

diagram	**utmE** UTM Easting of the point in decimal meters east from a central meridian.
type	**xs:double**
properties	content simple
annotation	documentation UTM Easting of the point in decimal meters east from a central meridian.

element **utmCoordGroup/utmZone**

diagram	**utmZone** UTM Zone of the point. A default zone can be set in the <options> tag.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple default -1
annotation	documentation UTM Zone of the point. A default zone can be set in the <options> tag.

complexType **aircraft**

diagram

children	**description** **airframeModel** **engineCode** **engineModCode** **anpAirplaneId** **badaAirplaneId** **anpHelicopterId** **bada4AirplaneModel** **bada4Engine** **bada4Suffix** **bada4FlapsMapSourceAnpId**

used by	element **fleet/aircraft**
annotation	documentation Main block for creating new user defined AEDT aircraft.

element **aircraft/description**

diagram	**description** The description for this user defined aircraft.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The description for this user defined aircraft.

element **aircraft/airframeModel**

diagram	**airframeModel** The airframe model used for this user defined aircraft.
type	**airframeModel**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The airframe model used for this user defined aircraft.

element **aircraft/engineCode**

diagram	**engineCode** The engine code used for this user defined aircraft.
type	**engineCode**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The engine code used for this user defined aircraft.

element **aircraft/engineModCode**

diagram	**engineModCode** The engine modification code used for this user defined aircraft.
type	**engineModCode**
properties	minOcc 0 maxOcc 1 content simple default NONE
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation The engine modification code used for this user defined aircraft.

element **aircraft/anpAirplaneId**

diagram	**anpAirplaneId** The ANP airplane linked to this user defined aircraft.
type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The ANP airplane linked to this user defined aircraft.

element **aircraft/badaAirplaneId**

diagram	**badaAirplaneId** The BADA airplane linked to this user defined aircraft.
type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The BADA airplane linked to this user defined aircraft.

element **aircraft/anpHelicopterId**

diagram	**anpHelicopterId** The ANP helicopter linked to this user defined helicopter.
type	**anpHeloId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The ANP helicopter linked to this user defined helicopter.

element **aircraft/bada4AirplaneModel**

diagram	**bada4AirplaneModel** Airplane's BADA 4 model.
type	**bada4AirplaneModel**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's BADA 4 model.

element **aircraft/bada4Engine**

diagram	**bada4Engine** Airplane's BADA 4 engine.
type	**bada4Engine**
properties	content simple
facets	Kind Value Annotation

	minLength 0 maxLength 255
annotation	documentation Airplane's BADA 4 engine.

element **aircraft/bada4Suffix**

diagram	**bada4Suffix** User-defined BADA 4 model suffix.
type	**bada4Suffix**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation User-defined BADA 4 model suffix.

element **aircraft/bada4FlapsMapSourceAnpId**

diagram	**bada4FlapsMapSourceAnpId** Source ANP airplane ID for mapping ANP flaps to BADA 4.
type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Source ANP airplane ID for mapping ANP flaps to BADA 4.

complexType **aircraftEngine**

diagram	

children	**code** **model** **engineType** **notes** **emissionsEngineModel** **performanceEngineModel** **manufacturer** **combustor** **superseded** **ratedEngineOut** **source** **bypassRatio** **pressureRatio** **tfmtFlag** **defaultSOx** **taxiIdleEmissionFactors** **takeOffEmissionFactors** **climbEmissionFactors** **approachEmissionFactors**
used by	element **fleet/engine**
annotation	documentation User defined engine information containing custom parameters that reflect an aircraft engine. This engine definition can that be used within a user defined aircraft.

element **aircraftEngine/code**

diagram	**code** Unique ICAO UID.
type	**engineCode**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Unique ICAO UID.

element **aircraftEngine/model**

diagram	**model** Engine model.
type	**engineModel**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Engine model.

element **aircraftEngine/engineType**

diagram	**engineType** Engine type. Valid values: J (jet), T (turboprop), P (piston).
type	**engineType**
properties	content simple
facets	Kind Value Annotation pattern Jet|J|Turbo|Turboprop|T|Prop|Piston|P
annotation	documentation Engine type. Valid values: J (jet), T (turboprop), P (piston).

element **aircraftEngine/notes**

diagram	**notes** Free-text notes for the engine.
type	**string200**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 200
annotation	documentation Free-text notes for the engine.

element **aircraftEngine/emissionsEngineModel**

diagram	**emissionsEngineModel** ICAO emissions model for the engine.
type	**string25**
properties	minOcc 0

	maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 25
annotation	documentation ICAO emissions model for the engine.

element **aircraftEngine/performanceEngineModel**

diagram	**performanceEngineModel** ICAO performance model for the engine.
type	**string25**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 25
annotation	documentation ICAO performance model for the engine.

element **aircraftEngine/manufacturer**

diagram	**manufacturer** Engine manufacturer.
type	**string100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Engine manufacturer.

element **aircraftEngine/combustor**

diagram	**combustor** Combustor used on engine.
type	**string50**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation Combustor used on engine.

element **aircraftEngine/superseded**

diagram	**superseded** ICAO UID of engine that supersedes the given engine.
type	**string10**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation

	minLength 0 maxLength 10
annotation	documentation ICAO UID of engine that supersedes the given engine.

element **aircraftEngine/ratedEngineOut**

diagram	**ratedEngineOut** Rated engine output (in kN). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Rated engine output (in kN). Valid values: Nonnegative.

element **aircraftEngine/source**

diagram	**source** Source of engine data.
type	**string100**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Source of engine data.

element **aircraftEngine/bypassRatio**

diagram	**bypassRatio** Engine's bypass ratio. Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Engine's bypass ratio. Valid values: Nonnegative.

element **aircraftEngine/pressureRatio**

diagram	**pressureRatio** Engine's pressure ratio. Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Engine's pressure ratio. Valid values: Nonnegative.

element **aircraftEngine/tfmtFlag**

diagram	**tfmtFlag** Turbo-fan or Mixed turn-fan flag. Valid values: TF (turbofan) or MTF (mixed turbofan).

type	**string50**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation Turbo-fan or Mixed turn-fan flag. Valid values: TF (turbofan) or MTF (mixed turbofan).

element **aircraftEngine/defaultSOx**

diagram	**defaultSOx** Sulfur oxides emitted (grams per kilogram of fuel). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Sulfur oxides emitted (grams per kilogram of fuel). Valid values: Nonnegative.

element **aircraftEngine/taxiIdleEmissionFactors**

diagram	
type	**engineModeEmissions**
properties	content complex
children	**time fuel CO HC NOx SOx SN PM**
annotation	documentation Emission factor when aircraft is idling.

element **aircraftEngine/takeOffEmissionFactors**

diagram	
type	**engineModeEmissions**
properties	content complex
children	**time** **fuel** **CO** **HC** **NOx** **SOx** **SN** **PM**
annotation	documentation Emission factor when aircraft is taking off.

element **aircraftEngine/climbEmissionFactors**

diagram	

type	**engineModeEmissions**
properties	content complex
children	**time** **fuel** **CO** **HC** **NOx** **SOx** **SN** **PM**
annotation	documentation Emission factor when aircraft is climbing.

element **aircraftEngine/approachEmissionFactors**

diagram	

type	**engineModeEmissions**
properties	content complex
children	**time** **fuel** **CO** **HC** **NOx** **SOx** **SN** **PM**
annotation	documentation Emission factor when aircraft is on approach.

complexType **aircraftEngineMod**

diagram	
children	**code** **description**
used by	element **fleet/engineMod**
annotation	documentation User defined engine modification information containing custom parameters that reflect an aircraft engine modification. This engine modification definition can that be used within a user defined aircraft.

element **aircraftEngineMod/code**

diagram	
type	**engineModCode**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 50

annotation	documentation Unique ICAO UID.

element **aircraftEngineMod/description**

diagram	**description** Description of engine modifications.
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Description of engine modifications.

complexType **aircraftType**

diagram	
children	**anpAircraftId** **airframeModel** **engineCode** **engineModCode** **apuName** **groundSupportEquipmentLTOOperationSet** **assignDefaultGse**
used by	elements **operation/aircraftType** **runup/aircraftType**
annotation	documentation Characterizes an aircraft.

element **aircraftType/anpAircraftId**

diagram	**anpAircraftId**
type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255

element **aircraftType/airframeModel**

diagram	**airframeModel** Air frame model.

type	**string50**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation Air frame model.

element **aircraftType/engineCode**

diagram	**engineCode** Engine code. Valid values: E (Electric), J (Jet), P (Piston), T (Turboprop).
type	**string25**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 25
annotation	documentation Engine code. Valid values: E (Electric), J (Jet), P (Piston), T (Turboprop).

element **aircraftType/engineModCode**

diagram	**engineModCode** Engine modification code. (AEDT database reference table FLEET.FLT_ENGINE_MODS column ENGINE_MOD_CODE.)
type	**engineModCode**
properties	minOcc 0 maxOcc 1 content simple default NONE
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation Engine modification code. (AEDT database reference table FLEET.FLT_ENGINE_MODS column ENGINE_MOD_CODE.)

element **aircraftType/apuName**

diagram	**apuName** Name of auxiliary power unit used by this type of aircraft.
type	**xs:string**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Name of auxiliary power unit used by this type of aircraft.

element **aircraftType/assignDefaultGse**

diagram	**assignDefaultGse** Whether the application should assign default GSE for this operation or not
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple

	default false
annotation	documentation Whether the application should assign default GSE for this operation or not

complexType **airframe**

diagram	
children	**model** **engineCount** **engineLocation** **designationCode** **maxRange** **introYear** **euroGroupCode** **usageCode** **sizeCode** **engineType** **auxiliaryPowerUnitId**
used by	element **fleet/airframe**
annotation	documentation This element supports the definition of custom airframes.

element **airframe/model**

diagram	
type	**airframeModel**
properties	content simple

facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Unique description of airframe.

element **airframe/engineCount**

diagram	**engineCount** Number of engines on airframe.
type	**xs:int**
properties	content simple
annotation	documentation Number of engines on airframe.

element **airframe/engineLocation**

diagram	**engineLocation** Position of engine on airframe. Valid values: F (Fuselage/Tail), W (Wing).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Position of engine on airframe. Valid values: F (Fuselage/Tail), W (Wing).

element **airframe/designationCode**

diagram	**designationCode** Type of aviation. Valid values: C (Civil), G (General Aviation), M (Military).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of aviation. Valid values: C (Civil), G (General Aviation), M (Military).

element **airframe/maxRange**

diagram	**maxRange** Number of miles airframe can fly fully fueled. Valid values: Nonnegative.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Number of miles airframe can fly fully fueled. Valid values: Nonnegative.

element **airframe/introYear**

diagram	**introYear** Year airframe was introduced. Valid values: Nonnegative.

type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Year airframe was introduced. Valid values: Nonnegative.

element **airframe/euroGroupCode**

diagram	**euroGroupCode** European group code for this airframe. Valid values: H1 (Helicopter Light), H2 (Helicopter Heavy), JB (Jet Business), JL (Jet Large), JM (Jet Medium), JR (Jet Regional), JS (Jet Small), PP (Propeller), SS (Supersonic), TP (Turboprop).
type	**string2**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 2
annotation	documentation European group code for this airframe. Valid values: H1 (Helicopter Light), H2 (Helicopter Heavy), JB (Jet Business), JL (Jet Large), JM (Jet Medium), JR (Jet Regional), JS (Jet Small), PP (Propeller), SS (Supersonic), TP (Turboprop).

element **airframe/usageCode**

diagram	**usageCode** Usage code for this airframe. Valid values: H (Heavy), L (Large), M (Medium), S (Small), T (Light), V (Very Light).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Usage code for this airframe. Valid values: H (Heavy), L (Large), M (Medium), S (Small), T (Light), V (Very Light).

element **airframe/sizeCode**

diagram	**sizeCode** Size code for this airframe. Valid values: H (Heavy), L (Large), M (Medium), S (Small), T (Light), V (Very Light).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Size code for this airframe. Valid values: H (Heavy), L (Large), M (Medium), S (Small), T (Light), V (Very Light).

element **airframe/engineType**

diagram	**engineType** Type of engine on this airframe. Valid values: E (Electric), J (Jet), P (Piston), T (Turboprop).

type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of engine on this airframe. Valid values: E (Electric), J (Jet), P (Piston), T (Turboprop).

element **airframe/auxiliaryPowerUnitId**

diagram	**auxiliaryPowerUnitId** Identifier of an auxiliary power unit.
type	**apuName**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 30
annotation	documentation Identifier of an auxiliary power unit.

complexType **airport**

diagram

children	**airportCode** **effDate** **expDate** **name** **state** **facilityType** **cityName** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **elevation** **patternAltitude** **tower** **layout** **archiveFlag** **dafifId** **faaId** **shell1** **smad** **zone** **airportWeather** **windRose** **taxiTime**
used by	element **userDefinedAirportSet/userDefinedAirport**
annotation	documentation Contains core airport information such as airport name, latitude/longitude, elevation, etc.

element **airport/airportCode**

diagram	
type	**airportCode**
properties	content complex

facets	Kind	Value	Annotation			
	minLength	0				
	maxLength	4				
attributes	Name	Type	Use	Default	Fixed	Annotation
	type	**airportCodeType**	optional	ANY		
	country	**string3**	optional	ANY		

element **airport/effDate**

diagram	**effDate** Effective date for the airport.
type	**xs:date**
properties	content simple
annotation	documentation Effective date for the airport.

element **airport/expDate**

diagram	**expDate** The expiration date for the airport.
type	**xs:date**
properties	content simple
annotation	documentation The expiration date for the airport.

element **airport/name**

diagram	**name** The name of airport.		
type	**string100**		
properties	minOcc 0 maxOcc 1 content simple		
facets	Kind	Value	Annotation
	minLength	0	
	maxLength	100	
annotation	documentation The name of airport.		

element **airport/state**

diagram	**state** The airport state / territory name.		
type	**string50**		
properties	minOcc 0 maxOcc 1 content simple		
facets	Kind	Value	Annotation
	minLength	0	
	maxLength	50	
annotation	documentation The airport state / territory name.		

element **airport/facilityType**

diagram	**facilityType** The facility type, i.e. airport, heliport, seaport
type	**string25**

properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 25
annotation	documentation The facility type, i.e. airport, heliport, seaport

element **airport/cityName**

diagram	cityName The name of city closest to the airport.
type	**string50**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation The name of city closest to the airport.

element **airport/elevation**

diagram	elevation Airport elevation above mean sea level. UNITS: Feet above MSL
type	**xs:double**
properties	content simple
annotation	documentation Airport elevation above mean sea level. UNITS: Feet above MSL

element **airport/patternAltitude**

diagram	patternAltitude Pattern altitude (where provided) above ground level. UNITS: Feet AGL
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Pattern altitude (where provided) above ground level. UNITS: Feet AGL

element **airport/tower**

diagram	tower Flag to indicate if the airport has a tower.
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Flag to indicate if the airport has a tower.

element **airport/layout**

diagram	

	layout Flag to indicate detailed layout information exists.
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Flag to indicate detailed layout information exists.

element **airport/archiveFlag**

diagram	**archiveFlag** Flag set to 1 if track, sub-track, segment, and group percentage data can be distributed.
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Flag set to 1 if track, sub-track, segment, and group percentage data can be distributed.

element **airport/dafifId**

diagram	**dafifId** DAFIF Airport ID.
type	**string7**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 7
annotation	documentation DAFIF Airport ID.

element **airport/faaId**

diagram	**faaId** FAA Airport ID.
type	**string15**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 15
annotation	documentation FAA Airport ID.

element **airport/shell1**

diagram	**shell1** Indicates if this airport is a shell 1 airport.
type	**xs:boolean**
properties	minOcc 0

	maxOcc 1 content simple default false
annotation	documentation Indicates if this airport is a shell 1 airport.

element **airport/smad**

diagram	
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation Indicates if airport is a JPDO Systems Modeling and Analysis Division analysis airport.

element **airport/zone**

diagram	
type	**string100**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation Zone info data for airport.

complexType **airportCode**

diagram	
type	extension of **string4**
properties	base string4
used by	elements **track/airport** **runup/airport** **airport/airportCode** **airportLayoutType/airportCode** **operation/arrivalAirport** **operation/departureAirport**
facets	Kind Value Annotation minLength 0 maxLength 4
attributes	Name Type Use Default Fixed Annotation type **airportCodeType** optional ANY country **string3** optional ANY
annotation	documentation An airport code.

attribute **airportCode/@type**

type	**airportCodeType**
properties	use optional default ANY
facets	Kind Value Annotation enumeration ICAO enumeration IATA enumeration FAA enumeration OTHER enumeration ANY

attribute **airportCode/@country**

type	**string3**
properties	use optional default ANY
facets	Kind Value Annotation minLength 0 maxLength 3

complexType **airportLayoutType**

diagram

table. This element supports the definition of airport buildings. These building sources affect the emitted point source plumes by essentially serving as obstacles to those sources, and therefore have a significant impact on concentrations resulting from stationary source emissions. Buildings have no effect on the concentrations estimated from volume and area sources such as aircraft, APU, GSE, roadways, and parking facilities.
parkingFacilitySet
Supports legacy EDMS studies relating to content contained in the PARKING table. This element supports the definition of parking lot and parking garage activities for scenario layouts.
airportLayoutType
Fields defining an airport and its layout.
stationarySourceSet
Container of stationary sources contributing emissions.
gateSet
Supports legacy EDMS studies relating to content contained in the GATES table. This element supports the definition of gates within an airport layout. In dispersion analyses, GSE, AGE, and APU emissions originate from the gate locations. Gates are needed for sequence modeling, which includes all dispersion analyses.
roadwaySet
Supports legacy EDMS studies relating to content contained in the ROADWAYS table. This element supports the definition of vehicle activity on roadways for scenario layouts.
taxiwaySet
Supports legacy EDMS studies relating to the TAXIWAYS table. Taxiways determine the ground segments where the aircraft operates.
runwaySet
Container for runways.
taxipathSet
Supports legacy EDMS studies relating to the TAXIPATHS table. A taxipath is a sequence of taxiways, possibly just one, that connects a gate to a runway or vice versa. Taxipaths are used to do the modeling of aircraft ground movement. They are needed for sequence modeling, which includes all dispersion analyses. Gates, taxiways and runways must be defined before taxipaths can be specified.
trackSet
A set of flight tracks.
airportConfigSet
Contains one or more airportConfig elements.
airportCapacity
Supports legacy EDMS studies relating to content contained in the

	RUNWAY_CONFIGURATIONS table. This element supports the definition of airport capacities based on various points within an airport. **quarterHourlyProfileSet** Supports the definition and use of QUARTER_HOURLY_PROFILES for the quarter hourly variation of operations. **dailyProfileSet** Supports the definition and use of DAILY_PROFILES for the daily variation of operations. **monthlyProfileSet** Supports the definition and use of MONTHLY_PROFILES for the monthly variation of operations. **activityProfileSet** Supports the definition and use of QUARTER_HOURLY_PROFILES, DAILY_PROFILES, and MONTHLY_PROFILES variation of operations.
children	**name** **airportCode** **startDate** **elevation** **peakMonthAverageDayScalingFactor** **taxiInTime** **taxiOutTime** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **buildingSet** **parkingFacilitySet** **stationarySourceSet** **gateSet** **roadwaySet** **taxiwaySet** **runwaySet** **taxipathSet** **trackSet** **airportConfigSet** **airportCapacity** **quarterHourlyProfileSet** **dailyProfileSet** **monthlyProfileSet** **activityProfileSet**
used by	element **airportLayoutSet/airportLayout**
annotation	documentation Fields defining an airport and its layout.

element **airportLayoutType/name**

diagram	**name** ID of the layout. Must be unique.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation ID of the layout. Must be unique.

element **airportLayoutType/airportCode**

diagram	**airportCode** ICAO code of airport in the layout. airportCode attributes type country
type	**airportCode**
properties	content complex
facets	Kind Value Annotation minLength 0 maxLength 4
attributes	Name Type Use Default Fixed Annotation type **airportCodeType** optional ANY

	country	**string3**	optional	ANY
annotation	documentation ICAO code of airport in the layout.			

element **airportLayoutType/startDate**

diagram	**startDate** Date airport is included in the study.
type	**xs:date**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Date airport is included in the study.

element **airportLayoutType/elevation**

diagram	**elevation** Elevation of the layout in feet above MSL. (feet) Valid values: -1500 to 15000.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Elevation of the layout in feet above MSL. (feet) Valid values: -1500 to 15000.

element **airportLayoutType/peakMonthAverageDayScalingFactor**

diagram	**peakMonthAverageDayScalingFa...** Converts Average Annual Day operations to Peak Month Average Day operations. This is to comply with regulatory reporting requirements for the Peak Month Average Day emissions and fuel burn totals at individual airports.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 1.0
annotation	documentation Converts Average Annual Day operations to Peak Month Average Day operations. This is to comply with regulatory reporting requirements for the Peak Month Average Day emissions and fuel burn totals at individual airports.

element **airportLayoutType/taxiInTime**

diagram	**taxiInTime** Number of minutes to complete a taxi-in. (min)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Number of minutes to complete a taxi-in. (min)

element **airportLayoutType/taxiOutTime**

diagram	**taxiOutTime** Number of minutes to complete a taxi-out. (min)
type	**xs:double**

properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Number of minutes to complete a taxi-out. (min)

complexType **anpAirplane**

diagram	
children	**anpAirplaneId** **description** **sizeCode** **owner** **engineTypeCode** **numberEngines** **maxGrossWeightTakeoff** **maxGrossWeightLand** **maxDsStop** **depThrustCoeffType** **thrustStatic** **thrustRestore** **noiseId** **noiseCategory** **minBurn**
used by	element **fleet/anpAirplane**
annotation	documentation

	Creates a new ANP airplane.

element **anpAirplane/anpAirplaneId**

diagram	**anpAirplaneId** ID of ANP airplane. Must be a new, unique value.
type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation ID of ANP airplane. Must be a new, unique value.

element **anpAirplane/description**

diagram	**description** Description of ANP airplane.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Description of ANP airplane.

element **anpAirplane/sizeCode**

diagram	**sizeCode** Size code for this airframe. Valid values: H (Heavy), L (Large), M (Medium), S (Small), T (Light), V (Very Light).
type	**anpSizeCode**
properties	content simple
facets	Kind Value Annotation pattern Heavy|H|Large|L|Small|S
annotation	documentation Size code for this airframe. Valid values: H (Heavy), L (Large), M (Medium), S (Small), T (Light), V (Very Light).

element **anpAirplane/owner**

diagram	**owner** The owner category: commercial, general aviation, military.
type	**anpOwnerType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern Commercial|C|Military|M|General|G
annotation	documentation The owner category: commercial, general aviation, military.

element **anpAirplane/engineTypeCode**

diagram	

	engineTypeCode The engine type code: prop, jet, turbo.
type	**engineType**
properties	content simple
facets	Kind Value Annotation pattern Jet|J|Turbo|Turboprop|T|Prop|Piston|P
annotation	documentation The engine type code: prop, jet, turbo.

element **anpAirplane/numberEngines**

diagram	**numberEngines** Number of engines on this airplane. Valid values: 1 through 8.
type	**xs:int**
properties	content simple
annotation	documentation Number of engines on this airplane. Valid values: 1 through 8.

element **anpAirplane/maxGrossWeightTakeoff**

diagram	**maxGrossWeightTakeoff** Maximum gross weight on takeoff (min = 0, max = 999999, lbs).
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Maximum gross weight on takeoff (min = 0, max = 999999, lbs).

element **anpAirplane/maxGrossWeightLand**

diagram	**maxGrossWeightLand** Maximum gross weight on landing (min = 0, max = 999999, lbs).
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Maximum gross weight on landing (min = 0, max = 999999, lbs).

element **anpAirplane/maxDsStop**

diagram	**maxDsStop** FAR landing field length at maximum landing weight (min =0, max = 20000, feet).
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation FAR landing field length at maximum landing weight (min =0, max = 20000, feet).

element **anpAirplane/depThrustCoeffType**

diagram	**depThrustCoeffType** Type of thrust coefficients: J=jet, P=prop.
type	**anpCoeffType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern Jet|J|Prop|P
annotation	documentation Type of thrust coefficients: J=jet, P=prop.

element **anpAirplane/thrustStatic**

diagram	**thrustStatic** Static rated thrust or 100% thrust (lb, min =0, max = 200000).
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Static rated thrust or 100% thrust (lb, min =0, max = 200000).

element **anpAirplane/thrustRestore**

diagram	**thrustRestore** Flag indicating aircraft has automated thrust restoration system.
type	**yesNoType**
properties	content simple default N
facets	Kind Value Annotation pattern Yes|Y|No|N
annotation	documentation Flag indicating aircraft has automated thrust restoration system.

element **anpAirplane/noiseId**

diagram	**noiseId** ID of a Noise Group.
type	**anpNoiseId**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation ID of a Noise Group.

element **anpAirplane/noiseCategory**

diagram	**noiseCategory** The noise category stage number.
type	**xs:int**
properties	minOcc 0 maxOcc 1

	content simple
annotation	documentation The noise category stage number.

element **anpAirplane/minBurn**

diagram	**minBurn** Minimum fuel burn rate. (kg/sec)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Minimum fuel burn rate. (kg/sec)

complexType **anpFlaps**

diagram	
children	**flapId** **operationType** **coeff_R** **coeff_CD** **coeff_B**
used by	element **anpFlapsSet/flaps**
annotation	documentation Flaps data element.

element **anpFlaps/flapId**

diagram	**flapId** Flap-setting identifier.
type	**anpFlapId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 6
annotation	documentation Flap-setting identifier.

element **anpFlaps/operationType**

diagram	**operationType** Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)
type	**string1**

properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)

element **anpFlaps/coeff_R**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The drag-over-lift ratio. Valid values: 0.0 to 1.34.

element **anpFlaps/coeff_CD**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The takeoff and landing calibrated airspeed coefficient. Valid values: 0.0 to 1.34. (knots/lb^1/2).

element **anpFlaps/coeff_B**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The takeoff distance coefficient. Valid values: empty or 0.0 to 1.34. (feet/lb).

complexType **anpFlapsSet**

diagram	
children	**anpAirplaneId** **flaps**
used by	element **fleet/anpFlapsSet**
annotation	documentation Flap settings set for an ANP aircraft type.

element **anpFlapsSet/anpAirplaneId**

diagram	

type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's ANP ID.

element **anpFlapsSet/flaps**

diagram	
type	**anpFlaps**
properties	minOcc 1 maxOcc unbounded content complex
children	**flapId operationType coeff_R coeff_CD coeff_B**

complexType **anpHelicopter**

diagram	

1000.
rpm
The helicopter rotor speed (revolutions per minute). Valid values: 0 to 1000.
maxTakeoffWeight
The max gross takeoff weight (pounds). Valid values: 0 to 50000.
hasWheels
Flag indicating if the helicopter has wheels. Valid values: Y (yes), N (no).
modelType
The helicopter model type. Valid values: I (INM), N (NoiseMap).
bLeft0
Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
bLeft1
Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
anpHelicopter
bLeft2
Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
bCenter0
Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
bCenter1
Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
bCenter2
Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
bRight0
Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
bRight1
Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
bRight2
Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
dbVerticalAscent
Decibel offset added to NPD levels, vertical ascent (dB). Valid values: Min = -50 Max = 50.
dbVerticalDescent
Decibel offset added to NPD levels, vertical descent (dB). Valid values: Min = -50 Max = 50.

	dbHorizontalAcceleration Decibel offset added to NPD levels, depart horizontal acceleration (dB). Valid values: Min = -50 Max = 50. **dbClimbAcceleration** Decibel offset added to NPD levels, depart with climbing acceleration (dB). Valid values: Min = -50 Max = 50. **dbHorizontalDeceleration** Decibel offset added to NPD levels, approach with horizontal deceleration (dB). Valid values: Min = -50 Max = 50. **dbDescendDeceleration** Decibel offset added to NPD levels, approach with descending deceleration (dB). Valid values: Min = -50 Max = 50.
children	**anpHelicopterId** **noiseId** **directivityId** **description** **owner** **engineTypeCode** **numberRotors** **diameter** **rpm** **maxTakeoffWeight** **hasWheels** **modelType** **bLeft0** **bLeft1** **bLeft2** **bCenter0** **bCenter1** **bCenter2** **bRight0** **bRight1** **bRight2** **dbVerticalAscent** **dbVerticalDescent** **dbHorizontalAcceleration** **dbClimbAcceleration** **dbHorizontalDeceleration** **dbDescendDeceleration**
used by	element **fleet/anpHelicopter**

element **anpHelicopter/anpHelicopterId**

diagram	**anpHelicopterId** Unique ID number of ANP Helicopter.
type	**anpHeloId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Unique ID number of ANP Helicopter.

element **anpHelicopter/noiseId**

diagram	**noiseId** ID of a Noise Group.
type	**anpHeloNoiseId**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation ID of a Noise Group.

element **anpHelicopter/directivityId**

diagram	**directivityId** Noise directivity ID for ANP helicopter.
type	**anpHeloDirectivityId**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 12

annotation	documentation Noise directivity ID for ANP helicopter.

element **anpHelicopter/description**

diagram	**description** Description of ANP Helicopter.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Description of ANP Helicopter.

element **anpHelicopter/owner**

diagram	**owner** The owner category. Valid values: C (commercial), G (general aviation), M (military).
type	**anpOwnerType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern Commercial|C|Military|M|General|G
annotation	documentation The owner category. Valid values: C (commercial), G (general aviation), M (military).

element **anpHelicopter/engineTypeCode**

diagram	**engineTypeCode** The engine type code. Valid values: P (piston), J (jet), T (turboprop).
type	**engineType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern Jet|J|Turbo|Turboprop|T|Prop|Piston|P
annotation	documentation The engine type code. Valid values: P (piston), J (jet), T (turboprop).

element **anpHelicopter/numberRotors**

diagram	**numberRotors** The number of rotors. Valid values: 1 to 9.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The number of rotors. Valid values: 1 to 9.

element **anpHelicopter/diameter**

diagram	

	diameter The helicopter diameter (feet). Valid values: 0 to 1000.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The helicopter diameter (feet). Valid values: 0 to 1000.

element **anpHelicopter/rpm**

diagram	**rpm** The helicopter rotor speed (revolutions per minute). Valid values: 0 to 1000.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The helicopter rotor speed (revolutions per minute). Valid values: 0 to 1000.

element **anpHelicopter/maxTakeoffWeight**

diagram	**maxTakeoffWeight** The max gross takeoff weight (pounds). Valid values: 0 to 50000.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The max gross takeoff weight (pounds). Valid values: 0 to 50000.

element **anpHelicopter/hasWheels**

diagram	**hasWheels** Flag indicating if the helicopter has wheels. Valid values: Y (yes), N (no).
type	**yesNoType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern Yes|Y|No|N
annotation	documentation Flag indicating if the helicopter has wheels. Valid values: Y (yes), N (no).

element **anpHelicopter/modelType**

diagram	**modelType** The helicopter model type. Valid values: I (INM), N (NoiseMap).
type	**string1**
properties	minOcc 0 maxOcc 1

	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation The helicopter model type. Valid values: I (INM), N (NoiseMap).

element **anpHelicopter/bLeft0**

diagram	bLeft0 Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bLeft1**

diagram	bLeft1 Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bLeft2**

diagram	bLeft2 Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bCenter0**

diagram	bCenter0 Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bCenter1**

diagram	bCenter1 Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bCenter2**

diagram	bCenter2 Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bRight0**

diagram	bRight0 Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bRight1**

diagram	bRight1 Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/bRight2**

diagram	bRight2 Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation

	Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.

element **anpHelicopter/dbVerticalAscent**

diagram	**dbVerticalAscent** Decibel offset added to NPD levels, vertical ascent (dB). Valid values: Min = -50 Max = 50.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel offset added to NPD levels, vertical ascent (dB). Valid values: Min = -50 Max = 50.

element **anpHelicopter/dbVerticalDescent**

diagram	**dbVerticalDescent** Decibel offset added to NPD levels, vertical descent (dB). Valid values: Min = -50 Max = 50.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel offset added to NPD levels, vertical descent (dB). Valid values: Min = -50 Max = 50.

element **anpHelicopter/dbHorizontalAcceleration**

diagram	**dbHorizontalAcceleration** Decibel offset added to NPD levels, depart horizontal acceleration (dB). Valid values: Min = -50 Max = 50.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel offset added to NPD levels, depart horizontal acceleration (dB). Valid values: Min = -50 Max = 50.

element **anpHelicopter/dbClimbAcceleration**

diagram	**dbClimbAcceleration** Decibel offset added to NPD levels, depart with climbing acceleration (dB). Valid values: Min = -50 Max = 50.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel offset added to NPD levels, depart with climbing acceleration (dB). Valid values: Min = -50 Max = 50.

element **anpHelicopter/dbHorizontalDeceleration**

diagram	**dbHorizontalDeceleration** Decibel offset added to NPD levels, approach with horizontal deceleration (dB). Valid values: Min = -50 Max = 50.
type	**xs:double**

properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel offset added to NPD levels, approach with horizontal deceleration (dB). Valid values: Min = -50 Max = 50.

element **anpHelicopter/dbDescendDeceleration**

diagram	**dbDescendDeceleration** Decibel offset added to NPD levels, approach with descending deceleration (dB). Valid values: Min = -50 Max = 50.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel offset added to NPD levels, approach with descending deceleration (dB). Valid values: Min = -50 Max = 50.

complexType **anpHeloDirectivity**

diagram

anpHeloDirectivity
Valid values: Min = -99.9 Max = 999.9.
L045
Decibel adjustment at 45 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
L030
Decibel adjustment at 30 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
L015
Decibel adjustment at 0 degrees along the nose (dB). Valid values: Min = -99.9 Max = 999.9.
C000
Decibel adjustment at 180 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R015
Decibel adjustment at 15 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R030
Decibel adjustment at 30 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R045
Decibel adjustment at 45 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R060
Decibel adjustment at 60 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R075
Decibel adjustment at 75 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R090
Decibel adjustment at 90 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R105
Decibel adjustment at 105 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R120
Decibel adjustment at 120 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R135
Decibel adjustment at 135 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R150
Decibel adjustment at 150 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R165
Decibel adjustment at 165 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R180

	Decibel adjustment at 180 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
children	**groundType** **opMode** **L180** **L165** **L150** **L135** **L120** **L105** **L090** **L075** **L060** **L045** **L030** **L015** **C000** **R015** **R030** **R045** **R060** **R075** **R090** **R105** **R120** **R135** **R150** **R165** **R180**
used by	element **anpHeloDirectivitySet/anpHeloDirectivity**

element **anpHeloDirectivity/groundType**

diagram	**groundType** Type of ground resistivity. Valid values: H (hard), S (soft), F (file), N (none).
type	**anpHeloGroundType**
properties	content simple
facets	Kind Value Annotation pattern Hard|H|Software|S|File|F|None|N
annotation	documentation Type of ground resistivity. Valid values: H (hard), S (soft), F (file), N (none).

element **anpHeloDirectivity/opMode**

diagram	**opMode** Operational Mode. Valid values: A (approach), D (departure).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Operational Mode. Valid values: A (approach), D (departure).

element **anpHeloDirectivity/L180**

diagram	**L180** Decibel adjustment at 180 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 180 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L165**

diagram	**L165** Decibel adjustment at 165 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 165 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L150**

diagram	L150 Decibel adjustment at 150 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 150 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L135**

diagram	L135 Decibel adjustment at 135 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 135 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L120**

diagram	L120 Decibel adjustment at 120 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 120 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L105**

diagram	L105 Decibel adjustment at 105 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 105 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L090**

diagram	L090 Decibel adjustment at 90 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation

	Decibel adjustment at 90 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L075**

diagram	L075 Decibel adjustment at 75 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 75 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L060**

diagram	L060 Decibel adjustment at 60 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 60 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L045**

diagram	L045 Decibel adjustment at 45 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 45 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L030**

diagram	L030 Decibel adjustment at 30 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 30 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/L015**

diagram	L015 Decibel adjustment at 0 degrees along the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**

properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 0 degrees along the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/C000**

diagram	C000 Decibel adjustment at 180 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 180 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R015**

diagram	R015 Decibel adjustment at 15 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 15 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R030**

diagram	R030 Decibel adjustment at 30 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 30 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R045**

diagram	R045 Decibel adjustment at 45 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 45 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R060**

diagram	

	R060 Decibel adjustment at 60 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 60 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R075**

diagram	R075 Decibel adjustment at 75 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 75 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R090**

diagram	R090 Decibel adjustment at 90 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 90 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R105**

diagram	R105 Decibel adjustment at 105 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 105 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R120**

diagram	R120 Decibel adjustment at 120 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation

	Decibel adjustment at 120 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R135**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 135 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R150**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 150 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R165**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 165 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

element **anpHeloDirectivity/R180**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel adjustment at 180 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

complexType **anpHeloDirectivitySet**

diagram	

children	**anpHelicopterId** **anpHeloDirectivity**
used by	element **fleet/anpHeloDirectivitySet**
annotation	documentation A set of helicopter directivities.

element **anpHeloDirectivitySet/anpHelicopterId**

diagram	**anpHelicopterId** Unique ID for ANP helicopters.
type	**anpHeloDirectId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 12
annotation	documentation Unique ID for ANP helicopters.

element **anpHeloDirectivitySet/anpHeloDirectivity**

diagram

anpHeloDirectivity
1..∞
ANP Helicopter directivity.
Decibel adjustment at 60 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
L045
Decibel adjustment at 45 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
L030
Decibel adjustment at 30 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
L015
Decibel adjustment at 0 degrees along the nose (dB). Valid values: Min = -99.9 Max = 999.9.
C000
Decibel adjustment at 180 degrees left of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R015
Decibel adjustment at 15 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R030
Decibel adjustment at 30 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R045
Decibel adjustment at 45 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R060
Decibel adjustment at 60 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R075
Decibel adjustment at 75 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R090
Decibel adjustment at 90 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R105
Decibel adjustment at 105 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R120
Decibel adjustment at 120 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R135
Decibel adjustment at 135 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R150
Decibel adjustment at 150 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.
R165
Decibel adjustment at 165 degrees right of the nose (dB). Valid values: Min = -99.9 Max = 999.9.

type	**anpHeloDirectivity**
properties	minOcc 1 maxOcc unbounded content complex
children	**groundType opMode L180 L165 L150 L135 L120 L105 L090 L075 L060 L045 L030 L015 C000 R015 R030 R045 R060 R075 R090 R105 R120 R135 R150 R165 R180**
annotation	documentation ANP Helicopter directivity.

complexType **anpHeloNoiseGroup**

diagram	
children	**noiseId spectralClassApproach spectralClassDeparture spectralClassFlyover speedApproach speedDeparture speedFlyover npdCurves**
used by	element **fleet/anpHeloNoiseGroup**
annotation	documentation This element contains the three spectral class references for a given aircraft Noise group with the corresponding thrust setting type and model type.

element **anpHeloNoiseGroup/noiseId**

diagram	
type	**anpHeloNoiseId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The noise group id.

element **anpHeloNoiseGroup/spectralClassApproach**

diagram	**spectralClassApproach** The approach spectral class number. Valid values: 0 to 999.
type	**xs:short**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The approach spectral class number. Valid values: 0 to 999.

element **anpHeloNoiseGroup/spectralClassDeparture**

diagram	**spectralClassDeparture** The departure spectral class number. Valid values: 0 to 999.
type	**xs:short**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The departure spectral class number. Valid values: 0 to 999.

element **anpHeloNoiseGroup/spectralClassFlyover**

diagram	**spectralClassFlyover** The flyover spectral class number. Valid values: 0 to 999.
type	**xs:short**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The flyover spectral class number. Valid values: 0 to 999.

element **anpHeloNoiseGroup/speedApproach**

diagram	**speedApproach** N 6.1 Approach reference true airspeed (KTAS). Valid values: Min = 0.0 Max = 250.0. UNITS: knots.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation N 6.1 Approach reference true airspeed (KTAS). Valid values: Min = 0.0 Max = 250.0. UNITS: knots.

element **anpHeloNoiseGroup/speedDeparture**

diagram	**speedDeparture** N 6.1 Depart reference true airspeed (KTAS) Min = 0.0 Max = 250.0. UNITS: knots.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation

	N 6.1 Depart reference true airspeed (KTAS) Min = 0.0 Max = 250.0. UNITS: knots.

element **anpHeloNoiseGroup/speedFlyover**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation N 6.1 Flyover reference true airspeed (KTAS) Min = 0.0 Max = 250.0. UNITS: knots.

element **anpHeloNoiseGroup/npdCurves**

diagram	
type	**anpHeloNPDCurves**
properties	minOcc 0 maxOcc 1 content complex
children	**npdCurve**
annotation	documentation The set of noise curves for this group.

complexType **anpHeloNPDCurve**

diagram	

children	**noiseType** **opMode** **sideType** **L_200** **L_400** **L_630** **L_1000** **L_2000** **L_4000** **L_6300** **L_10000** **L_16000** **L_25000**
used by	element **anpHeloNPDCurves/npdCurve**
annotation	documentation The Noise Power Distance curve table for a specified noise ID, noise type, operation mode, and thrust setting.

element **anpHeloNPDCurve/noiseType**

diagram	**noiseType** Type of noise described by this curve. Valid values: S (SEL), M (LAMAX), E (EPNL), P (PNLTM).
type	**anpNpdNoiseType**
properties	content simple
facets	Kind Value Annotation pattern S|M|E|P

annotation	documentation Type of noise described by this curve. Valid values: S (SEL), M (LAMAX), E (EPNL), P (PNLTM).

element **anpHeloNPDCurve/opMode**

diagram	**opMode** Engine operation mode.
type	**anpNpdOpMode**
properties	content simple
facets	Kind Value Annotation pattern A|D|L|G|H|I|J|V|W|Y|Z|B|C|E|F|X|S
annotation	documentation Engine operation mode.

element **anpHeloNPDCurve/sideType**

diagram	**sideType** Operation side type. Valid values: L (left), C (center), R (right), S (static)
type	**anpHeloSideType**
properties	content simple
facets	Kind Value Annotation pattern Left|L|Center|C|Right|R|Static|S
annotation	documentation Operation side type. Valid values: L (left), C (center), R (right), S (static)

element **anpHeloNPDCurve/L_200**

diagram	**L_200** Decibel level at 200 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel level at 200 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_400**

diagram	**L_400** Decibel level at 400 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel level at 400 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_630**

diagram	**L_630** Decibel level at 630 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1

	content simple
annotation	documentation Decibel level at 630 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_1000**

diagram	L_1000 Decibel level at 1000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel level at 1000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_2000**

diagram	L_2000 Decibel level at 2000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel level at 2000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_4000**

diagram	L_4000 Decibel level at 4000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 4000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_6300**

diagram	L_6300 Decibel level at 6300 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel level at 6300 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_10000**

diagram	L_10000 Decibel level at 10000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple

annotation	documentation Decibel level at 10000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_16000**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel level at 16000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpHeloNPDCurve/L_25000**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Decibel level at 25000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

complexType **anpHeloNPDCurves**

diagram	
children	**npdCurve**
used by	element **anpHeloNoiseGroup/npdCurves**
annotation	documentation The set of noise curves.

element **anpHeloNPDCurves/npdCurve**

diagram	

type	**anpHeloNPDCurve**
properties	minOcc 1 maxOcc unbounded content complex
children	**noiseType opMode sideType L_200 L_400 L_630 L_1000 L_2000 L_4000 L_6300 L_10000 L_16000 L_25000**
annotation	documentation Base noise data interpolated/extrapolated upon according to slant range distance and thrust setting for aircraft.

complexType **anpHeloProcedureStep**

diagram	

children	**stepNum** **operationType** **profileGroupId** **profileStageLength** **stepType** **duration** **distance** **altitude** **speed**
used by	element **anpHeloProfile/step**
annotation	documentation Procedure data element.

element **anpHeloProcedureStep/stepNum**

diagram	**stepNum** Step number of the procedure. Must be unique in a sequence.
type	**xs:int**

properties	content simple
annotation	documentation Step number of the procedure. Must be unique in a sequence.

element **anpHeloProcedureStep/operationType**

diagram	**operationType** Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)

element **anpHeloProcedureStep/profileGroupId**

diagram	**profileGroupId** Profile group identifier. Valid values: STANDARD, NOISEMAP (INM standard data).
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Profile group identifier. Valid values: STANDARD, NOISEMAP (INM standard data).

element **anpHeloProcedureStep/profileStageLength**

diagram	**profileStageLength** Profile stage number (min = 1, max = 9). Approach stage numbers are not related to trip distance. There is only one standard approach profile for most standard aircraft and its stage number is set to 1. Approach stage numbers are used to distinguish members of a group. For example, approach stage can mean different kinds of approaches (e.g. 1 = 3 degree approach, 2 = 5 degree approach).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Profile stage number (min = 1, max = 9). Approach stage numbers are not related to trip distance. There is only one standard approach profile for most standard aircraft and its stage number is set to 1. Approach stage numbers are used to distinguish members of a group. For example, approach stage can mean different kinds of approaches (e.g. 1 = 3 degree approach, 2 = 5 degree approach).

element **anpHeloProcedureStep/stepType**

diagram	

	stepType Type of step. (A) Approach at constant speed, (D) Depart at constant speed, (L) Level flyover at constant speed, (G) Ground idle, (H) Flight idle, (I) Hover in ground effect, (J) Hover out of ground effect, (V) Vertical ascent in ground effect, (W) Vertical ascent out of ground effect, (Y) Vertical descent in ground effect, (Z) Vertical descent out of ground effect, (B) Approach with horizontal deceleration, (C) Approach with descending deceleration, (E) Depart with horizontal acceleration, (F) Depart with climbing acceleration, (X) Taxi at constant speed, (S) Start altitude at constant speed
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of step. (A) Approach at constant speed, (D) Depart at constant speed, (L) Level flyover at constant speed, (G) Ground idle, (H) Flight idle, (I) Hover in ground effect, (J) Hover out of ground effect, (V) Vertical ascent in ground effect, (W) Vertical ascent out of ground effect, (Y) Vertical descent in ground effect, (Z) Vertical descent out of ground effect, (B) Approach with horizontal deceleration, (C) Approach with descending deceleration, (E) Depart with horizontal acceleration, (F) Depart with climbing acceleration, (X) Taxi at constant speed, (S) Start altitude at constant speed

element **anpHeloProcedureStep/duration**

diagram	**duration** Procedure's duration (seconds).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Procedure's duration (seconds).

element **anpHeloProcedureStep/distance**

diagram	**distance** Length of a particular segment (min = -9999999.9, max = 9999999.9, feet).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Length of a particular segment (min = -9999999.9, max = 9999999.9, feet).

element **anpHeloProcedureStep/altitude**

diagram	**altitude** Altitude above runway elevation (ARE) of aircraft (min = -9999, max = 60000). UNITS: feet.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple

annotation	documentation Altitude above runway elevation (ARE) of aircraft (min = -9999, max = 60000). UNITS: feet.

element **anpHeloProcedureStep/speed**

diagram	**speed** True airspeed (KTAS) at this point (min = 0, max = 600). UNITS: knots.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation True airspeed (KTAS) at this point (min = 0, max = 600). UNITS: knots.

complexType **anpHeloProfile**

diagram

children	**operationType** **profileGroupId** **profileStageLength** **weight** **useDirectivity** **useTrack** **headingTakeoffGround** **headingTakeoffHover** **headingLandGround** **headingLandHover** **step**
used by	element **anpHeloProfileSet/profile**
annotation	documentation Profile data element.

element **anpHeloProfile/operationType**

diagram	**operationType** Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)

element **anpHeloProfile/profileGroupId**

diagram	**profileGroupId** Profile group identifier. Valid values: STANDARD, NOISEMAP (INM standard data).
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Profile group identifier. Valid values: STANDARD, NOISEMAP (INM standard data).

element **anpHeloProfile/profileStageLength**

diagram	**profileStageLength** Profile stage number (min = 1, max = 9). Approach stage numbers are not related to trip distance. There is only one standard approach profile for most standard aircraft and its stage number is set to 1. Approach stage numbers are used to distinguish members of a group. For example, approach stage can mean different kinds of approaches (e.g. 1 = 3 degree approach, 2 = 5 degree approach).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Profile stage number (min = 1, max = 9). Approach stage numbers are not related to trip distance. There is only one standard approach profile for most standard aircraft and its stage number is set to 1. Approach stage numbers are used to distinguish members of a group. For example, approach stage can mean different kinds of approaches (e.g. 1 = 3 degree approach, 2 = 5 degree approach).

element **anpHeloProfile/weight**

diagram	

	weight Aircraft weight during this operation type. Valid values: 0 through 999999. (lb)
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Aircraft weight during this operation type. Valid values: 0 through 999999. (lb)

element **anpHeloProfile/useDirectivity**

diagram	**useDirectivity** Use directivity? Y=Yes N=No.
type	**yesNoType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern Yes|Y|No|N
annotation	documentation Use directivity? Y=Yes N=No.

element **anpHeloProfile/useTrack**

diagram	**useTrack** Use track (static heading is relative to track)? Y=Yes N=No.
type	**yesNoType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern Yes|Y|No|N
annotation	documentation Use track (static heading is relative to track)? Y=Yes N=No.

element **anpHeloProfile/headingTakeoffGround**

diagram	**headingTakeoffGround** Takeoff ground heading. Valid values: -180 through 360. (decimal degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Takeoff ground heading. Valid values: -180 through 360. (decimal degrees)

element **anpHeloProfile/headingTakeoffHover**

diagram	**headingTakeoffHover** Takeoff hover heading. Valid values: -180 through 360. (decimal degrees)
type	**xs:double**
properties	content simple
annotation	documentation

	Takeoff hover heading. Valid values: -180 through 360. (decimal degrees)

element **anpHeloProfile/headingLandGround**

diagram	**headingLandGround** Landing ground heading. Valid values: -180 through 360. (decimal degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Landing ground heading. Valid values: -180 through 360. (decimal degrees)

element **anpHeloProfile/headingLandHover**

diagram	**headingLandHover** Landing hover heading. Valid values: -180 through 360. (decimal degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Landing hover heading. Valid values: -180 through 360. (decimal degrees)

element **anpHeloProfile/step**

diagram	

type	**anpHeloProcedureStep**
properties	minOcc 0 maxOcc unbounded content complex
children	**stepNum operationType profileGroupId profileStageLength stepType duration distance altitude speed**
annotation	documentation The procedure steps.

complexType **anpHeloProfileSet**

diagram	
children	**anpHelicopterId** **profile**
used by	element **fleet/anpHeloProfileSet**
annotation	documentation A profile set for an ANP helicopter.

element **anpHeloProfileSet/anpHelicopterId**

diagram	
type	**anpHeloId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The anp helicopter id.

element **anpHeloProfileSet/profile**

diagram	

type	**anpHeloProfile**
properties	minOcc 1 maxOcc unbounded content complex
children	**operationType** **profileGroupId** **profileStageLength** **weight** **useDirectivity** **useTrack** **headingTakeoffGround** **headingTakeoffHover** **headingLandGround** **headingLandHover** **step**
annotation	documentation One or more ANP profiles.

complexType **anpNoiseGroup**

diagram	

children	**noiseId** **spectralClassApproach** **spectralClassDeparture** **spectralClassAfterburner** **thrustSetType** **modelType** **npdCurves**
used by	element **fleet/anpNoiseGroup**
annotation	documentation This element contains the three spectral class references for a given aircraft Noise group with the corresponding thrust setting type and model type.

element **anpNoiseGroup/noiseId**

diagram	**noiseId** Noise group's ID.
type	**anpNoiseId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Noise group's ID.

element **anpNoiseGroup/spectralClassApproach**

diagram	**spectralClassApproach** Spectral class number for approach (min = 0, max = 30000).
type	**xs:short**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation

	Spectral class number for approach (min = 0, max = 30000).

element **anpNoiseGroup/spectralClassDeparture**

diagram	**spectralClassDeparture** Spectral class number for departure (min = 0, max = 30000).
type	**xs:short**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Spectral class number for departure (min = 0, max = 30000).

element **anpNoiseGroup/spectralClassAfterburner**

diagram	**spectralClassAfterburner** Spectral class number for afterburner (min = 0, max = 30000).
type	**xs:short**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Spectral class number for afterburner (min = 0, max = 30000).

element **anpNoiseGroup/thrustSetType**

diagram	**thrustSetType** Type of thrust setting. Valid values: L (pounds), P (percent), X (other). The following are typically used for military airplane: A (Power Lever Angle), B (Pounds Thrust), C (Turbine Inlet Temperature (Deg C)), E (Engine Pressure Ratio), F (Fan Speed), H (Equivalent Shaft Power), I (Manifold Pressure (Inches Mercury)), M (Propeller or Compressor RPM), N (Percent Corrected Rotor Speed), O (Percent Low Pressure Compressor Speed), R (Percent Propeller or Compressor RPM), S (Pounds per Hour of Fuel Flow), V (Percent Fan Speed).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of thrust setting. Valid values: L (pounds), P (percent), X (other). The following are typically used for military airplane: A (Power Lever Angle), B (Pounds Thrust), C (Turbine Inlet Temperature (Deg C)), E (Engine Pressure Ratio), F (Fan Speed), H (Equivalent Shaft Power), I (Manifold Pressure (Inches Mercury)), M (Propeller or Compressor RPM), N (Percent Corrected Rotor Speed), O (Percent Low Pressure Compressor Speed), R (Percent Propeller or Compressor RPM), S (Pounds per Hour of Fuel Flow), V (Percent Fan Speed).

element **anpNoiseGroup/modelType**

diagram	**modelType** Type of distance-duration model. Valid values: I (INM), N (NoiseMap).
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0

	maxLength 1
annotation	documentation Type of distance-duration model. Valid values: I (INM), N (NoiseMap).

element **anpNoiseGroup/npdCurves**

diagram	
type	**anpNPDCurves**
properties	content complex
children	**npdCurve**
annotation	documentation The set of noise curves for ANP aircraft.

complexType **anpNPDCurve**

diagram	

children	**noiseType** **opMode** **netThrustPerEngine** **L_200** **L_400** **L_630** **L_1000** **L_2000** **L_4000** **L_6300** **L_10000** **L_16000** **L_25000**
used by	element **anpNPDCurves/npdCurve**
annotation	documentation The Noise Power Distance curve table for a specified noise ID, noise type, operation mode, and thrust setting.

element **anpNPDCurve/noiseType**

diagram	**noiseType** Type of noise described by this curve. Valid values: S (SEL), M (LAMAX), E (EPNL), P (PNLTM).
type	**anpNpdNoiseType**
properties	content simple

facets	Kind Value Annotation pattern S|M|E|P
annotation	documentation Type of noise described by this curve. Valid values: S (SEL), M (LAMAX), E (EPNL), P (PNLTM).

element **anpNPDCurve/opMode**

diagram	**opMode** Engine operation mode. Valid values: A (Approach), D (Depart), X (Afterburner)
type	**anpNpdOpMode**
properties	content simple
facets	Kind Value Annotation pattern A|D|L|G|H|I|J|V|W|Y|Z|B|C|E|F|X|S
annotation	documentation Engine operation mode. Valid values: A (Approach), D (Depart), X (Afterburner)

element **anpNPDCurve/netThrustPerEngine**

diagram	**netThrustPerEngine** Net thrust per engine (min = 0.10, max = 99999.00, lbs. or percentage depending on parent noise group THRUST_SET_TYPE value).
type	**xs:double**
properties	content simple
annotation	documentation Net thrust per engine (min = 0.10, max = 99999.00, lbs. or percentage depending on parent noise group THRUST_SET_TYPE value).

element **anpNPDCurve/L_200**

diagram	**L_200** Decibel level at 200 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 200 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_400**

diagram	**L_400** Decibel level at 400 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 400 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_630**

diagram	**L_630** Decibel level at 630 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation

	Decibel level at 630 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_1000**

diagram	L_1000 Decibel level at 1000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 1000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_2000**

diagram	L_2000 Decibel level at 2000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 2000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_4000**

diagram	L_4000 Decibel level at 4000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 4000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_6300**

diagram	L_6300 Decibel level at 6300 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 6300 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_10000**

diagram	L_10000 Decibel level at 10000 feet AGL. Valid values: Min = -50.0 Max = 999.9.
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 10000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_16000**

diagram	L_16000 Decibel level at 16000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 16000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

element **anpNPDCurve/L_25000**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Decibel level at 25000 feet AGL. Valid values: Min = -50.0 Max = 999.9.

complexType **anpNPDCurves**

diagram	
children	**npdCurve**
used by	element **anpNoiseGroup/npdCurves**
annotation	documentation The set of defined noise curves.

element **anpNPDCurves/npdCurve**

diagram	

type	**anpNPDCurve**
properties	minOcc 1 maxOcc unbounded content complex
children	**noiseType opMode netThrustPerEngine L_200 L_400 L_630 L_1000 L_2000 L_4000 L_6300 L_10000 L_16000 L_25000**
annotation	documentation Base noise data interpolated/extrapolated upon according to slant range distance and thrust setting for aircraft.

complexType **anpProcedureStep**

diagram	

children	**stepNum** **flapId** **stepType** **thrustType** **param1** **param2** **param3**
used by	element **anpProcedureSteps/step**
annotation	documentation A single procedure step datum for the profile.

element **anpProcedureStep/stepNum**

diagram	**stepNum** Step number of the procedure. Must be unique in a sequence.
type	**xs:int**
properties	content simple
annotation	documentation Step number of the procedure. Must be unique in a sequence.

element **anpProcedureStep/flapId**

diagram	**flapId** Flap-setting identifier.
type	**anpFlapId**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 6
annotation	documentation

	Flap-setting identifier.

element **anpProcedureStep/stepType**

diagram	**stepType** Type of step. (T) Takeoff, (C) Climb, (M) Cruise-Climb, (A) Accelerate, (P) Accel-Percent, (V) Level, (U) Level-Decel, (W) Level-Idle, (S) Level-Stretch, (D) Descend, (E) Descend-Decel, (F) Decend-Idle, (L) Land, (B) Decelerate
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of step. (T) Takeoff, (C) Climb, (M) Cruise-Climb, (A) Accelerate, (P) Accel-Percent, (V) Level, (U) Level-Decel, (W) Level-Idle, (S) Level-Stretch, (D) Descend, (E) Descend- Decel, (F) Decend-Idle, (L) Land, (B) Decelerate

element **anpProcedureStep/thrustType**

diagram	**thrustType** Type of thrust. (T) MaxTakeoff, (C) MaxClimb, (N) MaxContinuous, (H) ReduceTakeoff, (Q) ReduceClimb, (S) MaxTakeoffHiTemp, (B) MaxClimbHiTemp, (M) MaxContinuousHiTemp, (G) ReduceClimbHiTemp, (P) ReduceClimbHiTemp, (I) IdleApproach, (J) IdleApproachHiTemp, (R) MinimumThrust, (K) UserCutback, (U) UserValue
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of thrust. (T) MaxTakeoff, (C) MaxClimb, (N) MaxContinuous, (H) ReduceTakeoff, (Q) ReduceClimb, (S) MaxTakeoffHiTemp, (B) MaxClimbHiTemp, (M) MaxContinuousHiTemp, (G) ReduceClimbHiTemp, (P) ReduceClimbHiTemp, (I) IdleApproach, (J) IdleApproachHiTemp, (R) MinimumThrust, (K) UserCutback, (U) UserValue

element **anpProcedureStep/param1**

diagram	**param1** Parameter particular for this step type (min = 9999.0, max = 60000.0).
type	**xs:double**
properties	content simple
annotation	documentation Parameter particular for this step type (min = 9999.0, max = 60000.0).

element **anpProcedureStep/param2**

diagram	**param2** Parameter particular for this step type (min = 0, max = 600.0).
type	**xs:double**

properties	content simple
annotation	documentation Parameter particular for this step type (min = 0, max = 600.0).

element **anpProcedureStep/param3**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Parameter particular for this step type (min = 0.0, max = 9999999.9).

complexType **anpProcedureSteps**

diagram	
children	**step**
used by	element **anpProfile/procedureSteps**
annotation	documentation A set of procedure steps for the profile.

element **anpProcedureSteps/step**

diagram	

type	**anpProcedureStep**
properties	minOcc 1 maxOcc unbounded content complex
children	**stepNum flapId stepType thrustType param1 param2 param3**
annotation	documentation An ANP procedure step.

complexType **anpProfile**

diagram	

children	**operationType** **profileGroupId** **profileStageLength** **weight** **procedureSteps** **profilePoints**
used by	element **anpProfileSet/profile**
annotation	documentation Profile data element.

element **anpProfile/operationType**

diagram	**operationType** Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)

element **anpProfile/profileGroupId**

diagram	**profileGroupId** Profile group identifier. Valid values: STANDARD, NOISEMAP (INM standard data).
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Profile group identifier. Valid values: STANDARD, NOISEMAP (INM standard data).

element **anpProfile/profileStageLength**

diagram	
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Profile stage number (min = 1, max = 9). Approach stage numbers are not related to trip distance. There is only one standard approach profile for most standard aircraft and its stage number is set to 1. Approach stage numbers are used to distinguish members of a group. For example, approach stage can mean different kinds of approaches (e.g. 1 = 3 degree approach, 2 = 5 degree approach).

element **anpProfile/weight**

diagram	
type	**xs:int**
properties	content simple
annotation	documentation Aircraft weight during this operation type (min = 0, max = 999999, lbs).

element **anpProfile/procedureSteps**

diagram	
type	**anpProcedureSteps**
properties	content complex
children	**step**
annotation	documentation Set of procedure steps associated with this profile.

element **anpProfile/profilePoints**

diagram	
type	**anpProfilePoints**
properties	content complex
children	**point**
annotation	documentation Set of points associated with this profile.

complexType **anpProfilePoint**

diagram	
children	**pointNum** **distance** **altitude** **speed** **thrustSet** **opMode**
used by	element **anpProfilePoints/point**
annotation	documentation A single profile point data element.

element **anpProfilePoint/pointNum**

diagram	
type	**xs:short**
properties	content simple
annotation	documentation Point index number. Must be sequential and unique, starting at 1.

element **anpProfilePoint/distance**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Distance along the ground relative to start (min = -9999999.9, max = 9999999.9, feet).

element **anpProfilePoint/altitude**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation

	Altitude AFE of aircraft (min = -9999, max = 60000, feet).

element **anpProfilePoint/speed**

diagram	**speed** True air speed (TAS) at this point (min = 0, max = 600, knots).
type	**xs:double**
properties	content simple
annotation	documentation True air speed (TAS) at this point (min = 0, max = 600, knots).

element **anpProfilePoint/thrustSet**

diagram	**thrustSet** Corrected net thrust per engine at this point (min = 0.1, max = 99999, lbs or % max thrust).
type	**xs:double**
properties	content simple
annotation	documentation Corrected net thrust per engine at this point (min = 0.1, max = 99999, lbs or % max thrust).

element **anpProfilePoint/opMode**

diagram	**opMode** Operational mode. Valid values: A (Approach), D (Departure), X (Overflight).
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Operational mode. Valid values: A (Approach), D (Departure), X (Overflight).

complexType **anpProfilePoints**

diagram	**anpProfilePoints** — **point** 1..∞ A set of point profile data.
children	**point**
used by	element **anpProfile/profilePoints**
annotation	documentation A set of point profile data.

element **anpProfilePoints/point**

diagram	

type	**anpProfilePoint**
properties	minOcc 1 maxOcc unbounded content complex
children	**pointNum** **distance** **altitude** **speed** **thrustSet** **opMode**

complexType **anpProfileSet**

diagram	
children	**anpAirplaneId** **profile**
used by	element **fleet/anpProfileSet**
annotation	documentation A profile set for an ANP airplane.

element **anpProfileSet/anpAirplaneId**

diagram	
type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's ANP ID.

element **anpProfileSet/profile**

diagram	

type	**anpProfile**
properties	minOcc 1 maxOcc unbounded content complex
children	**operationType** **profileGroupId** **profileStageLength** **weight** **procedureSteps** **profilePoints**
annotation	documentation One or more ANP profiles.

complexType **anpThrustGeneral**

diagram	

children	**thrustType** **coeff_E** **coeff_F** **coeff_GA** **coeff_GB** **coeff_H** **coeff_K1** **coeff_K2**
used by	element **anpThrustSet/thrustGeneral**
annotation	documentation General thrust data for an ANP aircraft.

element **anpThrustGeneral/thrustType**

diagram	**thrustType** The type of generalized thrust-setting.
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation The type of generalized thrust-setting.

element **anpThrustGeneral/coeff_E**

diagram	**coeff_E** Corrected net thrust per engine coefficient. Valid values: -199999.9 through 99999.9. (lb).
type	**xs:double**
properties	content simple
annotation	documentation Corrected net thrust per engine coefficient. Valid values: -199999.9 through 99999.9. (lb).

element **anpThrustGeneral/coeff_F**

diagram	

	coeff_F Speed (TAS) adjustment coefficient. Valid values: -200.00000 through 1000.00000. (lb/knot TAS at sea level and 59°F)
type	**xs:double**
properties	content simple
annotation	documentation Speed (TAS) adjustment coefficient. Valid values: -200.00000 through 1000.00000. (lb/knot TAS at sea level and 59°F)

element **anpThrustGeneral/coeff_GA**

diagram	**coeff_GA** Altitude adjustment coefficient at MSL. (lb/ft)
type	**xs:double**
properties	content simple
annotation	documentation Altitude adjustment coefficient at MSL. (lb/ft)

element **anpThrustGeneral/coeff_GB**

diagram	**coeff_GB** Altitude-squared adjustment coefficient at MSL. (lb/ft^2)
type	**xs:double**
properties	content simple
annotation	documentation Altitude-squared adjustment coefficient at MSL. (lb/ft^2)

element **anpThrustGeneral/coeff_H**

diagram	**coeff_H** Temperature adjustment coefficient. (lb/°C)
type	**xs:double**
properties	content simple
annotation	documentation Temperature adjustment coefficient. (lb/°C)

element **anpThrustGeneral/coeff_K1**

diagram	**coeff_K1** EPR or N1/sqrt(theta) adjustment coefficient. (lb/EPR)
type	**xs:double**
properties	content simple
annotation	documentation EPR or N1/sqrt(theta) adjustment coefficient. (lb/EPR)

element **anpThrustGeneral/coeff_K2**

diagram	**coeff_K2** EPR- or N1/sqrt(theta)-squared adjustment coefficient. (lb/EPR2)
type	**xs:double**
properties	content simple

annotation	documentation EPR- or N1/sqrt(theta)-squared adjustment coefficient. (lb/EPR2)

complexType **anpThrustJet**

diagram	
children	**thrustType coeff_E coeff_F coeff_GA coeff_GB coeff_H**
used by	element **anpThrustSet/thrustJet**
annotation	documentation Jet thrust data for an ANP aircraft.

element **anpThrustJet/thrustType**

diagram	
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of thrust. Primary key UNITS: T = Max Takeoff, S = High Temp Takeoff, C = Max Climb, B = High Temp Climb, N = Max Continuous, M = High Temp Continuous

element **anpThrustJet/coeff_E**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Corrected net thrust per engine coefficient. Valid values: 0.0 through 500000.0. (lb)

element **anpThrustJet/coeff_F**

diagram	

	coeff_F Speed (TAS) adjustment coefficient. Valid values: -200.00000 through 1000.00000. (lb/knot TAS at sea level and 59°F)
type	**xs:double**
properties	content simple
annotation	documentation Speed (TAS) adjustment coefficient. Valid values: -200.00000 through 1000.00000. (lb/knot TAS at sea level and 59°F)

element **anpThrustJet/coeff_GA**

diagram	**coeff_GA** Altitude adjustment coefficient at MSL. (lb/ft)
type	**xs:double**
properties	content simple
annotation	documentation Altitude adjustment coefficient at MSL. (lb/ft)

element **anpThrustJet/coeff_GB**

diagram	**coeff_GB** Altitude-squared adjustment coefficient at MSL. (lb/ft^2)
type	**xs:double**
properties	content simple
annotation	documentation Altitude-squared adjustment coefficient at MSL. (lb/ft^2)

element **anpThrustJet/coeff_H**

diagram	**coeff_H** Temperature adjustment coefficient. (lb/°C)
type	**xs:double**
properties	content simple
annotation	documentation Temperature adjustment coefficient. (lb/°C)

complexType **anpThrustProp**

diagram	
children	**thrustType** **efficiency** **power**
used by	element **anpThrustSet/thrustProp**
annotation	documentation Prop thrust data for an ANP aircraft.

element **anpThrustProp/thrustType**

diagram	**thrustType** Type of thrust.

type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Type of thrust.

element **anpThrustProp/efficiency**

diagram	**efficiency** The propeller efficiency ratio. Valid values: 0.50 to 1.00.
type	**xs:double**
properties	content simple
annotation	documentation The propeller efficiency ratio. Valid values: 0.50 to 1.00.

element **anpThrustProp/power**

diagram	**power** Net propulsive power per engine (HP). Valid values: 0 to 9999.9.
type	**xs:double**
properties	content simple
annotation	documentation Net propulsive power per engine (HP). Valid values: 0 to 9999.9.

complexType **anpThrustSet**

diagram	
children	**anpAirplaneId** **thrustGeneral** **thrustJet** **thrustProp** **tsfcCoefficients**
used by	element **fleet/anpThrustSet**
annotation	documentation Specifies a set of thrust records for an ANP airplane.

element **anpThrustSet/anpAirplaneId**

diagram	**anpAirplaneId** Airplane's ANP ID.
type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's ANP ID.

element **anpThrustSet/thrustGeneral**

diagram	
type	**anpThrustGeneral**
properties	minOcc 0 maxOcc unbounded content complex
children	**thrustType** **coeff_E** **coeff_F** **coeff_GA** **coeff_GB** **coeff_H** **coeff_K1** **coeff_K2**

element **anpThrustSet/thrustJet**

diagram	

type	**anpThrustJet**
properties	minOcc 1 maxOcc unbounded content complex
children	**thrustType** **coeff_E** **coeff_F** **coeff_GA** **coeff_GB** **coeff_H**

element **anpThrustSet/thrustProp**

diagram	
type	**anpThrustProp**
properties	minOcc 1 maxOcc unbounded content complex
children	**thrustType** **efficiency** **power**

element **anpThrustSet/tsfcCoefficients**

diagram	

type	**anpTsfcCoefficients**
properties	minOcc 0 maxOcc unbounded content complex
children	**mode** **k1** **k2** **k3** **k4** **beta1** **beta2** **beta3** **alpha**

complexType **anpTsfcCoefficients**

diagram	

children	**mode** **k1** **k2** **k3** **k4** **beta1** **beta2** **beta3** **alpha**
used by	element **anpThrustSet/tsfcCoefficients**
annotation	documentation TSFC coefficient data for an ANP aircraft.

element **anpTsfcCoefficients/mode**

diagram	**mode** Arrival or departure mode.
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Arrival or departure mode.

element **anpTsfcCoefficients/k1**

diagram	**k1** Departure thrust specific fuel consumption constant coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Departure thrust specific fuel consumption constant coefficient.

element **anpTsfcCoefficients/k2**

diagram	k2 Departure thrust specific fuel consumption Mach number coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Departure thrust specific fuel consumption Mach number coefficient.

element **anpTsfcCoefficients/k3**

diagram	k3 Departure thrust specific fuel consumption altitude coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Departure thrust specific fuel consumption altitude coefficient.

element **anpTsfcCoefficients/k4**

diagram	k4 Departure thrust specific fuel consumption thrust coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Departure thrust specific fuel consumption thrust coefficient.

element **anpTsfcCoefficients/beta1**

diagram	beta1 Arrival thrust specific fuel consumption Mach number coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Arrival thrust specific fuel consumption Mach number coefficient.

element **anpTsfcCoefficients/beta2**

diagram	beta2 Arrival thrust specific fuel consumption altitude coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation

	Arrival thrust specific fuel consumption altitude coefficient.

element **anpTsfcCoefficients/beta3**

diagram	**beta3** Arrival thrust specific fuel consumption thrust coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Arrival thrust specific fuel consumption thrust coefficient.

element **anpTsfcCoefficients/alpha**

diagram	**alpha** Arrival thrust specific fuel consumption constant coefficient.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Arrival thrust specific fuel consumption constant coefficient.

complexType **auxiliaryPowerUnit**

diagram	
children	**name** **baseAuxiliaryPowerUnit** **defaultTimeArrivals** **defaultTimeDepartures** **CO** **HC** **NOx** **SOx** **PM**
used by	element **fleet/auxiliaryPowerUnit**

annotation	documentation This element supports the definition of custom auxiliary power units. These are most often on-board generators that provide electrical power to the aircraft while its engines are shut down.

element **auxiliaryPowerUnit/name**

diagram	**name** Identifying name of APU.
type	**apuName**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 30
annotation	documentation Identifying name of APU.

element **auxiliaryPowerUnit/baseAuxiliaryPowerUnit**

diagram	**baseAuxiliaryPowerUnit** Base reference name, typically a system name.
type	**apuName**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 30
annotation	documentation Base reference name, typically a system name.

element **auxiliaryPowerUnit/defaultTimeArrivals**

diagram	**defaultTimeArrivals** Default length of time APU used for powering arrival aircraft (minutes). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Default length of time APU used for powering arrival aircraft (minutes). Valid values: Nonnegative.

element **auxiliaryPowerUnit/defaultTimeDepartures**

diagram	**defaultTimeDepartures** Default length of time APU used for powering departure aircraft (minutes). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Default length of time APU used for powering departure aircraft (minutes). Valid values: Nonnegative.

element **auxiliaryPowerUnit/CO**

diagram	

	CO Amount of carbon monoxide emitted (kg/hour). Valid values [0…1,000].
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Amount of carbon monoxide emitted (kg/hour). Valid values [0…1,000].

element **auxiliaryPowerUnit/HC**

diagram	HC Amount of hydrocarbons emitted (kg/hour). Valid values [0…1,000].
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Amount of hydrocarbons emitted (kg/hour). Valid values [0…1,000].

element **auxiliaryPowerUnit/NOx**

diagram	NOx Amount of nitrous noxide emitted (kg/hour). Valid values [0…1,000].
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Amount of nitrous noxide emitted (kg/hour). Valid values [0…1,000].

element **auxiliaryPowerUnit/SOx**

diagram	SOx Amount of sulfur oxide emitted (kg/hour). Valid values [0…1,000].
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Amount of sulfur oxide emitted (kg/hour). Valid values [0…1,000].

element **auxiliaryPowerUnit/PM**

diagram	PM Amount of particulate matter emitted (kg/hour). Valid values [0…1,000].
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Amount of particulate matter emitted (kg/hour). Valid values [0…1,000].

complexType **bada4ProcedureStep**

diagram

	gearDown Flag representing if the landing gear is down(1) or not down(0).
children	**stepNumber** **configId** **anpAirplaneId** **anpFlapId** **stepType** **thrustType** **altitude** **calibratedAirspeed** **mach** **thrust** **angle** **climbRate** **distance** **percent** **gearDown**
used by	element **bada4ProcedureSteps/step**
annotation	documentation A single procedure step for the BADA 4 profile.

element **bada4ProcedureStep/stepNumber**

diagram	stepNumber Step number of the procedure. Must be unique in a sequence.
type	**xs:int**
properties	content simple
annotation	documentation Step number of the procedure. Must be unique in a sequence.

element **bada4ProcedureStep/configId**

diagram	configId AFCM configuration ID.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation AFCM configuration ID.

element **bada4ProcedureStep/anpAirplaneId**

diagram	anpAirplaneId Airplane's ANP ID.
type	**anpAirplaneId**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's ANP ID.

element **bada4ProcedureStep/anpFlapId**

diagram	anpFlapId Flap-setting identifier.
type	**anpFlapId**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 6
annotation	documentation Flap-setting identifier.

element **bada4ProcedureStep/stepType**

diagram	**stepType** Step type: (L) Level, (D) Descend, (L) Land, (B) Landing decelerate, (T) Takeoff, (C) Climb, (A) Accelerate, (M) Cruise climb, (S) Fit-to-track distance, (U) Level decelerate (U), (W) Level idle, (E) Descend decelerate, (F) Descend idle, (P) Percent accelerate.
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Step type: (L) Level, (D) Descend, (L) Land, (B) Landing decelerate, (T) Takeoff, (C) Climb, (A) Accelerate, (M) Cruise climb, (S) Fit-to-track distance, (U) Level decelerate (U), (W) Level idle, (E) Descend decelerate, (F) Descend idle, (P) Percent accelerate.

element **bada4ProcedureStep/thrustType**

diagram	**thrustType** Thrust type: (T) MaxTakeoff, (S) MaxTakeoffHiTemp, (F) MaxTakeoffReduce05, (E) MaxTakeoffReduce05HiTemp, (X) MaxTakeoffReduce10, (W) MaxTakeoffReduce10HiTemp, (Z) MaxTakeoffReduce15, (Y) MaxTakeoffReduce15HiTemp, (C) MaxClimb, (B) MaxClimbHiTemp, (D) MaxClimbReduce10, (A) MaxClimbReduce10HiTemp, (N) MaxCont, (M) MaxContHiTemp, (H) ReducedTakeoff, (G) ReducedTakeoffHiTemp, (Q) ReducedClimb, (P) ReducedClimbHiTemp, (R) MinimumThrust, (K) UserCutback, (U) UserValue, (V) ReversedThrust, (L) NormalThrust, (I) IdleApproach, (J) IdleApproachHiTemp, ('') UnknownThrust.
type	**string1**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Thrust type: (T) MaxTakeoff, (S) MaxTakeoffHiTemp, (F) MaxTakeoffReduce05, (E) MaxTakeoffReduce05HiTemp, (X) MaxTakeoffReduce10, (W) MaxTakeoffReduce10HiTemp, (Z) MaxTakeoffReduce15, (Y) MaxTakeoffReduce15HiTemp, (C) MaxClimb, (B) MaxClimbHiTemp, (D) MaxClimbReduce10, (A) MaxClimbReduce10HiTemp, (N) MaxCont, (M) MaxContHiTemp, (H) ReducedTakeoff, (G) ReducedTakeoffHiTemp, (Q) ReducedClimb, (P) ReducedClimbHiTemp, (R) MinimumThrust, (K) UserCutback, (U) UserValue, (V) ReversedThrust, (L) NormalThrust, (I) IdleApproach, (J) IdleApproachHiTemp, ('') UnknownThrust.

element **bada4ProcedureStep/altitude**

diagram	**altitude** Altitude above runway elevation (ARE) for the procedure step. UNITS: feet.
type	**xs:double**
properties	minOcc 0 maxOcc 1

	content simple
annotation	documentation Altitude above runway elevation (ARE) for the procedure step. UNITS: feet.

element **bada4ProcedureStep/calibratedAirspeed**

diagram	**calibratedAirspeed** Calibrated airspeed (KCAS). UNITS: knots.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Calibrated airspeed (KCAS). UNITS: knots.

element **bada4ProcedureStep/mach**

diagram	**mach** Mach number for procedure step. Min= 0.0 Max= 10.0 UNITS: Dimensionless.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Mach number for procedure step. Min= 0.0 Max= 10.0 UNITS: Dimensionless.

element **bada4ProcedureStep/thrust**

diagram	**thrust** Thrust in pounds.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Thrust in pounds.

element **bada4ProcedureStep/angle**

diagram	**angle** Climb or descend angle in degrees. Valid values: 0.00 to 180.00. UNITS: decimal degrees.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Climb or descend angle in degrees. Valid values: 0.00 to 180.00. UNITS: decimal degrees.

element **bada4ProcedureStep/climbRate**

diagram	**climbRate** Climb rate in feet per minute.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple

annotation	documentation Climb rate in feet per minute.

element **bada4ProcedureStep/distance**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Flight segment length in feet.

element **bada4ProcedureStep/percent**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Defines how much energy is spent on acceleration.

element **bada4ProcedureStep/gearDown**

diagram	
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Flag representing if the landing gear is down(1) or not down(0).

complexType **bada4ProcedureSteps**

diagram	
children	**step**
used by	element **bada4Profile/bada4ProcedureSteps**
annotation	documentation Set of procedure steps associated with this BADA 4 profile.

element **bada4ProcedureSteps/step**

diagram	

type	**bada4ProcedureStep**
properties	minOcc 1 maxOcc unbounded content complex
children	**stepNumber** **configId** **anpAirplaneId** **anpFlapId** **stepType** **thrustType** **altitude** **calibratedAirspeed** **mach** **thrust** **angle** **climbRate** **distance** **percent** **gearDown**

annotation	documentation A BADA 4 procedure step.

complexType **bada4Profile**

diagram	
children	**operationType** **flightProcedure** **weightClass** **weight** **bada4ProcedureSteps**
used by	element **bada4ProfileSet/bada4profile**
annotation	documentation BADA 4 profile data element.

element **bada4Profile/operationType**

diagram	
type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Operation associated with this profile. Valid values: A (Approach), D (Depart), T (Touch&Go), F (CircuitFlt), V (OverFlt)

element **bada4Profile/flightProcedure**

diagram	
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Flight procedure identifier. Typically STANDARD, ICAO A, ICAO B or user defined.

element **bada4Profile/weightClass**

diagram	

type	**string1**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation Formerly known as STAGE LENGTH.

element **bada4Profile/weight**

diagram	
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Weight in pounds.

element **bada4Profile/bada4ProcedureSteps**

diagram	
type	**bada4ProcedureSteps**
properties	content complex
children	**step**
annotation	documentation Set of procedure steps associated with this BADA 4 profile.

complexType **bada4ProfileSet**

diagram	
children	**anpAirplaneId** **bada4AirplaneModel** **bada4Engine** **bada4Suffix** **bada4profile**
used by	element **fleet/bada4ProfileSet**
annotation	documentation A profile set for an BADA4 airplane.

element **bada4ProfileSet/anpAirplaneId**

diagram	
type	**anpAirplaneId**
properties	content simple

facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's ANP ID.

element **bada4ProfileSet/bada4AirplaneModel**

diagram	**bada4AirplaneModel** Airplane's BADA 4 model.
type	**bada4AirplaneModel**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's BADA 4 model.

element **bada4ProfileSet/bada4Engine**

diagram	**bada4Engine** Airplane's BADA 4 engine.
type	**bada4Engine**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's BADA 4 engine.

element **bada4ProfileSet/bada4Suffix**

diagram	**bada4Suffix** User-defined BADA 4 model suffix.
type	**bada4Suffix**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation User-defined BADA 4 model suffix.

element **bada4ProfileSet/bada4profile**

diagram	

type	**bada4Profile**
properties	minOcc 1 maxOcc unbounded content complex
children	**operationType** **flightProcedure** **weightClass** **weight** **bada4ProcedureSteps**
annotation	documentation One or more BADA 4 profiles.

complexType **badaAirplane**

diagram	

children **badaAirplaneId** **mfgDescription** **numEngines** **engineTypeCode** **wakeCategory** **referenceAircraftMass** **minAircraftMass** **maxAircraftMass** **maxPayloadMass** **weightGradient** **maxOperatingSpeed** **maxOperatingMachNumber** **maxOperatingAltitude** **maxAltitudeAtMaxTakeoffWeight** **temperatureGradientOnMaximumAltitude** **wingSurfaceArea**

	buffetOnsetLiftCoeff **buffetingGradient** **machDragCoeff**
used by	element **fleet/badaAirplane**
annotation	documentation Block used to create a user defined BADA airplane.

element **badaAirplane/badaAirplaneId**

diagram	**badaAirplaneId** ID of a BADA airplane model. Must be unique.
type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation ID of a BADA airplane model. Must be unique.

element **badaAirplane/mfgDescription**

diagram	**mfgDescription** Manufacturer description.
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Manufacturer description.

element **badaAirplane/numEngines**

diagram	**numEngines** The number of engines.
type	**xs:int**
properties	content simple
annotation	documentation The number of engines.

element **badaAirplane/engineTypeCode**

diagram	**engineTypeCode** The engine type code: J/T/P.
type	**engineType**
properties	content simple
facets	Kind Value Annotation pattern Jet|J|Turbo|Turboprop|T|Prop|Piston|P
annotation	documentation The engine type code: J/T/P.

element **badaAirplane/wakeCategory**

diagram	**wakeCategory** The wake category.
type	**badaWakeType**
properties	content simple

facets	Kind Value Annotation pattern Heavy|H|Light|L|Medium|M|SuperHeavy|J
annotation	documentation The wake category.

element **badaAirplane/referenceAircraftMass**

diagram	**referenceAircraftMass** Minimum aircraft mass (min = 0.0, max = 455.0, metric ton).
type	**xs:double**
properties	content simple
annotation	documentation Minimum aircraft mass (min = 0.0, max = 455.0, metric ton).

element **badaAirplane/minAircraftMass**

diagram	**minAircraftMass** Minimum aircraft mass (min = 0.0, max = 455.0, metric ton).
type	**xs:double**
properties	content simple
annotation	documentation Minimum aircraft mass (min = 0.0, max = 455.0, metric ton).

element **badaAirplane/maxAircraftMass**

diagram	**maxAircraftMass** Maximum aircraft mass (min = 0.0, max = 455.0, metric ton).
type	**xs:double**
properties	content simple
annotation	documentation Maximum aircraft mass (min = 0.0, max = 455.0, metric ton).

element **badaAirplane/maxPayloadMass**

diagram	**maxPayloadMass** Maximum payload mass (min = 0.0, max = 455.0, (metric ton).
type	**xs:double**
properties	content simple
annotation	documentation Maximum payload mass (min = 0.0, max = 455.0, (metric ton).

element **badaAirplane/weightGradient**

diagram	**weightGradient** Weight gradient on maximum altitude (min = 0.0, max = 10.0, feet/kg).
type	**xs:double**
properties	content simple
annotation	documentation Weight gradient on maximum altitude (min = 0.0, max = 10.0, feet/kg).

element **badaAirplane/maxOperatingSpeed**

diagram	

	maxOperatingSpeed Maximum operating speed (KCAS) (min = 0.0, max = 600.0, UNITS: knots).
type	**xs:double**
properties	content simple
annotation	documentation Maximum operating speed (KCAS) (min = 0.0, max = 600.0, UNITS: knots).

element **badaAirplane/maxOperatingMachNumber**

diagram	**maxOperatingMachNumber** Maximum operating Mach number (min = 0.0, max = 10.0, UNITS: dimensionless).
type	**xs:double**
properties	content simple
annotation	documentation Maximum operating Mach number (min = 0.0, max = 10.0, UNITS: dimensionless).

element **badaAirplane/maxOperatingAltitude**

diagram	**maxOperatingAltitude** Maximum operating altitude (min = -9999.0, max = 60000.0, UNITS: feet, pressure altitude).
type	**xs:double**
properties	content simple
annotation	documentation Maximum operating altitude (min = -9999.0, max = 60000.0, UNITS: feet, pressure altitude).

element **badaAirplane/maxAltitudeAtMaxTakeoffWeight**

diagram	**maxAltitudeAtMaxTakeoffWeight** Maximum altitude at maximum takeoff weight and ISA (Min = -9999.0, Max = 60000.0, UNITS: feet, pressure altitude).
type	**xs:double**
properties	content simple
annotation	documentation Maximum altitude at maximum takeoff weight and ISA (Min = -9999.0, Max = 60000.0, UNITS: feet, pressure altitude).

element **badaAirplane/temperatureGradientOnMaximumAltitude**

diagram	**temperatureGradientOnMaximum...** Temperature gradient on maximum altitude.
type	**xs:double**
properties	content simple
annotation	documentation Temperature gradient on maximum altitude.

element **badaAirplane/wingSurfaceArea**

diagram	**wingSurfaceArea** Wing surface area (min = 0.0, max = 1000.0, square meters).
type	**xs:double**
properties	content simple
annotation	documentation

	Wing surface area (min = 0.0, max = 1000.0, square meters).

element **badaAirplane/buffetOnsetLiftCoeff**

diagram	**buffetOnsetLiftCoeff** Buffet onset lift coefficient (jet only) (min = 0.0, max = 10.0).
type	**xs:double**
properties	content simple
annotation	documentation Buffet onset lift coefficient (jet only) (min = 0.0, max = 10.0).

element **badaAirplane/buffetingGradient**

diagram	**buffetingGradient** Buffeting gradient (jet only).
type	**xs:double**
properties	content simple
annotation	documentation Buffeting gradient (jet only).

element **badaAirplane/machDragCoeff**

diagram	**machDragCoeff** Mach drag coefficient (min = 0.0, max = 10.0).
type	**xs:double**
properties	content simple
annotation	documentation Mach drag coefficient (min = 0.0, max = 10.0).

complexType **badaAltitudeDistribution**

diagram	
children	**altitudeCount** **distanceMean** **distanceStddev** **distanceLow** **distanceHigh** **altitude**
used by	element **badaAltitudeDistributionSet/altitudeDistribution**
annotation	documentation BADA altitude distribution data.

element **badaAltitudeDistribution/altitudeCount**

diagram	

	altitudeCount Flight counts for a selected altitude.
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Flight counts for a selected altitude.

element **badaAltitudeDistribution/distanceMean**

diagram	**distanceMean** Mean distance for a selected altitude. (nMi).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Mean distance for a selected altitude. (nMi).

element **badaAltitudeDistribution/distanceStddev**

diagram	**distanceStddev** Standard deviation for the distance of a selected altitude. (nMi).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Standard deviation for the distance of a selected altitude. (nMi).

element **badaAltitudeDistribution/distanceLow**

diagram	**distanceLow** Min distance for a selected altitude. (nMi).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Min distance for a selected altitude. (nMi).

element **badaAltitudeDistribution/distanceHigh**

diagram	**distanceHigh** Maximum distance for a selected altitude. (nMi).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Maximum distance for a selected altitude. (nMi).

element **badaAltitudeDistribution/altitude**

diagram	

	altitude The selected cruise altitude MSL. UNITS: feet.
type	**xs:int**
properties	content simple
annotation	documentation The selected cruise altitude MSL. UNITS: feet.

complexType **badaAltitudeDistributionSet**

diagram	
children	**badaAirplaneId** **altitudeDistribution**
used by	elements **fleet/badaAltitudeDistributionSet** **fleet/badaDefaultAltitudeDistributionSet**
annotation	documentation A block for defining a BADA altitude distribution set.

element **badaAltitudeDistributionSet/badaAirplaneId**

diagram	**badaAirplaneId** Airplane's BADA ID.
type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane's BADA ID.

element **badaAltitudeDistributionSet/altitudeDistribution**

diagram	
type	**badaAltitudeDistribution**
properties	minOcc 1 maxOcc unbounded content complex
children	**altitudeCount** **distanceMean** **distanceStddev** **distanceLow** **distanceHigh** **altitude**

complexType **badaConfig**

diagram	
children	**phase** **configName** **stallSpeed** **parasiticDrag** **inducedDrag**
used by	element **badaConfigSet/badaConfig**
annotation	documentation BADA Configuration Coefficient data.

element **badaConfig/phase**

diagram	
type	**badaPhaseType**
properties	content simple
facets	Kind Value Annotation pattern InitialClimb|IC|Takeoff|TO|Approach|AP|Landing|LD|Cruise|CR
annotation	documentation .The phase of flight (IC=initial climb, TO=take-off, AP=approach, LD=landing).

element **badaConfig/configName**

diagram	
type	**string10**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 10
annotation	documentation The configuration identifier.

element **badaConfig/stallSpeed**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1

	content simple
annotation	documentation Stall speed, CAS. Valid values: 0.0 through 600.0. UNITS: knots.

element **badaConfig/parasiticDrag**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The parasitic drag coefficient. Valid values: 0.0 through 10.0.

element **badaConfig/inducedDrag**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation The induced drag coefficient. Valid values: 0.0 through 10.0.

complexType **badaConfigSet**

diagram	
children	**badaAirplaneId** **badaConfig**
used by	element **fleet/badaConfigSet**
annotation	documentation A block for a custom BADA airplane configuration coefficient set.

element **badaConfigSet/badaAirplaneId**

diagram	
type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The BADA airplane ID for the profile set.

element **badaConfigSet/badaConfig**

diagram	

type	**badaConfig**
properties	minOcc 1 maxOcc unbounded content complex
children	**phase configName stallSpeed parasiticDrag inducedDrag**
annotation	documentation The BADA configuration coefficient data.

complexType **badaFuel**

diagram	
children	**badaAirplaneId coeff_CF1 coeff_CF2 coeff_CF3 coeff_CF4 coeff_CR**
used by	element **fleet/badaFuel**
annotation	documentation A BADA Fuel data record.

element **badaFuel/badaAirplaneId**

diagram	

type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The BADA aircraft ID

element **badaFuel/coeff_CF1**

diagram	**coeff_CF1** 1st thrust specific fuel consumption coefficient. Valid values: 0.0 through 10.0. Variable units. (kg/(min•kN) (jet); kg/(min•kN•knot); (turboprop); kg/min (piston))
type	**xs:double**
properties	content simple
annotation	documentation 1st thrust specific fuel consumption coefficient. Valid values: 0.0 through 10.0. Variable units. (kg/(min•kN) (jet); kg/(min•kN•knot); (turboprop); kg/min (piston))

element **badaFuel/coeff_CF2**

diagram	**coeff_CF2** 2nd thrust specific fuel consumption coefficient. Valid values: 0.0 through 1. UNITS: knots.
type	**xs:double**
properties	content simple
annotation	documentation 2nd thrust specific fuel consumption coefficient. Valid values: 0.0 through 1. UNITS: knots.

element **badaFuel/coeff_CF3**

diagram	**coeff_CF3** 1st descent fuel flow coefficient. Min= Valid values: 0.0 through 100.0.(kg/min)
type	**xs:double**
properties	content simple
annotation	documentation 1st descent fuel flow coefficient. Min= Valid values: 0.0 through 100.0.(kg/min)

element **badaFuel/coeff_CF4**

diagram	**coeff_CF4** 2nd descent fuel flow coefficient. Valid values: 0.0 through 1. (feet)
type	**xs:double**
properties	content simple
annotation	documentation 2nd descent fuel flow coefficient. Valid values: 0.0 through 1. (feet)

element **badaFuel/coeff_CR**

diagram	**coeff_CR** Cruise fuel flow correction coefficient. Valid values: 0.0 through 10.0.
type	**xs:double**

properties	content simple
annotation	documentation Cruise fuel flow correction coefficient. Valid values: 0.0 through 10.0.

complexType **badaProfile**

diagram

children	**massRangeValue** **companyCode1** **companyCode2** **companyName** **aircraftVersion** **engine** **climbSpeedBelowTransitionAltitude** **climbSpeedAboveTransitionAltitude** **climbMachNumber** **cruiseSpeedBelowTransitionAltitude** **cruiseSpeedAboveTransitionAltitude** **cruiseMachNumber** **descentSpeedUnderTransitionAltitude** **descentSpeedOverTransitionAltitude** **descentMachNumber**
used by	element **badaProfileSet/profile**

annotation	documentation A BADA profile APF (airline procedures file) record.

element **badaProfile/massRangeValue**

diagram	**massRangeValue** Mass range. Valid values: LO (low range), AV (average range), HI (high range).
type	**string2**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 2
annotation	documentation Mass range. Valid values: LO (low range), AV (average range), HI (high range).

element **badaProfile/companyCode1**

diagram	**companyCode1** Three-letter company code.
type	**string3**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 3
annotation	documentation Three-letter company code.

element **badaProfile/companyCode2**

diagram	**companyCode2** Two-letter company code.
type	**string2**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 2
annotation	documentation Two-letter company code.

element **badaProfile/companyName**

diagram	**companyName** Name of airline that uses this procedure.
type	**string15**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 15
annotation	documentation Name of airline that uses this procedure.

element **badaProfile/aircraftVersion**

diagram	**aircraftVersion** Aircraft version to which this procedure applies.
type	**string12**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 12
annotation	documentation Aircraft version to which this procedure applies.

element **badaProfile/engine**

diagram	**engine** Engine identifier.
type	**string12**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 12
annotation	documentation Engine identifier.

element **badaProfile/climbSpeedBelowTransitionAltitude**

diagram	**climbSpeedBelowTransitionAltitude** Standard climb calibrated speed (KCAS) between 1,500 / 6,000 and 10,000 ft (MSL). Min= 0.0 Max= 600.0: UNITS: knots.
type	**xs:short**
properties	content simple
annotation	documentation Standard climb calibrated speed (KCAS) between 1,500 / 6,000 and 10,000 ft (MSL). Min= 0.0 Max= 600.0: UNITS: knots.

element **badaProfile/climbSpeedAboveTransitionAltitude**

diagram	**climbSpeedAboveTransitionAltitu...** Standard climb speed (KCAS) between 10,000 ft (MSL) and Mach transition altitude. Min= 0.0 Max= 600.0: UNITS: knots.
type	**xs:short**
properties	content simple
annotation	documentation Standard climb speed (KCAS) between 10,000 ft (MSL) and Mach transition altitude. Min= 0.0 Max= 600.0: UNITS: knots.

element **badaProfile/climbMachNumber**

diagram	**climbMachNumber** Standard climb Mach number above Mach transition altitude (MSL). Min= 0.0 Max= 10.0. UNITS: Dimensionless.
type	**xs:double**
properties	content simple

annotation	documentation Standard climb Mach number above Mach transition altitude (MSL). Min= 0.0 Max= 10.0. UNITS: Dimensionless.

element **badaProfile/cruiseSpeedBelowTransitionAltitude**

diagram	**cruiseSpeedBelowTransitionAltitu...** Standard cruise speed (KCAS) between 3,000 and 10,000 ft (MSL). Min= 0.0 Max= 600.0: UNITS: knots.
type	**xs:short**
properties	content simple
annotation	documentation Standard cruise speed (KCAS) between 3,000 and 10,000 ft (MSL). Min= 0.0 Max= 600.0: UNITS: knots.

element **badaProfile/cruiseSpeedAboveTransitionAltitude**

diagram	**cruiseSpeedAboveTransitionAltitu...** Standard cruise speed (KCAS) above 10,000 ft (MSL) until Mach transition altitude. Min= 0.0 Max= 600.0: UNITS: knots.
type	**xs:short**
properties	content simple
annotation	documentation Standard cruise speed (KCAS) above 10,000 ft (MSL) until Mach transition altitude. Min= 0.0 Max= 600.0: UNITS: knots.

element **badaProfile/cruiseMachNumber**

diagram	**cruiseMachNumber** Standard cruise Mach number above transition altitude (MSL). Min= 0.0 Max= 10.0 UNITS: Dimensionless.
type	**xs:double**
properties	content simple
annotation	documentation Standard cruise Mach number above transition altitude (MSL). Min= 0.0 Max= 10.0 UNITS: Dimensionless.

element **badaProfile/descentSpeedUnderTransitionAltitude**

diagram	**descentSpeedUnderTransitionAltit...** Standard descent speed (KCAS) between 3,000 / 6,000 and 10,000 ft (MSL). Min= 0.0 Max= 600.0. UNITS: knots.
type	**xs:short**
properties	content simple
annotation	documentation Standard descent speed (KCAS) between 3,000 / 6,000 and 10,000 ft (MSL). Min= 0.0 Max= 600.0. UNITS: knots.

element **badaProfile/descentSpeedOverTransitionAltitude**

diagram	**descentSpeedOverTransitionAltitu...** Standard descent speed (KCAS) above 10,000 ft (MSL) until Mach transition. Min= 0.0 Max= 600.0. UNITS: knots.
type	**xs:short**
properties	content simple
annotation	documentation Standard descent speed (KCAS) above 10,000 ft (MSL) until Mach transition. Min= 0.0 Max= 600.0. UNITS: knots.

element **badaProfile/descentMachNumber**

diagram	

	descentMachNumber Standard descent Mach number above transition altitude (MSL). Min= 0.0 Max= 10.0 UNITS: Dimensionless.
type	**xs:double**
properties	content simple
annotation	documentation Standard descent Mach number above transition altitude (MSL). Min= 0.0 Max= 10.0 UNITS: Dimensionless.

complexType **badaProfileSet**

diagram	
children	**badaAirplaneId** **profile**
used by	element **fleet/badaProfileSet**
annotation	documentation A block used to define a custom BADA profile set.

element **badaProfileSet/badaAirplaneId**

diagram	**badaAirplaneId** The BADA airplane ID for the profile set.
type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The BADA airplane ID for the profile set.

element **badaProfileSet/profile**

diagram	

type	**badaProfile**
properties	minOcc 1 maxOcc unbounded content complex
children	**massRangeValue** **companyCode1** **companyCode2** **companyName** **aircraftVersion** **engine** **climbSpeedBelowTransitionAltitude** **climbSpeedAboveTransitionAltitude** **climbMachNumber** **cruiseSpeedBelowTransitionAltitude** **cruiseSpeedAboveTransitionAltitude** **cruiseMachNumber** **descentSpeedUnderTransitionAltitude** **descentSpeedOverTransitionAltitude** **descentMachNumber**

annotation	documentation The profile set data.

complexType **badaThrust**

diagram	
children	**badaAirplaneId** **coeff_TC1** **coeff_TC2** **coeff_TC3** **coeff_TC4** **coeff_TC5** **coeff_TDL** **coeff_TDH** **coeff_APP** **coeff_LD** **descentAlt** **descentSpeed** **descentMach** **notes**
used by	element **fleet/badaThrust**
annotation	documentation A custom BADA thrust data record.

element **badaThrust/badaAirplaneId**

diagram	

	badaAirplaneId The BADA airplane ID.
type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The BADA airplane ID.

element **badaThrust/coeff_TC1**

diagram	**coeff_TC1** 1st max climb thrust coefficient. Valid values: 0.0 through 1.
type	**xs:double**
properties	content simple
annotation	documentation 1st max climb thrust coefficient. Valid values: 0.0 through 1.

element **badaThrust/coeff_TC2**

diagram	**coeff_TC2** 2nd max climb thrust coefficient. Valid values: 0.0 through 1e9. (feet)
type	**xs:double**
properties	content simple
annotation	documentation 2nd max climb thrust coefficient. Valid values: 0.0 through 1e9. (feet)

element **badaThrust/coeff_TC3**

diagram	**coeff_TC3** 3rd max climb thrust coefficient. Valid values: -1034000 to 665880. Variable units. (1/feet^2 (jet); Newton (turboprop); knot-Newton (piston))
type	**xs:double**
properties	content simple
annotation	documentation 3rd max climb thrust coefficient. Valid values: -1034000 to 665880. Variable units. (1/feet^2 (jet); Newton (turboprop); knot-Newton (piston))

element **badaThrust/coeff_TC4**

diagram	**coeff_TC4** 1st thrust temperature coefficient. Valid values: -45 through 50. (K)
type	**xs:double**
properties	content simple
annotation	documentation 1st thrust temperature coefficient. Valid values: -45 through 50. (K)

element **badaThrust/coeff_TC5**

diagram	**coeff_TC5** 2nd thrust temperature coefficient. Valid values: 0.0 through 10.0. (1/K)

type	**xs:double**
properties	content simple
annotation	documentation 2nd thrust temperature coefficient. Valid values: 0.0 through 10.0. (1/K)

element **badaThrust/coeff_TDL**

diagram	**coeff_TDL** Low altitude descent thrust coefficient. Valid values: 0.0 through 10.0
type	**xs:double**
properties	content simple
annotation	documentation Low altitude descent thrust coefficient. Valid values: 0.0 through 10.0

element **badaThrust/coeff_TDH**

diagram	**coeff_TDH** High altitude descent thrust coefficient. Valid values: 0.0 through 10.0
type	**xs:double**
properties	content simple
annotation	documentation High altitude descent thrust coefficient. Valid values: 0.0 through 10.0

element **badaThrust/coeff_APP**

diagram	**coeff_APP** Approach thrust coefficient. Valid values: 0.0 through 10.0.
type	**xs:double**
properties	content simple
annotation	documentation Approach thrust coefficient. Valid values: 0.0 through 10.0.

element **badaThrust/coeff_LD**

diagram	**coeff_LD** Landing thrust coefficient. Valid values: 0.0 through 10.0.
type	**xs:double**
properties	content simple
annotation	documentation Landing thrust coefficient. Valid values: 0.0 through 10.0.

element **badaThrust/descentAlt**

diagram	**descentAlt** Transition altitude for calculation of descent thrust. Min= -9999.0 Max= 60000.0 UNITS: Feet, pressure altitude
type	**xs:double**
properties	content simple
annotation	documentation Transition altitude for calculation of descent thrust. Min= -9999.0 Max= 60000.0 UNITS: Feet, pressure altitude

element **badaThrust/descentSpeed**

diagram	**descentSpeed** Reference descent speed (KCAS). Min= 0.0 Max= 600.0. UNITS: knots.
type	**xs:double**
properties	content simple
annotation	documentation Reference descent speed (KCAS). Min= 0.0 Max= 600.0. UNITS: knots.

element **badaThrust/descentMach**

diagram	**descentMach** Reference descent Mach number. Valid values: 0.0 through 10.0, UNITS: dimensionless.
type	**xs:float**
properties	content simple
annotation	documentation Reference descent Mach number. Valid values: 0.0 through 10.0, UNITS: dimensionless.

element **badaThrust/notes**

diagram	**notes** User notes.
type	**string255**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation User notes.

complexType **coord2DType**

diagram	

children	**latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone**
used by	elements **stationarySourceOperation/pointCoord** **pointStationarySource/pointCoord** **volumeStationarySource/pointCoord** **oneOrThreeCoords2DGroupSet/pointCoord** **polygon2DType/vertex** complexType **coord3DElevationType**
annotation	documentation A 2D point coordinate.

complexType **coord3DElevationType**

diagram	

type	extension of **coord2DType**
properties	base coord2DType
children	**latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone elevation**
used by	elements **roadway/coordinates/vertex polygon3DElevationType/vertex**
annotation	documentation Type of coordinates used to specify a point in three-dimensional space. The type is actually the type of the point in two-dimensional space along with an elevation.

element **coord3DElevationType/elevation**

diagram	**elevation** Elevation or Z value for a coordinate.
type	**xs:float**
properties	content simple
annotation	documentation Elevation or Z value for a coordinate.

complexType **dispersionWeight1Type**

diagram	**dispersionWeight1Type** — **backbone** Abstract type used to specify the dispersion weight for the backbone subtrack. This type is intended only to be a base class and will not be used in ASIF files directly. Represents the centerline of a set of dispersed tracks.
children	**backbone**
used by	element **dispersionWeight/dispersionWeight1** complexType **dispersionWeight3Type**
annotation	documentation Abstract type used to specify the dispersion weight for the backbone subtrack. This type is intended only to be a base class and will not be used in ASIF files directly.

element **dispersionWeight1Type/backbone**

diagram	
type	**xs:double**
properties	content simple
used by	element **track**
annotation	documentation Represents the centerline of a set of dispersed tracks.

complexType **dispersionWeight3Type**

diagram	
type	extension of **dispersionWeight1Type**
properties	base dispersionWeight1Type
children	**backbone** **weightl1** **weightr1**
used by	element **dispersionWeight/dispersionWeight3** complexType **dispersionWeight5Type**
annotation	documentation Specify the dispersion weight for a backbone with 2 subtracks..

element **dispersionWeight3Type/weightl1**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Specify the dispersion weight for the first left subtrack.

element **dispersionWeight3Type/weightr1**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Specify the dispersion weight for the first right subtrack.

complexType **dispersionWeight5Type**

diagram	

type	extension of **dispersionWeight3Type**
properties	base dispersionWeight3Type
children	**backbone** **weightl1** **weightr1** **weightl2** **weightr2**
used by	element **dispersionWeight/dispersionWeight5** complexType **dispersionWeight7Type**
annotation	documentation Specify the dispersion weight for a backbone with 4 subtracks.

element **dispersionWeight5Type/weightl2**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Specify the dispersion weight for the second left subtrack.

element **dispersionWeight5Type/weightr2**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Specify the dispersion weight for the second right subtrack.

complexType **dispersionWeight7Type**

diagram	

type	extension of **dispersionWeight5Type**
properties	base dispersionWeight5Type
children	**backbone** **weightl1** **weightr1** **weightl2** **weightr2** **weightl3** **weightr3**
used by	element **dispersionWeight/dispersionWeight7** complexType **dispersionWeight9Type**
annotation	documentation Specify the dispersion weight for a backbone with 6 subtracks.

element **dispersionWeight7Type/weightl3**

diagram	**weightl3** Specify the dispersion weight for the third left subtrack.
type	**xs:double**
properties	content simple
annotation	documentation Specify the dispersion weight for the third left subtrack.

element **dispersionWeight7Type/weightr3**

diagram	**weightr3** Specify the dispersion weight for the third right subtrack.
type	**xs:double**
properties	content simple
annotation	documentation Specify the dispersion weight for the third right subtrack.

complexType **dispersionWeight9Type**

diagram	

type	extension of **dispersionWeight7Type**
properties	base dispersionWeight7Type
children	**backbone** **weightl1** **weightr1** **weightl2** **weightr2** **weightl3** **weightr3** **weightl4** **weightr4**
used by	element **dispersionWeight/dispersionWeight9**
annotation	documentation Specify the dispersion weight for a backbone with 8 subtracks.

element **dispersionWeight9Type/weightl4**

diagram	**weightl4** Specify the dispersion weight for the fourth left subtrack.
type	**xs:double**
properties	content simple
annotation	documentation Specify the dispersion weight for the fourth left subtrack.

element **dispersionWeight9Type/weightr4**

diagram	**weightr4** Specify the dispersion weight for the fourth right subtrack.
type	**xs:double**
properties	content simple
annotation	documentation

	Specify the dispersion weight for the fourth right subtrack.

complexType **emissionFactorSet**

diagram	
children	**CO** **HC** **NOx** **SOx** **PM10**
used by	elements **userGroundSupportEquipment/userEmissionFactors/emissionFactorsCNG** **userGroundSupportEquipment/userEmissionFactors/emissionFactorsDiesel** **userGroundSupportEquipment/userEmissionFactors/emissionFactorsGas** **userGroundSupportEquipment/userEmissionFactors/emissionFactorsLPG**
annotation	documentation Supports legacy EDMS studies relating to content that contains emission factor definitions. This element supports the definition of various emission factors defined under GSE and training fires.

element **emissionFactorSet/CO**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Amount of carbon monoxide emitted. Valid values: 0 to 3000. (kg/unit)

element **emissionFactorSet/HC**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Amount of hydrocarbons emitted. Valid values: 0 to 100. (kg/unit)

element **emissionFactorSet/NOx**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation Amount of nitrous oxides emitted. Valid values: 0 to 100. (kg/unit)

element **emissionFactorSet/SOx**

diagram	**SOx** Amount of sulfur oxides emitted. Valid values: 0 to 10. (kg/unit)
type	**xs:double**
properties	content simple
annotation	documentation Amount of sulfur oxides emitted. Valid values: 0 to 10. (kg/unit)

element **emissionFactorSet/PM10**

diagram	**PM10** Amount of 10-micron particulate matter emitted. Valid values: 0 to 1000. (kg/unit)
type	**xs:double**
properties	content simple
annotation	documentation Amount of 10-micron particulate matter emitted. Valid values: 0 to 1000. (kg/unit)

complexType **energyShare**

diagram	
children	**anpAirplaneId** **badaAirplaneId** **transEnergyShare**
used by	element **fleet/energyShare**
annotation	documentation A custom BADA energy share.

element **energyShare/anpAirplaneId**

diagram	**anpAirplaneId** The ANP airplane ID.
type	**anpAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation The ANP airplane ID.

element **energyShare/badaAirplaneId**

diagram	**badaAirplaneId** The BADA airplane ID.
type	**badaAirplaneId**
properties	content simple
facets	Kind Value Annotation minLength 0

	maxLength 255
annotation	documentation The BADA airplane ID.

element **energyShare/transEnergyShare**

diagram	
type	**xs:double**
properties	content simple
annotation	documentation The proportion of available energy used for acceleration compared to altitude change in the ANP to BADA transition region.

complexType **engineModeEmissions**

diagram	
children	**time fuel CO HC NOx SOx SN PM**
used by	elements **aircraftEngine/approachEmissionFactors aircraftEngine/climbEmissionFactors aircraftEngine/takeOffEmissionFactors aircraftEngine/taxiIdleEmissionFactors**
annotation	documentation Describes custom emission factors user-defined aircraft engines.

element **engineModeEmissions/time**

diagram	
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation

	Time engine operates in a given mode (minutes). Valid values: Nonnegative.

element **engineModeEmissions/fuel**

diagram	fuel Fuel emission factor (g/kg). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Fuel emission factor (g/kg). Valid values: Nonnegative.

element **engineModeEmissions/CO**

diagram	CO Amount of carbon monoxide emitted (g/kg). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of carbon monoxide emitted (g/kg). Valid values: Nonnegative.

element **engineModeEmissions/HC**

diagram	HC Amount of hydrocarbons emitted (g/kg). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of hydrocarbons emitted (g/kg). Valid values: Nonnegative.

element **engineModeEmissions/NOx**

diagram	NOx Amount of nitrous oxide emitted (g/kg). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of nitrous oxide emitted (g/kg). Valid values: Nonnegative.

element **engineModeEmissions/SOx**

diagram	SOx Amount of sulfur oxide emitted (g/kg). Valid values: Nonnegative.
type	**xs:double**

properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Amount of sulfur oxide emitted (g/kg). Valid values: Nonnegative.

element **engineModeEmissions/SN**

diagram	**SN** Smoke number for the engine mode (g/kg).Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Smoke number for the engine mode (g/kg).Valid values: Nonnegative.

element **engineModeEmissions/PM**

diagram	**PM** Amount of particulate matter emitted (g/kg). Valid values: Nonnegative.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Amount of particulate matter emitted (g/kg). Valid values: Nonnegative.

complexType **fleet**

diagram

auxiliaryPowerUnit 0..∞
Describes a custom auxiliary power unit (APU). These are typically on-board generators providing power to a parked aircraft.

airframe 0..∞
Supports the definition of custom airframes.

engine 0..∞
User defined engine information containing custom parameters that reflect an aircraft engine. This engine definition can then be used within a user-defined aircraft.

engineMod 0..∞
User defined engine modification information containing custom parameters that reflect an aircraft engine modification. This engine modification definition can that be used within a user defined aircraft.

spectralClass 0..∞
This element contains user-defined spectral class data.

anpNoiseGroup 0..∞
This element contains the

three spectral class references for a given aircraft noise group with the corresponding thrust setting type and model type.
anpAirplane
0..∞
Creates a new ANP aircraft.
anpFlapsSet
0..∞
Flap settings for an ANP aircraft type.
anpThrustSet
0..∞
Specifies a set of thrust records for an ANP aircraft.
anpProfileSet
0..∞
The profile set for an ANP aircraft.
anpHeloNoiseGroup
0..∞
This element contains the three spectral class references for a given helicopter noise group with the corresponding thrust setting type and model type.
fleet
Main block for creating user defined fleet/aircraft data.
anpHelicopter
0..∞
Creates a new ANP helicopter.
anpHeloDirectivitySet
0..∞
A set of helicopter directivities.
anpHeloProfileSet
0..∞
A profile set for an ANP helicopter.
badaAirplane
0..∞
Describes a new user-defined BADA airplane.
badaAltitudeDistributionSet
0..∞
A block for defining a BADA altitude distribution set.
badaDefaultAltitudeDistribution...
0..∞
A block for defining the BADA default altitude distribution set.
badaProfileSet
0..∞
A block used to define a custom BADA profile set.
badaConfigSet
0..∞
A block for a custom BADA airplane configuration coefficient set.
badaFuel
0..∞
A BADA fuel data record.
badaThrust
0..∞
Custom BADA airplane thrust data sets.
bada4ProfileSet
0..∞

children	**auxiliaryPowerUnit** **airframe** **engine** **engineMod** **spectralClass** **anpNoiseGroup** **anpAirplane** **anpFlapsSet** **anpThrustSet** **anpProfileSet** **anpHeloNoiseGroup** **anpHelicopter** **anpHeloDirectivitySet** **anpHeloProfileSet** **badaAirplane** **badaAltitudeDistributionSet** **badaDefaultAltitudeDistributionSet** **badaProfileSet** **badaConfigSet** **badaFuel** **badaThrust** **bada4ProfileSet** **aircraft** **energyShare**
used by	elements **AsifXml/fleet** **study/fleet**
annotation	documentation Main block for creating user defined fleet/aircraft data.

element **fleet/auxiliaryPowerUnit**

diagram	
type	**auxiliaryPowerUnit**
properties	minOcc 0 maxOcc unbounded content complex
children	**name** **baseAuxiliaryPowerUnit** **defaultTimeArrivals** **defaultTimeDepartures** **CO** **HC** **NOx** **SOx** **PM**
annotation	documentation Describes a custom auxiliary power unit (APU). These are typically on-board generators providing power to a parked aircraft.

element **fleet/airframe**

diagram	

type	**airframe**
properties	minOcc 0 maxOcc unbounded content complex
children	**model** **engineCount** **engineLocation** **designationCode** **maxRange** **introYear** **euroGroupCode** **usageCode** **sizeCode** **engineType** **auxiliaryPowerUnitId**
annotation	documentation Supports the definition of custom airframes.

element **fleet/engine**

diagram	

type	**aircraftEngine**
properties	minOcc 0 maxOcc unbounded content complex

children	**code** **model** **engineType** **notes** **emissionsEngineModel** **performanceEngineModel** **manufacturer** **combustor** **superseded** **ratedEngineOut** **source** **bypassRatio** **pressureRatio** **tfmtFlag** **defaultSOx** **taxiIdleEmissionFactors** **takeOffEmissionFactors** **climbEmissionFactors** **approachEmissionFactors**
annotation	documentation User defined engine information containing custom parameters that reflect an aircraft engine. This engine definition can then be used within a user-defined aircraft.

element **fleet/engineMod**

diagram	
type	**aircraftEngineMod**
properties	minOcc 0 maxOcc unbounded content complex
children	**code** **description**
annotation	documentation User defined engine modification information containing custom parameters that reflect an aircraft engine modification. This engine modification definition can that be used within a user defined aircraft.

element **fleet/spectralClass**

diagram	

type	**spectralClass**
properties	minOcc 0

	maxOcc unbounded content complex
children	**spectralClassId** **flightTypes** **frequencyBand17** **frequencyBand18** **frequencyBand19** **frequencyBand20** **frequencyBand21** **frequencyBand22** **frequencyBand23** **frequencyBand24** **frequencyBand25** **frequencyBand26** **frequencyBand27** **frequencyBand28** **frequencyBand29** **frequencyBand30** **frequencyBand31** **frequencyBand32** **frequencyBand33** **frequencyBand34** **frequencyBand35** **frequencyBand36** **frequencyBand37** **frequencyBand38** **frequencyBand39** **frequencyBand40**
annotation	documentation This element contains user-defined spectral class data.

element **fleet/anpNoiseGroup**

diagram	
type	**anpNoiseGroup**
properties	minOcc 0 maxOcc unbounded content complex
children	**noiseId** **spectralClassApproach** **spectralClassDeparture** **spectralClassAfterburner** **thrustSetType** **modelType** **npdCurves**
annotation	documentation This element contains the three spectral class references for a given aircraft noise group with the corresponding thrust setting type and model type.

element **fleet/anpAirplane**

diagram	

type	**anpAirplane**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpAirplaneId** **description** **sizeCode** **owner** **engineTypeCode** **numberEngines** **maxGrossWeightTakeoff** **maxGrossWeightLand** **maxDsStop** **depThrustCoeffType** **thrustStatic** **thrustRestore** **noiseId** **noiseCategory** **minBurn**
annotation	documentation Creates a new ANP aircraft.

element **fleet/anpFlapsSet**

diagram	
type	**anpFlapsSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpAirplaneId** **flaps**
annotation	documentation Flap settings for an ANP aircraft type.

element **fleet/anpThrustSet**

diagram	
type	**anpThrustSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpAirplaneId** **thrustGeneral** **thrustJet** **thrustProp** **tsfcCoefficients**
annotation	documentation Specifies a set of thrust records for an ANP aircraft.

element **fleet/anpProfileSet**

diagram	
type	**anpProfileSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpAirplaneId** **profile**
annotation	documentation The profile set for an ANP aircraft.

element **fleet/anpHeloNoiseGroup**

diagram	

type	**anpHeloNoiseGroup**
properties	minOcc 0 maxOcc unbounded content complex
children	**noiseId spectralClassApproach spectralClassDeparture spectralClassFlyover speedApproach speedDeparture speedFlyover npdCurves**
annotation	documentation This element contains the three spectral class references for a given helicopter noise group with the corresponding thrust setting type and model type.

element **fleet/anpHelicopter**

diagram

anpHelicopter
0..∞
Creates a new ANP helicopter.
diameter
The helicopter diameter (feet). Valid values: 0 to 1000.
rpm
The helicopter rotor speed (revolutions per minute). Valid values: 0 to 1000.
maxTakeoffWeight
The max gross takeoff weight (pounds). Valid values: 0 to 50000.
hasWheels
Flag indicating if the helicopter has wheels. Valid values: Y (yes), N (no).
modelType
The helicopter model type. Valid values: I (INM), N (NoiseMap).
bLeft0
Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
bLeft1
Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
bLeft2
Adjust flyover noise as a function of speed, left. Valid values: Min = -999.99 Max = 999.99.
bCenter0
Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
bCenter1
Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
bCenter2
Adjust flyover noise as a function of speed, center. Valid values: Min = -999.99 Max = 999.99.
bRight0
Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
bRight1
Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
bRight2
Adjust flyover noise as a function of speed, right. Valid values: Min = -999.99 Max = 999.99.
dbVerticalAscent
Decibel offset added to NPD levels, vertical ascent (dB). Valid values: Min = -50 Max = 50.
dbVerticalDescent

type	**anpHelicopter**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpHelicopterId noiseId directivityId description owner engineTypeCode numberRotors diameter rpm maxTakeoffWeight hasWheels modelType bLeft0 bLeft1 bLeft2 bCenter0 bCenter1 bCenter2 bRight0 bRight1 bRight2 dbVerticalAscent dbVerticalDescent dbHorizontalAcceleration dbClimbAcceleration dbHorizontalDeceleration dbDescendDeceleration**
annotation	documentation Creates a new ANP helicopter.

element **fleet/anpHeloDirectivitySet**

diagram	
type	**anpHeloDirectivitySet**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpHelicopterId anpHeloDirectivity**
annotation	documentation A set of helicopter directivities.

element **fleet/anpHeloProfileSet**

diagram	
type	**anpHeloProfileSet**
properties	minOcc 0 maxOcc unbounded

	content complex
children	**anpHelicopterId** **profile**
annotation	documentation A profile set for an ANP helicopter.

element **fleet/badaAirplane**

diagram	

badaAirplane
badaAirplaneId
ID of a BADA airplane model. Must be unique.
mfgDescription
Manufacturer description.
numEngines
The number of engines.
engineTypeCode
The engine type code: J/T/P.
wakeCategory
The wake category.
referenceAircraftMass
Minimum aircraft mass (min = 0.0, max = 455.0, metric ton).
minAircraftMass
Minimum aircraft mass (min = 0.0, max = 455.0, metric ton).
maxAircraftMass
Maximum aircraft mass (min = 0.0, max = 455.0, metric ton).
maxPayloadMass
Maximum payload mass (min = 0.0, max = 455.0, (metric ton).
weightGradient
Weight gradient on maximum altitude (min = 0.0, max = 10.0, feet/kg).
maxOperatingSpeed
Maximum operating speed (KCAS) (min = 0.0, max = 600.0, UNITS: knots).
maxOperatingMachNumber
Maximum operating Mach number (min = 0.0, max = 10.0, UNITS: dimensionless).
maxOperatingAltitude
Maximum operating altitude (min = -9999.0, max = 60000.0, UNITS: feet, pressure altitude).
maxAltitudeAtMaxTakeoffWeight
Maximum altitude at maximum takeoff weight and ISA (Min = -9999.0, Max = 60000.0, UNITS: feet, pressure altitude).
temperatureGradientOnMaximum...
Temperature gradient on maximum altitude.
wingSurfaceArea
Wing surface area (min = 0.0, max = 1000.0, square meters).
buffetOnsetLiftCoeff
Buffet onset lift coefficient (jet only) (min = 0.0, max = 10.0).
buffetingGradient
Buffeting gradient (jet only).
machDragCoeff
Mach drag coefficient (min = 0.0, max = 10.0).
badaAirplane
0..∞
Describes a new user-defined BADA airplane.

type	**badaAirplane**
properties	minOcc 0 maxOcc unbounded content complex
children	**badaAirplaneId** **mfgDescription** **numEngines** **engineTypeCode** **wakeCategory** **referenceAircraftMass** **minAircraftMass** **maxAircraftMass** **maxPayloadMass** **weightGradient** **maxOperatingSpeed** **maxOperatingMachNumber** **maxOperatingAltitude** **maxAltitudeAtMaxTakeoffWeight** **temperatureGradientOnMaximumAltitude** **wingSurfaceArea** **buffetOnsetLiftCoeff** **buffetingGradient** **machDragCoeff**
annotation	documentation Describes a new user-defined BADA airplane.

element **fleet/badaAltitudeDistributionSet**

diagram	
type	**badaAltitudeDistributionSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**badaAirplaneId** **altitudeDistribution**
annotation	documentation A block for defining a BADA altitude distribution set.

element **fleet/badaDefaultAltitudeDistributionSet**

diagram	
type	**badaAltitudeDistributionSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**badaAirplaneId** **altitudeDistribution**
annotation	documentation A block for defining the BADA default altitude distribution set.

element **fleet/badaProfileSet**

diagram	
type	**badaProfileSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**badaAirplaneId** **profile**
annotation	documentation

	A block used to define a custom BADA profile set.

element **fleet/badaConfigSet**

diagram	
type	**badaConfigSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**badaAirplaneId** **badaConfig**
annotation	documentation A block for a custom BADA airplane configuration coefficient set.

element **fleet/badaFuel**

diagram	
type	**badaFuel**
properties	minOcc 0 maxOcc unbounded content complex
children	**badaAirplaneId** **coeff_CF1** **coeff_CF2** **coeff_CF3** **coeff_CF4** **coeff_CR**
annotation	documentation A BADA fuel data record.

element **fleet/badaThrust**

diagram	

type	**badaThrust**
properties	minOcc 0 maxOcc unbounded content complex
children	**badaAirplaneId** **coeff_TC1** **coeff_TC2** **coeff_TC3** **coeff_TC4** **coeff_TC5** **coeff_TDL** **coeff_TDH** **coeff_APP** **coeff_LD** **descentAlt** **descentSpeed** **descentMach** **notes**
annotation	documentation Custom BADA airplane thrust data sets.

element **fleet/bada4ProfileSet**

diagram	
type	**bada4ProfileSet**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpAirplaneId** **bada4AirplaneModel** **bada4Engine** **bada4Suffix** **bada4profile**
annotation	documentation A profile set for an BADA4 airplane.

element **fleet/aircraft**

diagram	
type	**aircraft**

properties	minOcc 0 maxOcc unbounded content complex
children	**description** **airframeModel** **engineCode** **engineModCode** **anpAirplaneId** **badaAirplaneId** **anpHelicopterId** **bada4AirplaneModel** **bada4Engine** **bada4Suffix** **bada4FlapsMapSourceAnpId**
annotation	documentation A block used to create new user defined AEDT aircraft.

element **fleet/energyShare**

diagram	
type	**energyShare**
properties	minOcc 0 maxOcc unbounded content complex
children	**anpAirplaneId** **badaAirplaneId** **transEnergyShare**
annotation	documentation A custom BADA aircraft energy share set.

complexType **latitudeDecimalType**

diagram	
type	extension of **xs:double**
properties	base xs:double
used by	element **latlonCoordGroup/latitude**
attributes	Name: positive; Type: **derived by: xs:string**; Use: optional; Default: N; Fixed:; Annotation:
annotation	documentation Latitude specified as degrees in decimal format. Can include optional attribute positive. (decimal degrees)

attribute **latitudeDecimalType/@positive**

type	restriction of **xs:string**
properties	use optional default N
facets	Kind Value Annotation pattern N|n|S|s

complexType **longitudeDecimalType**

diagram	
type	extension of **xs:double**

properties	base xs:double
used by	element **latlonCoordGroup/longitude**
attributes	Name: positive; Type: **derived by: xs:string**; Use: optional; Default: E; Fixed: ; Annotation:
annotation	documentation Longitude specified as degrees in decimal format. Can include optional attribute positive. (decimal degrees)

attribute **longitudeDecimalType/@positive**

type	restriction of **xs:string**
properties	use optional default E
facets	Kind: pattern; Value: E|e|W|w; Annotation:

complexType **polygon2DType**

diagram	
children	**dummy vertex**
used by	elements **boundary/polygon oneOrThreeCoords2DGroupSet/polygonCoords**
annotation	documentation Describes a 2 dimenstional polygon.

element **polygon2DType/dummy**

diagram	
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple

element **polygon2DType/vertex**

diagram	

type	**coord2DType**
properties	minOcc 3 maxOcc unbounded content complex
children	**latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone**
annotation	documentation A list of vertices defining the polygon.

complexType **polygon3DElevationType**

diagram	
children	**dummy vertex**
annotation	documentation The elevation or Z value for a polygon.

element **polygon3DElevationType/dummy**

diagram	
type	**xs:int**
properties	minOcc 0 maxOcc 1 content simple

element **polygon3DElevationType/vertex**

diagram	

type	**coord3DElevationType**
properties	minOcc 3 maxOcc unbounded content complex
children	**latitude latitudeDMS longitude longitudeDMS utmN utmE utmZone elevation**
annotation	documentation A list of vertices defining the polygon.

complexType **profiles**

diagram	
children	**departureProfile arrivalProfile**
used by	elements **operation/badaProfiles operation/saeProfiles**
annotation	documentation Contains an arrival and departure profile.

element **profiles/departureProfile**

diagram	
type	**profileType**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255

annotation	documentation A flight's departure profile.

element **profiles/arrivalProfile**

diagram	arrivalProfile A flight's arrival profile.
type	**profileType**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation A flight's arrival profile.

complexType **runup**

diagram	

children	**id** **aircraftType** **flightNumber** **tailNumber** **numOperations** **airport** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **opTime** **duration** **heading** **thrust**
used by	elements **AsifXml/runup** **case/runup**

attributes

Name	Type	Use	Default	Fixed	Annotation
dummy	**xs:int**	optional			

attribute **runup/@dummy**

type	**xs:int**
properties	use optional

element **runup/id**

diagram	
type	**string16**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation User-provided runup identifier.

element **runup/aircraftType**

diagram	
type	**aircraftType**
properties	content complex
children	**anpAircraftId** **airframeModel** **engineCode** **engineModCode** **apuName** **groundSupportEquipmentLTOOperationSet** **assignDefaultGse**
annotation	documentation Aircraft type employed in this runup operation.

element **runup/flightNumber**

diagram	
type	**string16**
properties	minOcc 0 maxOcc 1 content simple

facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation Optional flight number.

element **runup/tailNumber**

diagram	tailNumber Optional tail number.
type	**string8**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation Optional tail number.

element **runup/numOperations**

diagram	numOperations The number of occurences of this operation.
type	**xs:double**
properties	content simple
annotation	documentation The number of occurences of this operation.

element **runup/airport**

diagram	airport The airport code at which this operation occurs. airportCode attributes type country
type	**airportCode**
properties	content complex
facets	Kind Value Annotation minLength 0 maxLength 4
attributes	Name Type Use Default Fixed Annotation type **airportCodeType** optional ANY country **string3** optional ANY
annotation	documentation The airport code at which this operation occurs.

element **runup/opTime**

diagram	opTime The runup operation time.
type	**xs:dateTime**
properties	content simple
annotation	documentation The runup operation time.

element **runup/duration**

diagram	**duration** The duration of the runup.
type	**xs:double**
properties	content simple
annotation	documentation The duration of the runup.

element **runup/heading**

diagram	**heading** The orientation of the aircraft.
type	**xs:double**
properties	content simple
annotation	documentation The orientation of the aircraft.

element **runup/thrust**

diagram	**thrust** The thrust employed for this runup operation.
type	**xs:double**
properties	content simple
annotation	documentation The thrust employed for this runup operation.

complexType **runwayEnd**

diagram	

children	**name** **latitude** **latitudeDMS** **longitude** **longitudeDMS** **utmN** **utmE** **utmZone** **elevation** **threshCrossHeight** **threshElevation** **glideSlope** **intAltitude** **depDispThresh** **appDispThresh** **percentWind** **isHelipad**
used by	element **runway/runwayEnd**

annotation	documentation Characterizes the runway's endpoint.

element **runwayEnd/name**

diagram	**name** ID of the runway's endpoint.
type	**string8**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation ID of the runway's endpoint.

element **runwayEnd/elevation**

diagram	**elevation** Runway endpoint's elevation above MSL in feet. (feet)
type	**xs:double**
properties	content simple
annotation	documentation Runway endpoint's elevation above MSL in feet. (feet)

element **runwayEnd/threshCrossHeight**

diagram	**threshCrossHeight** Approach threshold crossing height AGL (feet)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Approach threshold crossing height AGL (feet)

element **runwayEnd/threshElevation**

diagram	**threshElevation** Elevation of runway's endpoint above or below MSL (feet)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Elevation of runway's endpoint above or below MSL (feet)

element **runwayEnd/glideSlope**

diagram	**glideSlope** Glide slope for runway's endpoint. Valid values: 2 to 6 (decimal degrees)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Glide slope for runway's endpoint. Valid values: 2 to 6 (decimal degrees)

element **runwayEnd/intAltitude**

diagram	**intAltitude** Altitude at which glide slope should be intercepted above ground level. (feet)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Altitude at which glide slope should be intercepted above ground level. (feet)

element **runwayEnd/depDispThresh**

diagram	**depDispThresh** Displaced threshold length at departure end of runway. (feet)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Displaced threshold length at departure end of runway. (feet)

element **runwayEnd/appDispThresh**

diagram	**appDispThresh** Displaced threshold length at arrival end of runway. (feet)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Displaced threshold length at arrival end of runway. (feet)

element **runwayEnd/percentWind**

diagram	**percentWind** Percent change in airport average headwind. (%)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Percent change in airport average headwind. (%)

element **runwayEnd/isHelipad**

diagram	**isHelipad** Indicates if this end of the runway is also a helipad. Valid values: Y = yes, N = no.
type	**xs:string**
properties	minOcc 0 maxOcc 1 content simple
annotation	documentation Indicates if this end of the runway is also a helipad. Valid values: Y = yes, N = no.

complexType **scenarioAirportLayoutType**

diagram

children	**airportLayoutName** **mixingHeight** **useHourlyMetData** **averageTemperature** **dailyHighTemperature** **dailyLowTemperature** **pressure** **pressureMSL** **humidty** **windSpeed** **windDirection** **ceiling** **visibility** **airportConfigSet** **airportCapacity**
used by	element **scenarioAirportLayoutSet/scenarioAirportLayout**
annotation	documentation Describes weather conditions.

element **scenarioAirportLayoutType/airportLayoutName**

diagram	**airportLayoutName** Airport layout name.
type	**string255**
properties	content simple
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airport layout name.

element **scenarioAirportLayoutType/mixingHeight**

diagram	**mixingHeight** Height at the top layer of atmosphere where relatively vigorous mixing of pollutants and other gases takes place for the airport in a given month. Varies diurnally and seasonally. (feet AFE)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Height at the top layer of atmosphere where relatively vigorous mixing of pollutants and other gases takes place for the airport in a given month. Varies diurnally and seasonally. (feet AFE)

element **scenarioAirportLayoutType/useHourlyMetData**

diagram	**useHourlyMetData** If true, use user-defined hourly meteorological data to compute emissions. If false, use default annual averages to compute emissions. (true or false)
type	**xs:boolean**
properties	minOcc 0 maxOcc 1 content simple default false
annotation	documentation If true, use user-defined hourly meteorological data to compute emissions. If false, use default annual averages to compute emissions. (true or false)

element **scenarioAirportLayoutType/averageTemperature**

diagram	**averageTemperature** Average temperature (°F).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Average temperature (°F).

element **scenarioAirportLayoutType/dailyHighTemperature**

diagram	**dailyHighTemperature** Average daily high temperature (°F).
type	**xs:double**

properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Average daily high temperature (°F).

element **scenarioAirportLayoutType/dailyLowTemperature**

diagram	**dailyLowTemperature** Average daily low temperature (°F).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Average daily low temperature (°F).

element **scenarioAirportLayoutType/pressure**

diagram	**pressure** Average barometric pressure. (in inches Hg)
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Average barometric pressure. (in inches Hg)

element **scenarioAirportLayoutType/pressureMSL**

diagram	**pressureMSL** Average barometric pressure at mean sea level.
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Average barometric pressure at mean sea level.

element **scenarioAirportLayoutType/humidty**

diagram	**humidty** Relative humidity (%).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Relative humidity (%).

element **scenarioAirportLayoutType/windSpeed**

diagram	**windSpeed** Wind speed at airport surface (mph).

type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Wind speed at airport surface (mph).

element **scenarioAirportLayoutType/windDirection**

diagram	**windDirection** Wind direction. Valid values: 0-360. (decimal degrees)
type	**int0to360**
properties	minOcc 0 maxOcc 1 content simple default 1
facets	Kind Value Annotation minInclusive 0 maxExclusive 360
annotation	documentation Wind direction. Valid values: 0-360. (decimal degrees)

element **scenarioAirportLayoutType/ceiling**

diagram	**ceiling** Ceiling (feet AFE).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Ceiling (feet AFE).

element **scenarioAirportLayoutType/visibility**

diagram	**visibility** Visibility (statute miles).
type	**xs:double**
properties	minOcc 0 maxOcc 1 content simple default 0
annotation	documentation Visibility (statute miles).

complexType **spectralClass**

diagram	**spectralClassId** Spectral Class ID - short value. Valid values 20,000 through 30,000 inclusive. **flightTypes** Flags indicating allowable flight types - A (arrival), D (departure), L (Level/Afterburner), U (Unknown). Options are: A, D, L, AD, AL, DL, ADL, or U **frequencyBand17** Frequency value for Band 17. Valid values: 0.0 through 100.0.

spectralClass
This element contains the definition for a single user-defined spectral class with 24 bands.
frequencyBand18
Frequency value for Band 18. Valid values: 0.0 through 100.0.
frequencyBand19
Frequency value for Band 19. Valid values: 0.0 through 100.0.
frequencyBand20
Frequency value for Band 20. Valid values: 0.0 through 100.0.
frequencyBand21
Frequency value for Band 21. Valid values: 0.0 through 100.0.
frequencyBand22
Frequency value for Band 22. Valid values: 0.0 through 100.0.
frequencyBand23
Frequency value for Band 23. Valid values: 0.0 through 100.0.
frequencyBand24
Frequency value for Band 24. Valid values: 0.0 through 100.0.
frequencyBand25
Frequency value for Band 25. Valid values: 0.0 through 100.0.
frequencyBand26
Frequency value for Band 26. Valid values: 0.0 through 100.0.
frequencyBand27
Frequency value for Band 27. Valid values: 0.0 through 100.0.
frequencyBand28
Frequency value for Band 28. Valid values: 0.0 through 100.0.
frequencyBand29
Frequency value for Band 29. Valid values: 0.0 through 100.0.
frequencyBand30
Frequency value for Band 30. Valid values: 0.0 through 100.0.
frequencyBand31
Frequency value for Band 31. Valid values: 0.0 through 100.0.
frequencyBand32
Frequency value for Band 32. Valid values: 0.0 through 100.0.
frequencyBand33
Frequency value for Band 33. Valid values: 0.0 through 100.0.
frequencyBand34
Frequency value for Band 34. Valid values: 0.0 through 100.0.
frequencyBand35
Frequency value for Band 35. Valid values: 0.0 through 100.0.

	frequencyBand36 Frequency value for Band 36. Valid values: 0.0 through 100.0. **frequencyBand37** Frequency value for Band 37. Valid values: 0.0 through 100.0. **frequencyBand38** Frequency value for Band 38. Valid values: 0.0 through 100.0. **frequencyBand39** Frequency value for Band 39. Valid values: 0.0 through 100.0. **frequencyBand40** Frequency value for Band 40. Valid values: 0.0 through 100.0.
children	**spectralClassId** **flightTypes** **frequencyBand17** **frequencyBand18** **frequencyBand19** **frequencyBand20** **frequencyBand21** **frequencyBand22** **frequencyBand23** **frequencyBand24** **frequencyBand25** **frequencyBand26** **frequencyBand27** **frequencyBand28** **frequencyBand29** **frequencyBand30** **frequencyBand31** **frequencyBand32** **frequencyBand33** **frequencyBand34** **frequencyBand35** **frequencyBand36** **frequencyBand37** **frequencyBand38** **frequencyBand39** **frequencyBand40**
used by	element **fleet/spectralClass**
annotation	documentation This element contains the definition for a single user-defined spectral class with 24 bands.

element **spectralClass/spectralClassId**

diagram	**spectralClassId** Spectral Class ID - short value. Valid values 20,000 through 30,000 inclusive.
type	**spectralClassId**
properties	content simple
facets	Kind Value Annotation minInclusive 20000 maxInclusive 30000
annotation	documentation Spectral Class ID - short value. Valid values 20,000 through 30,000 inclusive.

element **spectralClass/flightTypes**

diagram	**flightTypes** Flags indicating allowable flight types - A (arrival), D (departure), L (Level/Afterburner), U (Unknown). Options are: A, D, L, AD, AL, DL, ADL, or U
type	**spectralFlightType**
properties	minOcc 0 maxOcc 1 content simple
facets	Kind Value Annotation pattern A|D|L|AD|AL|DL|ADL|U
annotation	documentation Flags indicating allowable flight types - A (arrival), D (departure), L (Level/Afterburner), U (Unknown). Options are: A, D, L, AD, AL, DL, ADL, or U

element **spectralClass/frequencyBand17**

diagram	**frequencyBand17** Frequency value for Band 17. Valid values: 0.0 through 100.0.
type	**floatInclusive100**

properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 17. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand18**

diagram	**frequencyBand18** Frequency value for Band 18. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 18. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand19**

diagram	**frequencyBand19** Frequency value for Band 19. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 19. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand20**

diagram	**frequencyBand20** Frequency value for Band 20. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 20. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand21**

diagram	**frequencyBand21** Frequency value for Band 21. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 21. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand22**

diagram	**frequencyBand22** Frequency value for Band 22. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 22. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand23**

diagram	**frequencyBand23** Frequency value for Band 23. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 23. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand24**

diagram	**frequencyBand24** Frequency value for Band 24. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 24. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand25**

diagram	**frequencyBand25** Frequency value for Band 25. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 25. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand26**

diagram	**frequencyBand26** Frequency value for Band 26. Valid values: 0.0 through 100.0.

type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 26. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand27**

diagram	**frequencyBand27** Frequency value for Band 27. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 27. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand28**

diagram	**frequencyBand28** Frequency value for Band 28. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 28. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand29**

diagram	**frequencyBand29** Frequency value for Band 29. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 29. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand30**

diagram	**frequencyBand30** Frequency value for Band 30. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100

annotation	documentation Frequency value for Band 30. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand31**

diagram	**frequencyBand31** Frequency value for Band 31. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 31. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand32**

diagram	**frequencyBand32** Frequency value for Band 32. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 32. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand33**

diagram	**frequencyBand33** Frequency value for Band 33. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 33. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand34**

diagram	**frequencyBand34** Frequency value for Band 34. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 34. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand35**

diagram	

	frequencyBand35 Frequency value for Band 35. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 35. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand36**

diagram	**frequencyBand36** Frequency value for Band 36. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 36. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand37**

diagram	**frequencyBand37** Frequency value for Band 37. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 37. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand38**

diagram	**frequencyBand38** Frequency value for Band 38. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 38. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand39**

diagram	**frequencyBand39** Frequency value for Band 39. Valid values: 0.0 through 100.0.
type	**floatInclusive100**
properties	content simple

facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 39. Valid values: 0.0 through 100.0.

element **spectralClass/frequencyBand40**

diagram	
type	**floatInclusive100**
properties	content simple
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation Frequency value for Band 40. Valid values: 0.0 through 100.0.

simpleType **aircraftPerformanceModelType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **scenario/acftPerfModel**
facets	Kind Value Annotation enumeration ICAO enumeration SAE1845
annotation	documentation Type of aircraft performance model. Valid values: ICAO, SAE1845.

simpleType **AircraftSizeType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **runwayAssignment/aircraftSize**
facets	Kind Value Annotation enumeration S enumeration L enumeration H
annotation	documentation Aircraft size.

simpleType **airframeModel**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraft/airframeModel** **airframe/model**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Refers to an existing airframe model.

simpleType **airportCodeType**

type	restriction of **xs:string**
properties	base xs:string
used by	attribute **airportCode/@type**
facets	Kind Value Annotation enumeration ICAO

	enumeration IATA enumeration FAA enumeration OTHER enumeration ANY
annotation	documentation The type of an airport code.

simpleType **anpAirplaneId**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraftType/anpAircraftId** **aircraft/anpAirplaneId** **anpAirplane/anpAirplaneId** **anpThrustSet/anpAirplaneId** **anpFlapsSet/anpAirplaneId** **anpProfileSet/anpAirplaneId** **energyShare/anpAirplaneId** **bada4ProfileSet/anpAirplaneId** **bada4ProcedureStep/anpAirplaneId** **aircraft/bada4FlapsMapSourceAnpId**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation ID of ANP airplane. Must be a new, unique value.

simpleType **anpCoeffType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **anpAirplane/depThrustCoeffType**
facets	Kind Value Annotation pattern Jet|J|Prop|P

simpleType **anpFlapId**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **bada4ProcedureStep/anpFlapId** **anpFlaps/flapId** **anpProcedureStep/flapId**
facets	Kind Value Annotation minLength 0 maxLength 6

simpleType **anpHeloDirectId**

type	restriction of **xs:string**
properties	base xs:string
used by	element **anpHeloDirectivitySet/anpHelicopterId**
facets	Kind Value Annotation minLength 0 maxLength 12

simpleType **anpHeloDirectivityId**

type	restriction of **xs:string**
properties	base xs:string
used by	element **anpHelicopter/directivityId**
facets	Kind Value Annotation minLength 0 maxLength 12

simpleType **anpHeloGroundType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **anpHeloDirectivity/groundType**
facets	Kind Value Annotation pattern Hard|H|Software|S|File|F|None|N

simpleType **anpHeloId**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraft/anpHelicopterId** **anpHelicopter/anpHelicopterId** **anpHeloProfileSet/anpHelicopterId**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation ID of the helicopter.

simpleType **anpHeloNoiseId**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **anpHelicopter/noiseId** **anpHeloNoiseGroup/noiseId**
facets	Kind Value Annotation minLength 0 maxLength 255

simpleType **anpHeloSideType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **anpHeloNPDCurve/sideType**
facets	Kind Value Annotation pattern Left|L|Center|C|Right|R|Static|S

simpleType **anpNoiseId**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **anpNoiseGroup/noiseId** **anpAirplane/noiseId**
facets	Kind Value Annotation minLength 0 maxLength 255

simpleType **anpNpdNoiseType**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **anpNPDCurve/noiseType** **anpHeloNPDCurve/noiseType**
facets	Kind Value Annotation pattern S|M|E|P

simpleType **anpNpdOpMode**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **anpNPDCurve/opMode** **anpHeloNPDCurve/opMode**
facets	Kind Value Annotation pattern A|D|L|G|H|I|J|V|W|Y|Z|B|C|E|F|X|S

simpleType **anpOwnerType**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **anpHelicopter/owner** **anpAirplane/owner**
facets	Kind Value Annotation pattern Commercial|C|Military|M|General|G

simpleType **anpSizeCode**

type	restriction of **xs:string**
properties	base xs:string
used by	element **anpAirplane/sizeCode**
facets	Kind Value Annotation pattern Heavy|H|Large|L|Small|S

simpleType **apuName**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **airframe/auxiliaryPowerUnitId** **auxiliaryPowerUnit/baseAuxiliaryPowerUnit** **auxiliaryPowerUnit/name**
facets	Kind Value Annotation minLength 0 maxLength 30
annotation	documentation Name of the auxiliary power unit.

simpleType **bada4AirplaneModel**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraft/bada4AirplaneModel** **bada4ProfileSet/bada4AirplaneModel**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Model of BADA 4 airplane.

simpleType **bada4Engine**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraft/bada4Engine** **bada4ProfileSet/bada4Engine**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Airplane BADA 4 engine.

simpleType **bada4Suffix**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraft/bada4Suffix** **bada4ProfileSet/bada4Suffix**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation User-defined BADA 4 model suffix.

simpleType **badaAirplaneId**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraft/badaAirplaneId** **badaAirplane/badaAirplaneId** **badaAltitudeDistributionSet/badaAirplaneId** **badaProfileSet/badaAirplaneId** **badaConfigSet/badaAirplaneId** **badaFuel/badaAirplaneId** **badaThrust/badaAirplaneId** **energyShare/badaAirplaneId**
facets	Kind Value Annotation minLength 0

	maxLength 255
annotation	documentation ID of a BADA airplane model. Must be unique.

simpleType **badaPhaseType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **badaConfig/phase**
facets	Kind Value Annotation pattern InitialClimb|IC|Takeoff|TO|Approach|AP|Landing|LD|Cruise|CR

simpleType **badaWakeType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **badaAirplane/wakeCategory**
facets	Kind Value Annotation pattern Heavy|H|Light|L|Medium|M|SuperHeavy|J

simpleType **directionType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **taxipath/direction**
facets	Kind Value Annotation pattern A|Arrival|D|Departure|I|Inbound|O|Outbound
annotation	documentation Supports the direction type of a taxi path. Direction type can be either arrival, departure, inbound, or outbound.

simpleType **doubleExclusive0Inclusive10**

type	restriction of **xs:double**
properties	base xs:double
used by	element **pointStationarySource/stackDiameter**
facets	Kind Value Annotation maxInclusive 10 minExclusive 0
annotation	documentation A double value in the range (0,10).

simpleType **doubleExclusive10**

type	restriction of **xs:double**
properties	base xs:double
facets	Kind Value Annotation minInclusive 0 maxExclusive 10
annotation	documentation A double value in the range [0,10).

simpleType **doubleExclusive100**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **taxiway/dispersionWidth** **categorySandSaltPile/fastestMileOfWind** **categorySandSaltPile/frictionVelocity** **categoryBoilerHeater/fuelAshContent** **categoryBoilerHeater/fuelSulfurContent** **categoryGenerator/fuelSulfurContent** **airportConfig/maxWindSpeed** **categoryFuelTank/verticalTank/meanWindSpeed** **categorySandSaltPile/meanWindSpeed** **airportConfig/minWindSpeed** **categoryDeicingArea/solutionConcentrationPercent**
facets	Kind Value Annotation minInclusive 0

	maxExclusive 100
annotation	documentation A double value in the range [0,100).

simpleType **doubleExclusive1000**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **categoryFuelTank/verticalTank/averageSolutionLevel** **categoryBoilerHeater/fuelCalciumSulfurRatio** **categorySandSaltPile/massDisturbedPerDisturbance** **categoryFuelTank/verticalTank/maximumSolutionLevel** **categoryFuelTank/tankDiameter** **categoryFuelTank/verticalTank/tankHeight** **categoryFuelTank/horizontalTank/tankLength** **categoryAircraftEngine/timePercentPower100** **categoryAircraftEngine/timePercentPower30** **categoryAircraftEngine/timePercentPower7** **categoryAircraftEngine/timePercentPower85**
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation A double value in the range [0,1000).

simpleType **doubleExclusive10000**

type	restriction of **xs:double**
properties	base xs:double
used by	element **categorySandSaltPile/erodedSurfaceArea**
facets	Kind Value Annotation minInclusive 0 maxExclusive 10000
annotation	documentation A double value in the range [0,10000).

simpleType **doubleExclusive2000**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **categoryDeicingArea/ethyleneGlycolDensity** **categoryDeicingArea/propyleneGlycolDensity** **categorySolventDegreaser/solutionDensity**
facets	Kind Value Annotation minInclusive 0 maxExclusive 2000
annotation	documentation A double value in the range [0,2000).

simpleType **doubleExclusiveRange100**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **categorySandSaltPile/moistureContent** **categorySandSaltPile/surfaceRoughness**
facets	Kind Value Annotation minExclusive 0 maxExclusive 100
annotation	documentation A double value in the range (0,100).

simpleType **doubleInclusive1**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **userGroundSupportEquipment/defaultLoadFactor** **groundSupportEquipmentGateAssignment/fractionAssigned** **categoryBoilerHeater/pm25ToPm10Ratio** **categoryGenerator/pm25ToPm10Ratio** **categoryIncinerator/pm25ToPm10Ratio** **categoryOther/pm25ToPm10Ratio** **categorySandSaltPile/surfaceWindSpeedFraction**
facets	Kind Value Annotation minInclusive 0 maxInclusive 1

annotation	documentation A double value in the range [0,1].

simpleType **doubleInclusive100**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **runwayAssignment/arrivalPercentage** **runwayAssignment/departurePercentage** **categoryBoilerHeater/pollutionControlFactorCO** **categoryGenerator/pollutionControlFactorCO** **categoryIncinerator/pollutionControlFactorCO** **categoryOther/pollutionControlFactorCO** **categoryBoilerHeater/pollutionControlFactorHC** **categoryOther/pollutionControlFactorHC** **categoryBoilerHeater/pollutionControlFactorNOx** **categoryGenerator/pollutionControlFactorNOx** **categoryIncinerator/pollutionControlFactorNOx** **categoryOther/pollutionControlFactorNOx** **categoryBoilerHeater/pollutionControlFactorPM10** **categoryGenerator/pollutionControlFactorPM10** **categoryIncinerator/pollutionControlFactorPM10** **categoryOther/pollutionControlFactorPM10** **categoryBoilerHeater/pollutionControlFactorSOx** **categoryGenerator/pollutionControlFactorSOx** **categoryIncinerator/pollutionControlFactorSOx** **categoryOther/pollutionControlFactorSOx** **categoryBoilerHeater/pollutionControlFactorTNMOC** **categoryBoilerHeater/pollutionControlFactorTOC** **categoryGenerator/pollutionControlFactorTOC** **categoryBoilerHeater/pollutionControlFactorVOC** **categoryGenerator/pollutionControlFactorVOC** **categoryIncinerator/pollutionControlFactorVOC** **categorySurfaceCoatingPainting/pollutionControlFactorVOC** **pointStationarySource/releaseHeight** **areaStationarySource/releaseHeight** **volumeStationarySource/releaseHeight** **runwayAssignment/tgoPercentage**
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation A double value in the range [0,100].

simpleType **doubleInclusive1000**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **categoryBoilerHeater/ashTermPm10** **categoryGenerator/CO_EF** **categoryBoilerHeater/CO_EI** **categoryOther/CO_EI** **categoryGenerator/CO_EI** **categoryIncinerator/CO_EI** **categoryBoilerHeater/constantTermPm10** **categoryBoilerHeater/constantTermSOx** **categoryGenerator/NOx_EF** **categoryBoilerHeater/NOx_EI** **categoryIncinerator/NOx_EI** **categoryGenerator/NOx_EI** **categoryOther/NOx_EI** **categoryGenerator/PM10_EF** **categoryGenerator/PM10_EI** **categoryIncinerator/PM10_EI** **categoryOther/PM10_EI** **categoryGenerator/SOx_EF** **categoryGenerator/SOx_EI** **categoryIncinerator/SOx_EI** **categoryOther/SOx_EI** **categoryBoilerHeater/sulfurTermPm10** **categoryBoilerHeater/sulfurTermSOx** **categoryBoilerHeater/THC_EI** **categoryOther/THC_EI** **categoryBoilerHeater/TNMOC_EI** **categoryGenerator/TOC_EF** **categoryBoilerHeater/TOC_EI** **categoryBoilerHeater/VOC_EI** **categoryGenerator/VOC_EI** **categoryIncinerator/VOC_EI** **categorySurfaceCoatingPainting/VOC_EI** **categoryDeicingArea/VOC_EI**
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation A double value in the range [0,1000].

simpleType **doubleInclusive10000**

type	restriction of **xs:double**
properties	base xs:double
used by	element **categoryGenerator/powerRatingHorsepower**
facets	Kind Value Annotation minInclusive 0 maxInclusive 10000
annotation	documentation A double value in the range [0,10000].

simpleType **doubleInclusive2000**

type	restriction of **xs:double**
properties	base xs:double
facets	Kind Value Annotation minInclusive 0 maxInclusive 2000
annotation	documentation A double value in the range [0,2000].

simpleType **doubleInclusive24**

type	restriction of **xs:double**
properties	base xs:double

used by	elements **airportConfig/endHour** **airportConfig/startHour**
facets	Kind Value Annotation minInclusive 0 maxInclusive 24
annotation	documentation A double value in the range [0,24].

simpleType **doubleInclusive4000**

type	restriction of **xs:double**
properties	base xs:double
used by	element **roadwayOperation/roundTripDistance**
facets	Kind Value Annotation minInclusive 0 maxInclusive 4000
annotation	documentation A double value in the range [0,4000].

simpleType **doubleInclusiveRange0to600**

type	restriction of **xs:double**
properties	base xs:double
used by	element **pointStationarySource/temperature**
facets	Kind Value Annotation minInclusive 0 maxInclusive 600
annotation	documentation A double value in the range [0,600].

simpleType **doubleInclusiveRange1to30**

type	restriction of **xs:double**
properties	base xs:double
used by	element **pointStationarySource/gasVelocity**
facets	Kind Value Annotation minInclusive 1 maxInclusive 30
annotation	documentation A double value in the range [1,30].

simpleType **doubleMin0**

type	restriction of **xs:double**
properties	base xs:double
used by	elements **quarterHourlyProfile/temporalFactor** **monthlyProfile/temporalFactorApril** **monthlyProfile/temporalFactorAugust** **monthlyProfile/temporalFactorDecember** **monthlyProfile/temporalFactorFebruary** **dailyProfile/temporalFactorFriday** **monthlyProfile/temporalFactorJanuary** **monthlyProfile/temporalFactorJuly** **monthlyProfile/temporalFactorJune** **monthlyProfile/temporalFactorMarch** **monthlyProfile/temporalFactorMay** **dailyProfile/temporalFactorMonday** **monthlyProfile/temporalFactorNovember** **monthlyProfile/temporalFactorOctober** **dailyProfile/temporalFactorSaturday** **monthlyProfile/temporalFactorSeptember** **dailyProfile/temporalFactorSunday** **dailyProfile/temporalFactorThursday** **dailyProfile/temporalFactorTuesday** **dailyProfile/temporalFactorWednesday**
facets	Kind Value Annotation minInclusive 0
annotation	documentation A double value with a lower inclusive bound of 0.

simpleType **emissionsSourceType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **case/source**

facets	Kind Value Annotation enumeration Container enumeration Aircraft enumeration GSE Population enumeration Parking Facilities enumeration Roadways enumeration Stationary Sources
annotation	documentation Source of emissions.

simpleType **emissionsUnitsType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **study/emissionsUnits**
facets	Kind Value Annotation enumeration MetricTonnes enumeration Kilograms enumeration Grams enumeration ImperialTons enumeration Pounds
annotation	documentation Unit of measure for a given emission.

simpleType **empty-string**

type	restriction of **xs:string**
properties	base xs:string
facets	Kind Value Annotation enumeration

simpleType **engineCode**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraftEngine/code** **aircraft/engineCode**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation Code for an airframe's engine.

simpleType **engineModCode**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraftEngineMod/code** **aircraftType/engineModCode** **aircraft/engineModCode**
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation Airplane's engine modification code.

simpleType **engineModel**

type	restriction of **xs:string**
properties	base xs:string
used by	element **aircraftEngine/model**
facets	Kind Value Annotation minLength 0 maxLength 255

simpleType **engineType**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraftEngine/engineType** **anpHelicopter/engineTypeCode** **anpAirplane/engineTypeCode** **badaAirplane/engineTypeCode**
facets	Kind Value Annotation pattern Jet|J|Turbo|Turboprop|T|Prop|Piston|P
annotation	documentation Type of engine on this airframe. Valid values: E (Electric), J (Jet), P (Piston), T (Turboprop).

simpleType **floatExclusive0Inclusive10**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation maxInclusive 10 minExclusive 0
annotation	documentation A real number in the range (0,10].

simpleType **floatExclusive10**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxExclusive 10
annotation	documentation A real number in the range [0,10).

simpleType **floatExclusive100**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxExclusive 100
annotation	documentation A real number in the range [0,100).

simpleType **floatExclusive1000**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxExclusive 1000
annotation	documentation A real number in the range [0,1,000).

simpleType **floatExclusive10000**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxExclusive 10000
annotation	documentation A real number in the range [0,10,000).

simpleType **floatExclusive2000**

type	restriction of **xs:float**
properties	base xs:float

facets	Kind Value Annotation minInclusive 0 maxExclusive 2000
annotation	documentation A real number in the range [0,2,000).

simpleType **floatExclusiveRange100**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minExclusive 0 maxExclusive 100
annotation	documentation A real number in the range (0,100).

simpleType **floatInclusive1**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxInclusive 1
annotation	documentation A real number in the range [0,1].

simpleType **floatInclusive100**

type	restriction of **xs:float**
properties	base xs:float
used by	elements **spectralClass/frequencyBand17** **spectralClass/frequencyBand18** **spectralClass/frequencyBand19** **spectralClass/frequencyBand20** **spectralClass/frequencyBand21** **spectralClass/frequencyBand22** **spectralClass/frequencyBand23** **spectralClass/frequencyBand24** **spectralClass/frequencyBand25** **spectralClass/frequencyBand26** **spectralClass/frequencyBand27** **spectralClass/frequencyBand28** **spectralClass/frequencyBand29** **spectralClass/frequencyBand30** **spectralClass/frequencyBand31** **spectralClass/frequencyBand32** **spectralClass/frequencyBand33** **spectralClass/frequencyBand34** **spectralClass/frequencyBand35** **spectralClass/frequencyBand36** **spectralClass/frequencyBand37** **spectralClass/frequencyBand38** **spectralClass/frequencyBand39** **spectralClass/frequencyBand40**
facets	Kind Value Annotation minInclusive 0 maxInclusive 100
annotation	documentation A real number in the range [0,100].

simpleType **floatInclusive1000**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxInclusive 1000
annotation	documentation A real number in the range [0,1,000].

simpleType **floatInclusive10000**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxInclusive 10000
annotation	documentation A real number in the range [0,10,000].

simpleType **floatInclusive2000**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxInclusive 2000
annotation	documentation A real number in the range [0,2,000].

simpleType **floatInclusive24**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxInclusive 24
annotation	documentation A real number in the range [0,24].

simpleType **floatInclusive4000**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 0 maxInclusive 4000
annotation	documentation A real number in the range [0,4,000].

simpleType **floatInclusiveRange1to30**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 1 maxInclusive 30
annotation	documentation A real number in the range [1,30].

simpleType **floatInclusiveRange32to600**

type	restriction of **xs:float**
properties	base xs:float
facets	Kind Value Annotation minInclusive 32 maxInclusive 600
annotation	documentation A real number in the range [32,600].

simpleType **fuelType**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **parkingFacilityOperation/fuelType** **roadwayOperation/fuelType** **groundSupportEquipmentPopulationOperation/fuelType** **groundSupportEquipmentLTOOperation/fuelType**
facets	Kind Value Annotation pattern G|Gasoline|D|Diesel|C|Compressed Natural Gas|L|Liquefied Petroleum Gas|E|Electric
annotation	documentation Supports legacy EDMS studies relating to content that contains different types of fuel use. Fuel types can be based on either gasoline, diesel, compressed natural gas, liquid propane gas, or electric based.

simpleType **groundVehicleType**

type	restriction of **xs:string**

properties	base xs:string
used by	elements **parkingFacilityOperation/vehicleType** **roadwayOperation/vehicleType**
facets	Kind Value Annotation pattern 0|Default Fleet Mix|1|Passenger Cars|2|Light Trucks 1|3|Light Trucks 2|4|Light Trucks 3|5|Light Trucks 4|6|Class 2b Heavy Trucks|7|Class 3 Heavy Trucks|8|Class 4 Heavy Trucks|9|Class 5 Heavy Trucks|10|Class 6 Heavy Trucks|11|Class 7 Heavy Trucks|12|Class 8a Heavy Trucks|13|Class 8b Heavy Trucks|14|School Busses|15|Transit and Urban Busses|16|Motorcycle
annotation	documentation Supports legacy EDMS studies relating to the use of ground vehicles.Ground vehicle types can range from fleet mixes, passanger cars, and various light or heavy trucks.

simpleType **int0to23**

type	restriction of **xs:int**
properties	base xs:int
used by	attribute **quarterHourlyProfile/temporalFactor/@startHour**
facets	Kind Value Annotation minInclusive 0 maxInclusive 23
annotation	documentation An integer in the range [0,23].

simpleType **int0to360**

type	restriction of **xs:int**
properties	base xs:int
used by	elements **airportConfig/endWindAngle** **airportConfig/startWindAngle** **scenarioAirportLayoutType/windDirection**
facets	Kind Value Annotation minInclusive 0 maxExclusive 360
annotation	documentation An integer in the range [0,360].

simpleType **int0to5**

type	restriction of **xs:int**
properties	base xs:int
used by	element **categoryOther/fuelUnits**
facets	Kind Value Annotation minInclusive 0 maxInclusive 5
annotation	documentation An integer in the range [0,5].

simpleType **int0to87**

type	restriction of **xs:int**
properties	base xs:int
facets	Kind Value Annotation minInclusive 0 maxInclusive 87
annotation	documentation An integer in the range [0,87].

simpleType **int1to13**

type	restriction of **xs:int**
properties	base xs:int
used by	element **categorySolventDegreaser/typeCode**
facets	Kind Value Annotation minInclusive 1 maxInclusive 13

annotation	documentation An integer in the range [1,13].

simpleType **int1to15**

type	restriction of **xs:int**
properties	base xs:int
facets	Kind Value Annotation minInclusive 1 maxInclusive 15
annotation	documentation An integer in the range [1,15].

simpleType **int1to2**

type	restriction of **xs:int**
properties	base xs:int
used by	element **categoryIncinerator/typeCode**
facets	Kind Value Annotation minInclusive 1 maxInclusive 2
annotation	documentation An integer in the range [1,2].

simpleType **int1to25**

type	restriction of **xs:int**
properties	base xs:int
used by	element **categoryFuelTank/typeCode**
facets	Kind Value Annotation minInclusive 1 maxInclusive 25
annotation	documentation An integer in the range [1,25].

simpleType **int1to4**

type	restriction of **xs:int**
properties	base xs:int
used by	element **categoryDeicingArea/typeCode**
facets	Kind Value Annotation minInclusive 1 maxInclusive 4
annotation	documentation An integer in the range [1,4].

simpleType **int1to5**

type	restriction of **xs:int**
properties	base xs:int
used by	elements **categorySandSaltPile/typeCode** **categoryTrainingFire/typeCode**
facets	Kind Value Annotation minInclusive 1 maxInclusive 5
annotation	documentation An integer in the range [1,5].

simpleType **int1to8**

type	restriction of **xs:int**
properties	base xs:int

used by	elements **categoryGenerator/typeCode** **categorySurfaceCoatingPainting/typeCode**
facets	Kind Value Annotation minInclusive 1 maxInclusive 8
annotation	documentation An integer in the range [1,8].

simpleType **int1to93**

type	restriction of **xs:int**
properties	base xs:int
facets	Kind Value Annotation minInclusive 1 maxInclusive 93
annotation	documentation An integer in the range [1,93].

simpleType **int5to65**

type	restriction of **xs:int**
properties	base xs:int
used by	element **roadwayOperation/speed**
facets	Kind Value Annotation minInclusive 5 maxInclusive 65
annotation	documentation An integer in the range [5,65].

simpleType **int6to13**

type	restriction of **xs:int**
properties	base xs:int
used by	element **categoryFuelTank/reidVaporPressure**
facets	Kind Value Annotation minInclusive 6 maxInclusive 13
annotation	documentation An integer in the range [6,13].

simpleType **int89to148**

type	restriction of **xs:int**
properties	base xs:int
facets	Kind Value Annotation minInclusive 89 maxInclusive 148
annotation	documentation An integer in the range [89,148].

simpleType **latitudeDMSType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **latlonCoordGroup/latitudeDMS**
facets	Kind Value Annotation pattern [0-9]{2}[\-|:|"][0-9]{2}[\-|:|'][0-9]{2}(.[0-9]{3})?[N|n|S|s]
annotation	documentation Latitude expressed as dd"mm'sss with optional indicator N, n, S, s. (degrees)

simpleType **longitudeDMSType**

type	restriction of **xs:string**

properties	base xs:string
used by	element **latlonCoordGroup/longitudeDMS**
facets	Kind Value Annotation pattern [0-9]?[0-9]{2}[\-|:|"][0-9]{2}[\-|:|'][0-9]{2}(.[0-9]{3})?[E|e|W|w]
annotation	documentation Longitude expressed as dd"mm'sss with optional indicator N, n, S, s. (degrees)

simpleType **nodeControlType**

type	restriction of **xs:string**
properties	base xs:string
used by	attributes **trackNode/altitude/@control** **trackNode/speed/@control**
facets	Kind Value Annotation pattern 0|None|1|AtOrBelow|2|Match|3|AtOrAbove
annotation	documentation Type of altitude clearance at this point.

simpleType **opType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **operation/opType**
facets	Kind Value Annotation pattern A|Arrival|D|Departure|V|Overflight|F|Circuit|T|TouchAndGo|R|Runup|W|RunwayToRunway|L|LTO|LandingTakoff|X|Taxi
annotation	documentation Type of operation.

simpleType **originSourceType**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **polarGrid/originSource** **polarReceptor/originSource**
facets	Kind Value Annotation pattern Gate|Parking Facility|Roadway|Runway|Stionary Source|Taxiway|Training Fire
annotation	documentation Supports the polarReceptor source type. Original source type can be either gate, parking facility, roadway, runway, stationary source, taxiway, and training fire.

simpleType **profileType**

type	**string255**
properties	base string255
used by	elements **profiles/arrivalProfile** **operation/badaProfile** **profiles/departureProfile** **operation/saeProfile**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation An aircraft's flight profile.

simpleType **quarterHourMinutes**

type	restriction of **xs:int**
properties	base xs:int
used by	attribute **quarterHourlyProfile/temporalFactor/@startMinutes**
facets	Kind Value Annotation enumeration 0 enumeration 15 enumeration 30 enumeration 45
annotation	documentation

	Either 0, 15, 30, or 45.

simpleType **spectralClassId**

type	restriction of **xs:short**
properties	base xs:short
used by	element **spectralClass/spectralClassId**
facets	Kind Value Annotation minInclusive 20000 maxInclusive 30000
annotation	documentation User-defined Spectral Class ID in the range 20,000 to 30,000 - inclusive.

simpleType **spectralFlightType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **spectralClass/flightTypes**
facets	Kind Value Annotation pattern A|D|L|AD|AL|DL|ADL|U
annotation	documentation Flags indicating allowable flight types - A (arrival), D (departure), L (Level/Afterburner), U (Unknown).

simpleType **string1**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **operation/arrivalStageLength** **operation/departureStageLength** **airframe/designationCode** **airframe/engineLocation** **airframe/engineType** **anpTsfcCoefficients/mode** **anpNoiseGroup/modelType** **anpHelicopter/modelType** **anpHeloProfile/operationType** **anpHeloProcedureStep/operationType** **anpFlaps/operationType** **anpProfile/operationType** **bada4Profile/operationType** **anpHeloDirectivity/opMode** **anpProfilePoint/opMode** **anpHeloProfile/profileStageLength** **anpHeloProcedureStep/profileStageLength** **anpProfile/profileStageLength** **airframe/sizeCode** **operation/stageLength** **anpHeloProcedureStep/stepType** **anpProcedureStep/stepType** **bada4ProcedureStep/stepType** **anpNoiseGroup/thrustSetType** **anpThrustGeneral/thrustType** **anpThrustJet/thrustType** **anpThrustProp/thrustType** **anpProcedureStep/thrustType** **bada4ProcedureStep/thrustType** **airframe/usageCode** **bada4Profile/weightClass**
facets	Kind Value Annotation minLength 0 maxLength 1
annotation	documentation A string up to one character long.

simpleType **string10**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **badaConfig/configName** **aircraftEngine/superseded**
facets	Kind Value Annotation minLength 0 maxLength 10
annotation	documentation A string up to 10 characters long.

simpleType **string100**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **operation/activityProfile** **airportConfig/configurationName** **activityProfile/dailyProfile** **aircraftEngine/manufacturer** **activityProfile/monthlyProfile** **airport/name** **quarterHourlyProfile/profileName** **dailyProfile/profileName** **monthlyProfile/profileName** **activityProfile/quarterHourlyProfile** **aircraftEngine/source** **airport/zone** attribute **activityProfile/@name**
facets	Kind Value Annotation minLength 0 maxLength 100
annotation	documentation

	A string up to 100 characters long.

simpleType **string11**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **windRoseStation/calmCriteria** **windRoseStation/endDayMonth** **windRoseStation/userString**
facets	Kind Value Annotation minLength 0 maxLength 11

simpleType **string12**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **badaProfile/aircraftVersion** **windRoseStation/beginDayMonth** **badaProfile/engine** **operation/userType**
facets	Kind Value Annotation minLength 0 maxLength 12
annotation	documentation A string up to 12 characters long.

simpleType **string14**

type	restriction of **xs:string**
properties	base xs:string
used by	element **windRoseData/directionRange**
facets	Kind Value Annotation minLength 0 maxLength 14

simpleType **string15**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **badaProfile/companyName** **airport/faaId**
facets	Kind Value Annotation minLength 0 maxLength 15
annotation	documentation A string up to 15 characters long.

simpleType **string16**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **nodeIdGroup/description** **operation/flightNumber** **runup/flightNumber** **case/hourlyWxMD5** **operation/id** **runup/id** **nodeIdGroup/id** **operation/userParam** attribute **AsifXml/@version**
facets	Kind Value Annotation minLength 0 maxLength 16
annotation	documentation A string up to 16 characters long.

simpleType **string2**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **badaProfile/companyCode2** **airframe/euroGroupCode** **badaProfile/massRangeValue**
facets	Kind Value Annotation minLength 0

	maxLength 2
annotation	documentation A string up to two characters long.

simpleType **string20**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **groundSupportEquipmentGateAssignment/gate** **taxiway/name** **taxipath/taxiwayName**
facets	Kind Value Annotation minLength 0 maxLength 20
annotation	documentation A string up to 20 characters long.

simpleType **string200**

type	restriction of **xs:string**
properties	base xs:string
used by	element **aircraftEngine/notes**
facets	Kind Value Annotation minLength 0 maxLength 200
annotation	documentation A string up to 200 characters long.

simpleType **string25**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraftEngine/emissionsEngineModel** **aircraftType/engineCode** **airport/facilityType** **aircraftEngine/performanceEngineModel** **airportWeatherStation/weatherStationName**
facets	Kind Value Annotation minLength 0 maxLength 25
annotation	documentation A string up to 25 characters long.

simpleType **string255**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **trackref/airportLayoutName** **scenarioAirportLayoutType/airportLayoutName** **study/description** **scenario/description** **case/description** **aircraft/description** **aircraftEngineMod/description** **anpHelicopter/description** **anpAirplane/description** **categoryAircraftEngine/engineCode** **bada4Profile/flightProcedure** **case/hourlyWxFile** **badaAirplane/mfgDescription** **study/name** **scenario/name** **case/name** **annualization/name** **annualizationCase/name** **building/name** **receptorSet/name** **pointReceptor/name** **airportLayoutType/name** **badaThrust/notes** **anpHeloProfile/profileGroupId** **anpHeloProcedureStep/profileGroupId** **anpProfile/profileGroupId** **case/reference/refCase** **case/reference/refScenario** **sensorNode/source** **study/terrainFiles** **trackref/trackName** simpleType **profileType**
facets	Kind Value Annotation minLength 0 maxLength 255
annotation	documentation A string up to 255 characters long.

simpleType **string3**

type	restriction of **xs:string**
properties	base xs:string
used by	element **badaProfile/companyCode1** attribute **airportCode/@country**
facets	Kind Value Annotation minLength 0

	maxLength 3
annotation	documentation A string up to three characters long.

simpleType **string30**

type	restriction of **xs:string**
properties	base xs:string
facets	Kind Value Annotation minLength 0 maxLength 30
annotation	documentation A string up to 30 characters long.

simpleType **string32**

type	restriction of **xs:string**
properties	base xs:string
used by	element **windRoseStation/windRoseDataSource**
facets	Kind Value Annotation minLength 0 maxLength 32

simpleType **string4**

type	restriction of **xs:string**
properties	base xs:string
used by	element **operation/carrier** complexType **airportCode**
facets	Kind Value Annotation minLength 0 maxLength 4
annotation	documentation A string up to four characters long.

simpleType **string40**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **groundSupportEquipmentPopulationOperation/activityProfile** **emissionsUsage/activityProfile** **operation/arrivalGate** **operation/departureGate** **taxipath/gateName** **userGroundSupportEquipment/gseName** **gate/name** **stationarySource/name** **parkingFacility/name** **roadway/name** **polarGrid/originName** **polarReceptor/originName** **stationarySourceOperation/refName** **parkingFacilityOperation/refName** **roadwayOperation/refName**
facets	Kind Value Annotation minLength 0 maxLength 40
annotation	documentation A string up to 40 characters long.

simpleType **string42**

type	restriction of **xs:string**
properties	base xs:string
used by	element **windRoseStation/windRoseStationDescription**
facets	Kind Value Annotation minLength 0 maxLength 42

simpleType **string5**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **airportWeatherStation/wbanId** **airportWeatherStation/weatherStationCode** **windRose/windRoseStationId** **windRoseStation/windRoseStationId**

facets	Kind Value Annotation minLength 0 maxLength 5

simpleType **string50**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **aircraftType/airframeModel** **airport/cityName** **aircraftEngine/combustor** **airport/state** **aircraftEngine/tfmtFlag**
facets	Kind Value Annotation minLength 0 maxLength 50
annotation	documentation A string up to 50 characters long.

simpleType **string6**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **centroid/bnaId** **airportWeatherStation/cooperativeId** **taxiTime/source**
facets	Kind Value Annotation minLength 0 maxLength 6
annotation	documentation A string up to six characters long.

simpleType **string64**

type	restriction of **xs:string**
properties	base xs:string
used by	element **track/name**
facets	Kind Value Annotation minLength 0 maxLength 64
annotation	documentation A string up to 64 characters long.

simpleType **string66**

type	restriction of **xs:string**
properties	base xs:string
used by	element **windRoseStation/windRoseDataSet**
facets	Kind Value Annotation minLength 0 maxLength 66

simpleType **string7**

type	restriction of **xs:string**
properties	base xs:string
used by	element **airport/dafifId**
facets	Kind Value Annotation minLength 0 maxLength 7

simpleType **string8**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **operation/arrivalRunway** **case/climateId** **operation/departureRunway** **climate/identifier** **runwayEnd/name** **trackref/runway** **track/runway** **runwayAssignment/runway** **taxipath/runwayName** **operation/tailNumber** **runup/tailNumber**

facets	Kind Value Annotation minLength 0 maxLength 8
annotation	documentation A string up to eight characters long.

simpleType **string9**

type	restriction of **xs:string**
properties	base xs:string
used by	element **windRoseStation/directionUnit**
facets	Kind Value Annotation minLength 0 maxLength 9

simpleType **studyType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **study/studyType**
facets	Kind Value Annotation enumeration Emissions enumeration Dispersion enumeration Noise and Emissions enumeration Noise and Dispersion
annotation	documentation Type of study. NOTE: AEDT only supports the Noise and Emissions value.

simpleType **taxiModelType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **scenario/taxiModel**
facets	Kind Value Annotation enumeration UserSpecified enumeration Delayed enumeration Sequencing
annotation	documentation Type of taxi modeling.

simpleType **timeInModeBasisType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **scenario/timeInModeBasis**
facets	Kind Value Annotation enumeration Performance enumeration ICAO
annotation	documentation Time in mode can either be based on ICAO or performance.

simpleType **trackType**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **trackref/optype** **track/optype**
facets	Kind Value Annotation pattern A|Arrival|D|Departure|V|Overflight|T|TouchAndGo|X|ArrivalHeliTaxi|O|DepartureHeliTaxi
annotation	documentation Type of track.

simpleType **trainingFireFuelType**

type	restriction of **xs:string**
properties	base xs:string
facets	Kind Value Annotation pattern JP-4|JP-5|JP-8|Propane|Tekflame
annotation	documentation Supports legacy EDMS studies relating to training fire content. Training fire fuel types can be either JP-4, JP-5, JP-8, propane, or tekflame.

simpleType **vectorTrackType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **trackVector/type**
facets	Kind Value Annotation pattern S|Straight|L|LeftTurn|R|RightTurn
annotation	documentation Type of vector.

simpleType **weatherDataYear**

type	union of (restriction of **xs:int**, restriction of **xs:string**)
used by	element **weatherData/year**
annotation	documentation There are expected to be 11 records for weather data - one each for the preceding 10 years and one AVG record for the Average of the ten years.

simpleType **wingType**

type	restriction of **xs:string**
properties	base xs:string
used by	element **track/wingtype**
facets	Kind Value Annotation pattern F|FixedWing|R|RotaryWing
annotation	documentation Type of wing. If not specified, AEDT attempts to determine the wing type based on the optype.

simpleType **yesNoType**

type	restriction of **xs:string**
properties	base xs:string
used by	elements **anpHelicopter/hasWheels** **anpAirplane/thrustRestore** **anpHeloProfile/useDirectivity** **anpHeloProfile/useTrack**
facets	Kind Value Annotation pattern Yes|Y|No|N
annotation	documentation Simple element allowing for either a choice of "yes" or "no".

XML Schema documentation generated by **XMLSpy** Schema Editor **http://www.altova.com/xmlspy**